## ANZ Standard Operating Procedure Paint Shop

## **Anti-Chip Coating Product List ANZ** 3M™ Car Wash Soap Concentrate, 3.78 litre, **Pre-Cleaning** PN38377 Pre-wash/clean vehicle prior to disassembly 3M™ All Purpose Cleaner (power wash undercarriage area at repair). and Degreaser Concentrate. 3.78 litre, PN 38350 3M™ General Purpose Adhesive Cleaner, aerosol, PN08987 OR 700 Adhesive Cleaner Solvent **Removal of Heavy Surface Contaminates** Scotch-Brite™ Clean N Strip Disc, Clean to remove heavy contaminants from repair area. PN57016 or Scotch-Brite™ Rolog Clean N Strip TR Disc, PN 07466 3M™ Cubitron™ II Clean Sanding Hookit™ Abrasive Disc, 150mm, 80+ OEM Coating Removal grade, PN 31371 Remove OEM coating as needed using Scotch-Brite™ 3M™ Advanced Finishing Glaze, Clean N Strip disc. Featheredge using grade 80 abrasive 710ml, PN05821 or 3M™ Flowable Finishing Glaze, 710ml, PN05824 or on DA sander. Blow off surface with clean, dry air. Clean 3M™ Platinum Plus Glaze, 476g, surface with 3M™ All Purpose Cleaner and Degreaser. PN03080 3M™ Hookit™ Purple Clean Sanding Sheet Roll. P180, 70mm x 12m, Filling/Leveling Surface PN30733; Disc 334U, 150mm, P320 Use polyester glaze to fill the repair area, bringing it the PN01812 same level as the surrounding coating. 3M™ Hookit™ Sanding Block Dust Free, 70mm x 127mm, PN 05207 Sanding and Primer 3M™ Dry Guide Coat, 50 gram applicator kit, PN 05861 Sand glaze using P180 on a hand block. Final featheredge area using P320 abrasive on a DA sander. 3M™ Hookit™ Soft Interface Blow off with clean, dry air. Final clean with VOC Pad,150mm x 10mm, PN 05777 compliant wax and grease remover. Apply primer or PN 50544 following paint company recommendations. 3M™ Soft Edge Foam Masking Tape PLUS, 21mm, PN 06293 Sanding Primer Apply 3M<sup>™</sup> Dry Guide Coat to primed surface. Sand 3M™ Smooth Transition primer using P320 on a DA sander with an interface pad. Tape, 6.4mm, PN 06800 Blow off with clean, dry air. Final clean with VOC compliant wax and grease remover. 3M™ Scotchblok™ Masking Paper 457mm x 228m, PN 06718 Masking Scotch® Performance Green Apply soft edge foam masking tape following existing Masking Tape 233+,12mm width, coating edge. Final mask the area using tape and paper to protect from overspray. 3M™ Accuspray™ HGP Pressure Spray Gun, PN 16587 **Coating Test Panel** 3M™ Rocker Protector Apply the coating to a test panel. Always apply a light Pouch, 162 ml, PN 08747 coat first, allow it to flash, and adjust the spray equipment to deliver the texture required to match the OEM 3M™ Trizact™ Hookit™ Blending appearance. Disc, 150mm, P1000, PN 02090 or Apply Coating Think About Your Health Apply anti chip coating to the repair area using settings from test panel, blending the material into surrounding area as needed. 3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300 **Blend Sanding** 3M™ Half Facepiece Use P1000 3M™ Trizact™ Disc on a DA sander to smooth Respirator, PN 07502 with appropriate cartridge the blend edges. This operation produces a smooth

transition without removing chip coating profile.

Visit www.3m.com.au/aad or www.3m.co.nz/aad for more SOPs and videos

3M<sup>™</sup> Lexa<sup>™</sup> Protective Eyewear, PN 15200 or 3M

Secure Fit AF401SF-AS