

3M™ Tegaderm™ I.V. Advanced Securement Dressing

1685 Application Technique



1 Prepare the site according to your facility's protocol. **Allow all preps and skin protectants to dry completely.** Open package and remove sterile dressing.



2 Peel liner from dressing, exposing adhesive surface. Flip dressing over so adhesive faces skin.



3 Position notched edge of dressing over catheter hub, placing stabilization border over catheter "wings". Do not stretch dressing over skin surface. Slightly overlap the stabilization border tabs under hub of lumens.



4 Press transparent portion of dressing into place.



5 While slowly peeling off paper frame, smooth dressing edges with fingertips. Smooth dressing from centre toward edges, using firm pressure.



6 Remove sterile tape strip from paper frame. Fold edge over itself, making a small tab for easier removal. Secure strip underneath the hub, with notch facing towards the insertion site.



7 Apply documentation label over catheter hub and label according to your facility's protocol.



8 Apply firm pressure to entire dressing to ensure optimal adhesion.

1685 Removal Technique



1 Remove tape strips applied to top of dressing.



2 Separate stabilization border tabs and gently peel the dressing back toward insertion site.



3 Slowly peel dressing back over itself while stabilizing catheter and supporting surrounding skin. A medical adhesive remover can be used if needed.

Skin & Wound Care Division 3M Canada

P.O. Box 5757
London, Ontario N6A 4T1
Canada
1-800-364-3577
www.3M.com/ca/healthcare

3M Health Care
2510 Conway Avenue
St. Paul, MN 55144
USA

3M and Tegaderm are trademarks of 3M.
Used under license in Canada.
Please recycle. Printed in Canada.
© 2014, 3M. All rights reserved.
1401-00053B



3M™ Tegaderm™ I.V. Advanced Securement Dressing

1685 PICC Application Technique



1 Prepare the site according to your facility's protocol. **Allow all preps and skin protectants to dry completely.** Open package and remove sterile dressing.



2 Peel liner from dressing, exposing adhesive surface. Flip dressing over so adhesive faces skin.



3 Position notched edge of dressing over catheter hub, placing stabilization border over catheter "wings". Do not stretch dressing over skin surface. Slightly overlap the stabilization border tabs under hub of lumens.



4 Press transparent portion of dressing into place.



5 While slowly peeling off paper frame, smooth dressing edges with fingertips. Smooth dressing from centre toward edges, using firm pressure.



6 Remove sterile tape strip from paper frame. Fold edge over itself, making a small tab for easier removal. Secure strip underneath the hub, with notch facing towards the insertion site.



7 Apply documentation label over catheter hub and label according to your facility's protocol.



8 Apply firm pressure to entire dressing to ensure optimal adhesion.

1685 PICC Removal Technique



1 Remove tape strips applied to top of dressing.



2 Separate stabilization border tabs and gently peel the dressing back toward insertion site.



3 Slowly peel dressing back over itself while stabilizing catheter and supporting surrounding skin. A medical adhesive remover can be used if needed.

Skin & Wound Care Division 3M Canada

P.O. Box 5757
London, Ontario N6A 4T1
Canada
1-800-364-3577
www.3M.com/ca/healthcare

3M Health Care
2510 Conway Avenue
St. Paul, MN 55144
USA

3M and Tegaderm are trademarks of 3M.
Used under license in Canada.
Please recycle. Printed in Canada.
© 2014, 3M. All rights reserved.
1401-00057E

