

Primer Masking

1



Clean

Clean part with soap and water, followed by a VOC compliant surface cleaner.

2



Back Masking

Back mask primer application area using tape and paper. Alternatively, use Soft Edge Foam Masking Tape Plus around area to be primed, along with masking paper.

3



Overspray Protection

Apply plastic film to remaining exposed areas, cut out repair area.

4



Seal Edge

Seal edge of masking film using wide width masking tape.

Visit www.3M.com.au/aad or www.3m.co.nz/aad for more SOPs and videos

Product List ANZ

3M™ Car Wash
Soap Concentrate,
3.78L, PN 38377



3M™ All Purpose
Cleaner and Degreaser
Concentrate, 3.78L,
PN 38350



3M™ ScotchbloK™
Masking Paper,
457mm. x 229m,
PN 06718



3M™ Overspray Protective Sheeting,
4.87m. x 106m roll, PN 06728;



Scotch® Performance
Green Masking Tape 233+,
18mm width, PN 26334
36mm width, PN 26338
48mm width, PN 26340



3M™ Soft Edge Foam
Masking Tape PLUS,
21mm x 49m, box,
PN 06293 or 50421



Think About Your Health

3M™ E-A-R™ Skull Screws™
Ear Plug, PN P1300



3M™ Half Facepiece
Respirator, PN 07502 with
appropriate cartridge



3M™ Lexa™ Protective
Eyewear, PN 15200 or 3M™
Secure Fit AF421SF-AS



Want a product sample or demo, or to speak to a 3M expert? Let us know here: <http://go.3M.com/4AHf>

For ordering information, contact your 3M Sales Representative