

Primer Masking	
1	 <p>Clean Clean part with soap and water, followed by a VOC compliant surface cleaner.</p>
2	 <p>Back Masking Back mask primer application area using tape and paper. Alternatively, use Soft Edge Foam Masking Tape Plus around area to be primed, along with masking paper.</p>
3	 <p>Overspray Protection Apply plastic film to remaining exposed areas, cut out repair area.</p>
4	 <p>Seal Edge Seal edge of masking film using wide width masking tape.</p>

Visit www.3M.com.au/aad or www.3m.co.nz/aad for more SOPs and videos

Product List ANZ	
<p>3M™ Car Wash Soap Concentrate, 3.78L, PN 38377</p>	
<p>3M™ All Purpose Cleaner and Degreaser Concentrate, 3.78L, PN 38350</p>	
<p>3M™ Scotchblok™ Masking Paper, 457mm. x 229m, PN 06718</p>	
<p>3M™ Overspray Protective Sheeting, 4.87m. x 106m roll, PN 06728;</p>	
<p>Scotch® Performance Green Masking Tape 233+, 18mm width, PN 26334 36mm width, PN 26338 48mm width, PN 26340</p>	
<p>3M™ Soft Edge Foam Masking Tape PLUS, 21mm x 49m, box, PN 06293 or 50421</p>	

Think About Your Health	
<p>3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300</p>	
<p>3M™ Half Facepiece Respirator, PN 07502 with appropriate cartridge</p>	
<p>3M™ Lexa™ Protective Eyewear, PN 15200 or 3M™ Secure Fit AF421SF-AS</p>	