

# Learn more about Cold Shrink



## Installation Tips of Cold shrink accessories

The installation of Cold shrink accessories is easy and simple, as aligning the accessory in the correct position and removing the support core is all that is required. If the support core gets stuck, the following tips will allow for an easy, successful installation.

First, make the cold shrink accessory slowly shrink until it is just touching the cable. The accessory can then be rotated to align it with the tape marker. When the accessory is positioned, removing a few additional wraps of the support core will secure the accessory. The best way to remove the support core is to move the end of the core around the cable counterclockwise and then apply a short pull. This method keeps the support core away from the cable and connector or lug. Be careful, if you make long pulls on the core, it can cause the core to dig into the cable. If this occurs do additional wraps of the core ribbon around the cable counterclockwise to keep the support core ribbon from getting stuck.

Lastly, while removing the support core, only touch the support core ribbon and not the accessory itself, as this will allow the accessory to install in the correct location.

Do you want to know more? Please call a 3M representative.



Electrical Markets Division  
3M Austin Center  
Austin TX 78753 USA

3M is a trademark of 3M Company.  
© 3M 2025. All rights reserved.