

**3M™ Perfect-It™ Hookit™ II
Foam DA Glazing Pad
05739/60-9800-3771-1**

Instructions for Use:

1. Center the DA Glazing Pad Part No. 05739 to the 3M™ Hookit™ II 6 in. Backup Pad Part No. 05276.
2. Adjust the air pressure for the DA tool between 45 and 60 PSI for maximum performance.
3. Apply 3M™ Perfect-It™ III Finishing Glaze Part No. 05941 to the painted surface.
4. Operate the DA tool at a medium speed keeping the pad flat on the surface to assure a consistent and level application of Finishing Glaze.

Note Illustrations:



5. If Glazing Pad becomes clogged, remove and install a clean pad. Rinse soiled pad in warm water (up to 115° F) and squeeze to remove excess water. Place pads face up in a clean area to dry.
6. The Finishing Glaze is to be applied with the DA foam pad and **not to be removed with the Pad**. To remove the Glaze, use a 3M™ Perfect-It™ III Detail Cloth Part No. 06016.

Covered by one or more of the following U.S. Patents: 4,962,562 (RE 35021); 5,007,128; 5,396,737.

Warranty and Limited Remedy: This product will be free from defects in material and workmanship at the time of shipment. **3M MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** User is responsible for determining whether the 3M product is fit for a particular purpose and suitable for user's application. If this product is defective, your exclusive remedy and 3M's and seller's sole obligation shall be, at 3M's option, to replace the product or refund the purchase price.

Limitation of Liability: 3M and seller will not be liable for any loss or damage arising from this 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.

3M Automotive Aftermarket Division

3M Center/Bldg. 223-6N-01

St. Paul, MN 55144-1000

1-877-666-2277 (1-877-MMM-CARS) or 651-737-6501

www.3M.com/automotive

3M, Perfect-It and Hookit are trademarks of 3M Company.

Made in U.S.A.

© 3M 2005