

# 3M™ Drive-Thru Headset G5

## Quick Start Guide



### ▶ Buttons

- Volume**  
Adjust Volume Level
- Lane 2**  
Answer Lane 2 Order Point in Dual Lane
- Paging**  
Talk to Other Headsets
- Lane 1**  
Answer Lane 1 Order Point in Dual Lane

- **Feather-touch buttons** sense finger pad for a touch versus push
- **Vibration** confirms that the button has been pressed

**NOTE:** In a Single Lane operation, use Lane 1 or Lane 2 touch zones to answer the Order Point.

### ▶ Light on Microphone Boom

- **Green (Steady) Light:** Lane 1 no car present, stand by
- **Red/Green (Steady) Light:** Lane 2 (Dual Lane) no car present, stand by
- **Blue (Flashing) Light:** Vehicle arrived, but not answered
- **Blue (Steady) Light:** Vehicle present and answered
- **Red (Steady) Light:** Talk (either lane or page)

### ▶ Headset Charging Station and Batteries

**Headset Charging Station**  
*Charge headsets without removing batteries*

**Battery**  
Four lights indicate 100% fully charged



**Contact your  
3M Representative  
Today**

1-800-328-0033  
3M.com/G5

### ▶ Battery Removal



1. Place pointer finger between Control Pod and battery; place thumb under the battery latch.

2. Using a pinching motion, pinch and gently pull battery straight out.



**Commercial Solutions**  
3M Center Bldg 220-12E-04  
St. Paul, MN 55144

Phone 1-800-328-0033  
Web 3M.com/drivethru

© 3M 2016. All rights reserved.  
3M is a trademark of 3M. Used under license in Canada.  
Printed in the USA. Please recycle. 78-8134-0685-3 August 2016