

Seam Sealer and Coating Removal

1



Pre-Cleaning

Pre-wash/clean vehicle prior to disassembly (power wash undercarriage area at repair).

2



Method A

Use Scotch-Brite™ Clean N Strip disc to remove seam sealer and coatings where accessible.

3



Method B

Use CRS Scotch-Brite™ belt to remove coatings and seam sealers in hard to reach areas.

Product List ANZ

3M™ Car Wash Soap Concentrate, 3.78 litre, PN 38377



3M™ All Purpose Cleaner and Degreaser Concentrate, 3.78 litre, PN 38350



Scotch-Brite™ Clean N Strip Disc, PN 57016 OR



Scotch-Brite™ Roloc™+ Clean N Strip TR Disc, PN 07466



3M™ Roloc™+ Holder, PN 07500



Scotch-Brite™ Durable Flex Belt, CRS



Think About Your Health

3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300



3M™ Half Facepiece Respirator, PN 07502 with appropriate cartridge



3M™ Lexa™ Protective Eyewear, PN 15200 or 3M Secure Fit SF401AF-AS



Visit www.3m.com.au/aad or www.3m.co.nz/aad for more SOPs and videos