

Ford PAPR Hood: Adjusting the Head Suspension

Always read and follow product User Instructions



1. Try the hood on to determine if suspension adjustments are needed.



2. Turn the hood upside down and adjust the suspension from this position.



3. If you need access to the adjustment straps, spin the suspension 180° so that all 3 straps are completely outside of the hood opening. Take care to not rip or damage the hood/suspension attachment.



4. Adjust the strap that goes around the back of the head.



5. Adjust the strap that goes over the top of the head.



6. When finished, spin the suspension 180° in the opposite direction in step 3. Reposition the suspension back inside of the hoodtop.



7. The sweatpad should be facing towards the visor. Where the hood is attached to the suspension should not be twisted.

Questions? Call 1-844-206-1444