

Marble Floor Care System

Description:

The 3M™ Marble Care System is designed to improve/maintain the appearance of marble floors. The products of this system are intended to be used in a spray cleaning operation using 175 rpm rotary floor equipment. The system includes three products:

1. 3M™ 5200 Stone Renew Pad

Used with 3M Marble Enhancer in spray cleaning operation to clean and increase gloss on floors with a honed or dull appearance.

2. 3M™ Brand 4000 Stone Polish Pad

Used with 3M™ Marble Enhancer in spray cleaning operation using 175 rpm rotary floor equipment. This pad is used to maintain floors with moderate to high gloss. This pad can also be used to achieve a higher appearance level after the use of 3M™ 5200 Stone Renew Pad and 3M Marble Enhancer chemical.

3. 3M™ Marble Enhancer

Used with either 3M Stone Care Pad in spray cleaning operation with 175 rpm rotary floor equipment to clean and polish interior marble floors.

Equipment:

- 3M™ Doodleduster Cloth
- 175 rpm Rotary Floor Equipment
- 3M™ Insta-Lok™ Drive Assembly
- Trigger Spray Bottles

Floor Preparation:

1. Dust mop with 3M™ Doodleduster Cloth to remove loose debris.
2. Damp mop to remove spots and spills; use of 3M™ Stone Maintainer is recommended.
3. Remove floor finish or stone treatments containing wax using 3M™ Stone Prep according to label directions.
4. Protect metal, wood and carpet surfaces adjacent to area to be polished.
5. Allow floor to dry completely before polishing.

Directions for Use:

Note: Marble is a natural substance and chemical reactivity can vary greatly. Test on an inconspicuous area before general use.

3M Marble Enhancer is a ready-to-use product; do not dilute. Refer to Material Safety Data Sheet for handling precautions.

1. Prepare floor following preparation guide.
2. Select a 2 x 3 foot area.
3. Apply product to floor with a trigger spray bottle. Apply only enough product to uniformly cover the area selected.
4. Immediately spread the product with a 175 rpm floor machine using the appropriate 3M Stone Care Pad.

Directions for Use: (Continued)

5. Buff area completely using circular motion, overlapping areas already polished.
6. Repeat Step 5 until the desired appearance is achieved.
Note: If noticeable gloss increase does not occur after three applications of product, the surface may not have been adequately prepared or completely dried before polishing.
7. Move to an adjacent area and repeat Steps 2-6.
8. As a final step, dust mop using 3M Doodleduster Cloth.

General Information:

Proper use of the 3M Marble Floor Care System will remove many scratches and produce a moderate/high shine. Repeat process as needed. Frequency will depend on wear, traffic patterns and desired appearance levels. Dust mopping with 3M Doodleduster Cloth on a daily basis will help prolong desired appearance. Use 3M Stone Maintainer for general cleaning between applications.

3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Area Code 907 Tel. 522-5200
Facsimile 907-522-1645

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-3E-04
St. Paul, MN 55144-1000
Order Entry 1-800-698-4595
Facsimile 1-800-447-0408

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Area Code 808 Tel. 422-2721
Facsimile 808-422-9557

3M CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P. O. Box 5757
London, Ontario, Canada
N6A 4T1
519-451-2500
Fax: 519-452-6262

"3M" and "Insta-Lok" are trademarks of 3M.

Important Notice:

This flyer is intended to be an introductory summary. The information provided is based upon typical conditions and is believed to be reliable; however, due to the wide variety of intervening factors, 3M does not warrant that the results will necessarily be obtained. All details concerning product specifications and terms of sale are available from 3M.