


Donning & Doffing

How to put on or 'Don' and take off or 'Doff' your 3M™ Protective Coverall

Wearing your protective coverall properly is essential to the performance and protection it can offer, starting with how you put it on and ending with how you take it off.





3M Personal Safety Division

West Europe
3M Centre, Cain Road
Bracknell, Berkshire
RG12 8HT
United Kingdom
Office: +44 (0)1344 858000
www.3M.eu/PPESafety

Please recycle. Printed in UK. 3M is a trademark of 3M Company. ©3M 2016. All rights reserved.

areas, it may be easier to ask a

dressing buddy to assist.

Important Notice

to reduce the risk of the material

attracting contaminants.

This guide is only an outline. It should not be used as the only means for selecting protective clothing. Before using any protective clothing, the wearer must read and understand the user instructions for each product. Specific country legislation must be observed. If in doubt, contact a safety professional. Selection of the most appropriate PPE will depend on the particular situation and should only be made by a competent person knowledgeable of the actual working conditions and the limitations of PPE. Final determination as to the suitability of these products for a particular situation is the employer's responsibility. This information is subject to revision at any time. Always read and follow all *User Instructions* supplied with your 3M™ Protective Coveralls in order to ensure correct operation. If you have questions contact 3M Technical Service.