



## 2-in-1 Flat Mop

Ergonomic Handle: 75-0400-2020-0

Straight Handle: 75-0400-2019-2

### Assembly and Use Instructions

Note: Always wear appropriate personal safety equipment when working with the 3M mops.

1. Attach the mop frame to the handle by depressing the two buttons and inserting the frame into the bottom of the handle.



2. Make sure the buttons snap through the two holes in the handle to secure it.



3. Apply a 3M™ Easy Scrub Microfiber Mop Pad to the bottom of the mop frame aligning the edges to the frame.



4. Fill the fluid bottle with any suitable fluid, such as 3M™ Floor Cleaning Chemical or Finish, by removing the valve cap. Re-tighten the valve cap. Attach an appropriate ready-to-use label to the fluid bottle.



5. Attach the fluid bottle to the handle by sliding the fluid bottle down through the C-Clip until it clicks into place. Make sure the tan rubber dispensing tube is sticking out of the slot and pointing outward. The mop tool is ready for use.



### Adjusting the tool height

With the mop pad on the floor and handle upright, adjust the height of the tool by turning the locking collar counter-clockwise to loosen and adjust the height to your preference. Turn the locking collar clockwise to tighten.



## Use Instructions

### Dispensing fluid onto floor

1. To dispense fluid onto the floor, squeeze the trigger. Note: It may take a few seconds for the fluid to exit the dispensing tube.
2. To stop dispensing, release the trigger.

### Trigger actuation

The unique trigger design allows for multiple hand positions for your comfort.

Side grip with thumb actuation.



Side grip with finger actuation.



Palm grip with finger actuation.



### Replacing 3M™ Hook and Loop Strips

If the 3M™ Hook and Loop Strips on the bottom of the frame become loaded with lint or become ineffective over time, new strips can be ordered and installed. Contact your distributor to order, using 3M part number 75-0400-2033-3.

To replace, remove the end clip on the frame by pushing the button on the clip and pulling the end clip out of the frame. The old strips can be slid out of the track and replaced with the new strips. To complete the replacement of strips, snap the end clip back on by aligning the edges with the tracks of the frame. Make sure the button locks in place.



Note: It may be necessary to use a floor stripper or other appropriate chemical to remove any hardened floor finish that may prevent the end clips or the 3M™ Hook and Loop Strips from coming off the frame.

### Instructions for using ergonomic handle (3M Part # 75-0400-2020-0)

The ergonomic handle has been designed to make mopping floors more comfortable for the user by minimizing user hand, wrist, and arm movement required to pivot the mop head.



Ergonomic Handle



Straight Handle



3M Commercial Solutions Division  
St. Paul, MN 55144-1000  
Phone: 1-800-364-3577  
www.3M.com/facility

Please recycle. Printed in U.S.A.  
3M and Scotch-Brite and trademarks of 3M.  
Used under license in Canada.  
© 3M 2018. All rights reserved  
34-8722-5851-1

**dZ**

**Requester:** Sarah Kyllonen  
**Creator:** deZinnia\_23647  
**File Name:** 34872258511.indd  
**Structure #:** SS-16895  
**Date:** 06/07/18

**Printed Colors – Front:**



**Printed Colors – Back:**



**Match Colors:**

Scale:  1 Inch

**This artwork has been created as requested by 3M. 3M is responsible for the artwork AS APPROVED and assumes full responsibility for its correctness.**