








Corrosion Protection (Cavity Wax)

1		<p>Pre-Cleaning Pre-wash/clean vehicle prior to disassembly (power wash undercarriage area at repair).</p>
2		<p>Shake Aerosol Agitate the aerosol can thoroughly — one minute of shaking is required to mix the components prior to use. Attach the desired accessory extension and actuator if needed to access the areas inside the panel enclosure.</p>
3		<p>Application with Standard Actuator If applying to new panels prior to installation use the standard actuator. Spray up to three (3) coats to ensure full coverage and maximise protection.</p>
4		<p>Mark Extension Wand If using the 360° accessory wand, mark the extension about one inch from the end as a reference to reduce overspray.</p>
5		<p>Insert Wand Into Panel Opening Insert the wand to the farthest point. Begin spraying as you remove the wand until the reference mark comes into view. Repeat up to three (3) times to ensure complete coverage and maximise corrosion protection.</p>
6		<p>Clean Accessory Nozzle After application, invert the can and clear material from the accessory wand and nozzle by depressing the actuator.</p>
7		<p>Remove Excess Cavity Wax Re-assemble the associated parts and wipe off any excess using a VOC compliant surface cleaner.</p>

Product List

3M™ Car Wash Soap Concentrate, 3.7L, PN 38377



3M™ All Purpose Cleaner and Degreaser Concentrate, 3.7L, PN 38350

3M™ Cavity Wax Plus Aerosol 511g, PN 08852



3M™ Cavity Wax Plus Applicator Wand Kit, PN 08851



Think About Your Health

3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300



3M™ Half Face Welding Respirator Kit, PN 6228



3M™ Secure Fit™ 200 Series Anti-fog Eyewear, Clear Frame, PN 201AF-AS



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.