

Stop Use & Recall Notice IMMEDIATE ACTION REQUIRED

3M™ DBI-SALA® Twin-Leg Nano-Lok™ *edge* and Twin-Leg Nano-Lok™ Wrap Back Self-Retracting Lifelines



Twin-Leg Nano-Lok™ *edge* and Twin-Leg Nano-Lok™ Wrap Back Models

3M Fall Protection announces an immediate **stop use and product recall** of the 3M™ DBI-SALA® Twin-Leg Nano-Lok™ *edge* and the Twin-Leg Nano-Lok™ Wrap Back Self-Retracting Lifeline. These Twin-Leg Nano-Loks are used as part of a personal fall protection system that connects two self-retracting lifelines/devices (SRLs/SRDs) directly under the dorsal D-ring of a worker's harness. The Twin-Leg Nano-Lok *edge* is intended to be anchored at foot-level, is designed for sharp and/or leading edge applications and incorporates an energy absorber. The Twin-Leg Nano-Lok Wrap Back is intended for wrapping around an anchor and incorporates a similar energy absorber. 3M has determined that in a fall and under certain conditions, the energy absorber of these devices may not properly deploy which could expose the worker to serious injury or death. There have been no reports of accidents or injuries associated with this issue, **these products must be removed from service immediately.**

To address this situation, in the interests of worker safety, 3M is launching a global **stop use** of the Twin-Leg Nano-Lok *edge* and Twin-Leg Nano-Lok Wrap Back SRL devices. 3M is recalling all these devices to be repaired or replaced as soon as a solution is identified, tested and certified. Alternatively, end-users may elect to receive cash for their returned devices as described below. This stop use/recall affects all models of the Twin-Leg Nano-Lok *edge* and Twin-Leg Wrap Back SRLs since first introduced in 2013. This stop use/recall does not affect the single-leg versions of these models. **As of the date of this notice, no 3M twin-leg SRL product is approved for use over sharp or abrasive edges.**

Users/Owners: Immediately stop using your Twin-Leg Nano-Lok *edge* and Twin-Leg Nano-Lok Wrap Back SRL and take these devices out of service. Next, go to www.NanoLokEdgeRecall.com and follow the instructions on how to return your unit. As soon as a product solution is available, 3M will either repair or replace your device and return it to you at 3M's expense. Alternatively, and only until a repair or replacement solution is available, you can return your device and elect to receive cash in the amount of \$400 USD if your device was manufactured after January 1, 2017, or \$200 USD if your device was manufactured before January 1, 2017. The manufacture year/month is printed on the back label of the device.

Distributors: Please contact our Customer Service department at +33 (0) 4 83 58 08 08 or email us at informationfallprotection@mmm.com to obtain a listing of all Twin-Leg Nano-Lok *edge* and Twin-Leg Wrap Back SRLs sold to you. If you have any of these devices in stock, please return them to 3M Fall Protection for credit at 3M's expense. **Please immediately forward this Notice to any of your customers/users who have purchased Twin-Leg Nano-Lok *edge* and Twin-Leg Nano-Lok Wrap Back SRLs from you with an urgent request that they read and comply with this Notice.**

Please contact 3M Customer Service for assistance, additional recall information, or alternative solutions at +33 (0) 4 83 58 08 08 or informationfallprotection@mmm.com.

We sincerely apologize for any inconvenience that this situation may cause to you or your customers.

July 31st, 2019

List of affected Part Numbers for EMEA:

CE web	CE cable	ANSI
3101440	3500239	3500225
3101441	3500240	3500227
3101442	3500241	3500228
3101443	3500242	3500231
3101444		3500257
3101445		
3101446		
3101447		
3101448		