

Helping You Wear it Right

Wearing your elastomeric 3M™ Full Facepiece
Reusable Respirator 7800 Series



Always read and follow User Instructions.

1



Fully loosen all six head straps. Pull hair back with one hand. Bring facepiece up to face with other hand.

2



While holding the facepiece in place, pull the straps over your head.

3



Tighten the two bottom straps.

4



Tighten the two middle straps, then the two top straps. Make sure the back of the harness is centered on the back of the head.

Perform a User Seal Check

Before assigning any respirator to be worn in a contaminated area, a qualitative or quantitative fit test must be performed per U.S. OSHA standard 29CFR 1910.134 or local requirements.

Positive Pressure User Seal Check



Place the palm of your hand over the exhalation valve cover and *exhale* gently. The facepiece should bulge slightly. If air leaks between the face and the facepiece of the respirator, reposition it and adjust the straps for a tighter seal. If you cannot achieve a proper seal, **do not** enter the contaminated area. See your supervisor.

Negative Pressure User Seal Check



Using Particulate Filters

Place your thumbs over the center of the particulate filters and *inhale* gently. The facepiece should collapse slightly. If air leaks between the face and the facepiece of the respirator, reposition it and adjust the straps for a tighter seal. If you cannot achieve a proper seal, **do not** enter the contaminated area. See your supervisor.



Using Cartridges

Place the palms of your hands over the cartridges and *inhale* gently. The facepiece should collapse slightly. If air leaks between the face and the facepiece of the respirator, reposition it and adjust the straps for a tighter seal. If you cannot achieve a proper seal, **do not** enter the contaminated area. See your supervisor.



⚠ WARNING

These respirators help protect against certain airborne contaminants. Before use, the wearer must read and understand the User Instructions provided as a part of the product packaging. A written respiratory protection program must be implemented meeting all the requirements of OSHA 1910.134 including training, fit testing and medical evaluation. In Canada, CSA standards Z94.4 requirements must be met and/or requirements of the applicable jurisdiction, as appropriate. **Improper use may result in sickness or death.** For correct use, see supervisor and User Instructions, or call 3M PSD Technical Service in USA at 1-800-243-4630 and in Canada at 1-800-267-4414.