Product Data Sheet

3M™ Dyneon™

Commercial Product

Fluoroelastomer FPO 3632 Medium Fluorine Peroxide Curable

Product Description

Dyneon Fluoroelastomer FPO 3632 is a medium fluorine content peroxide curable grade, which provides excellent physical properties, very good chemical resistance and improved bonding to silicones. The material is recommended for extrusion and moulding processes.

Special Features

- Composition: terpolymer of vinylidene fluoride, hexafluoropropylene and tetrafluoroethylene plus cure site monomer
- Process target: moulding and extrusion
- Excellent flow and scorch safety

- Improved bonding to silicones
- Excellent physical properties
- Good low temperature properties
- · High resistance against chemical fluids

Typical Applications

Dyneon Fluoroelastomer FPO 3632 has been designed for hoses as well as for moulded goods. It can be used for manufacturing of multi-layer turbo charger hoses due to its improved bonding to silicones.

Typical Polymer Properties

Property	Test method	Unit	Value
Colour			Off-white
Fluorine Content	QCM 50.18.3C	%	67.3
Mooney Viscosity (raw gum) ML 1 + 10 @ 121 °C	QCM 2.14.4C	Mooney unit	37
Solubility			Ketones and Esters
Specific Gravity	QCM 14.10		1.81
Tg		°C	- 19

Storage and Handling

Store and use all Dyneon Fluoroelastomers only in well-ventilated areas under cool and dry conditions. The shelf life of FPO 3632 is 2 years from date of manufacturing (in case of unopened bags). Opening the bags reduces the shelf life to 6 months; usage of the material as soon as possible is preferable. It is highly recommended to reseal the bags of both the gum and the compounds produced thereof when not used right away.

Inappropriate storage of gum and compound can affect the bonding characteristics.

Delivery Form

Dyneon Fluoroelastomer FPO 3632 is delivered in slab form.

Packaging sizes are:

- 25 kg cardboard box comprised of 2 PE / Aluminium / Epoxy bags, containing 12.5 kg of product each
- 600 kg returnable bulk shipping container systems comprised of 48 PE / Aluminium / Epoxy bags, containing 12.5 kg of product each

Processing Recommendations

Dyneon Fluoroelastomer FPO 3632 can be compounded using standard water-cooled internal mixers or two-roll mills with standard fillers and ingredients utilized in typical fluoroelastomer formulations. The "dry" ingredients should be blended before adding to the masticated gum. For best results, FPO 3632 should be banded on the mill several minutes prior to adding the blended dry ingredients. Once mixed, the compounded stocks have good scorch resistance.



3M[™] Dyneon[™] Fluoroelastomer FPO 3632 Medium Fluorine Peroxide Curable

Commercial Product

Typical Properties

Compound	Amount (in Parts/100)
FPO 3632	100
Carbon Black MT N-990	30
TAIC (70 %)	3.5
Trigonox 101-50D	3
ZnO	3

Typical Rheological Properties

Alpha Technologies Moving Die Rheometer (MDR 2000), 100 cpm, 0.5° Arc, (QCM 2.19.1) Test Condition, 6' @ 177 °C

Property	Unit	Value	
ML, Minimum Torque	dNm	1.0	
MH, Maximum Torque	dNm	24.2	
ts2	Minutes	0.6	
t'50, Time to 50 % cure	Minutes	0.8	
t'90, Time to 90 % cure	Minutes	2.2	

Typical Physical Properties

Press Cured 15' @ 177 °C Post Cured 4 hours @ 200 °C

Property	Unit	Value				
Physical Properties DIN 53504 (S	2 DIE)					
100 % Modulus	MPa	6.6				
Tensile	MPa	19.4				
Elongation at break	%	176				
Hardness (ASTM D2240)	Shore A	73				
Compression Set on buttons ASTM D395 method B						
70 hours @ 200 °C	%	26				
Compression Set on 2 mm disks; 50% deformation VDA 675218						
22 hours @ 150 °C	%	48				
Lower Temperature Property						
TR10 (ASTM D1329)	°C	- 16				



Product Data Sheet

Commercial Product

3M[™] Dyneon[™] Fluoroelastomer FPO 3632 Medium Fluorine Peroxide Curable

Safety Instructions

Follow the normal precautions observed with all fluoropolymer materials.

Please consult the Material Safety Data Sheet and Product Label for information regarding the safe handling of the material. By following all precautions and safety measures, processing these products poses no known health risks. General handling/processing precautions include: 1) Process only in well-ventilated areas. 2) Do not smoke in areas contaminated with powder/residue from these products. 3) Avoid eye contact. 4) If skin comes into contact with these products during handling, wash with soap and water afterwards. 5) Avoid contact with hot fluoropolymer.

Potential hazards, including release of toxic vapours, can arise if processing occurs under excessively high temperature conditions. Vapour extractor units should be installed above processing equipment. When cleaning processing equipment, do not burn off any of this product with a naked flame or in a furnace.

Important Notice

All information set forth herein is based on our present state of knowledge and is intended to provide general notes regarding products and their uses. It should not therefore be construed as a guarantee of specific properties of the products described or their suitability for a particular application. Because conditions of product use are outside Dyneon's control and vary widely, user must evaluate and determine whether a Dyneon product will be suitable for user's intended application before using it.

The quality of our products is warranted under our General Terms and Conditions of Sale as now are or hereafter may be in force.

Technical information, test data, and advice provided by Dyneon personnel are based on information and tests we believe are reliable and are intended for persons with knowledge and technical skills sufficient to analyze test types and conditions, and to handle and use raw polymers and related compounding ingredients.

No license under any Dyneon or third party intellectual rights is granted or implied by virtue of this information.

General recommendations on health and safety in processing, on work hygiene and on measures to be taken in the event of accident are detailed in our material safety data sheets.

You will find further notes on the safe handling of fluoropolymers in the brochure "Guide for the safe handling of Fluoropolymers Resins" (download link) by PlasticsEurope, Box 3, B-1160 Brussels, Tel. +32 (2) 676 17 32.

You can also download it with your smartphone using the QR code below.



Customer Service

Europe

Phone: 00 800 396 366 27 Fax: 00 800 396 366 39

Italy

Phone: 800 7 910 18 Fax: 800 7 810 19

USA

Phone: +1 800 810 8499 Fax: +1 800 635 8061 Technical Service Fluoroplastics

Dyneon GmbH

3M Advanced Materials Division Industrieparkstraße 1 84508 Burgkirchen

Germany

Phone: +49 8679 7 4709 Fax: +49 8679 7 5037 Technical Service Fluoroelastomers & Polymer Processing Additives

3M Belgium BVBA / SPRL 3M Advanced Materials Division Canadastraat 11, Haven 1005 2070 Zwiindrecht

Belgium Phone: +32 3 250 7868 Fax: +32 3 250 7905 Technical Service PTFE Compounds

Dyneon B.V.

3M Advanced Materials Division Tunnelweg 95 6468 EJ Kerkrade

The Netherlands
Phone: +31 45 567 9600
Fax: +31 45 567 9619

We will gladly supply further contact details for our full network of global sales offices. Alternatively, find them here.



Web Site: www.dyneon.eu

Printed in Germany © Dyneon 2014 Status: Mar. 2014 3M, Dyneon and Dynamar are Trademarks of 3M Company.

All Rights reserved. The present edition replaces all previous versions. Its content is being continuously adjusted to reflect the current level of knowledge. Please make sure and inquire if in doubt whether you have the latest edition.