

3M[™] Vapour Permeable Air Barrier 3015VP Installation Guidelines

Introduction	3M [™] Vapour Permeable Air Barrier 3015VP with high performance 3M [™] Acrylic Adhesive, adheres on contact to most exterior sheathing, concrete, masonry, wood and more. For installation and flexibility, it can be applied without priming, torching or asphalt mess.
	Can be applied in temperature as low as -18°C to 66°C (0°F to 150°F) helping to extend the building season. 3M [™] Vapour Permeable Air Barrier 3015VP resists UV exposure for up to twelve months.
Installation Best Practices	Substrate Information and Surface Preparation
	3M [™] Vapour Permeable Air Barrier 3015VP can be applied to a wide variety of sheathing substrates, typically without priming. Substrate condition is crucial to the adhesion performance of any adhesive membrane. Substrate surfaces must be free of grease, oil, un-bonded paint, corrosion or other substrates that would adversely affect the adhesive bond between the membrane and substrate. For optimum performance, substrate surface must be dry to the touch with the ambient temperature above -18°C to 66°C (0°F to 150°F). Additionally, consider the following for success with specific surfaces:
	 Exterior gypsum sheathing shall have moisture content below 19% with no open joints or cracks wider than 1.27 cm (½ inch).
	 Plywood substrates shall have moisture content below 16% with no open joints or cracks wider than 1.27 cm (½ inch).
	 Concrete substrates shall have fins ground flush and void areas filled. Masonry substrates must have mortar joints struck flush.
	 Fill gaps and cracks exceeding 6.35 mm (¼ inch) width with 3M[™] Polyurethane Sealant 540 (or similar), and tool the surface flush and smooth.
	 Fill gaps exceeding 1.27 cm (½ inch) width with closed cell foam backer rod seal with 3M[™] Polyurethane Sealant 540 (or similar), and tool the surface flush and smooth.


Application

Techniques

Wall Application

3M[™] Vapour Permeable Air Barrier 3015VP is wound with the adhesive on the outside surface of the roll to accommodate easy installation. After removing the roll from the box, remove the plastic wrap on the roll to expose the adhesive. Align the roll on the wall and ensure the leading edge is tacked to the wall. Unwind the roll along the wall in a continuous motion to install the membrane.

After the strip of membrane is applied to the wall, roll with a rubber roller to ensure a tight, secure bond. Remove the clear poly liner from the white **backing** before installing the next strip.



Remove the protective film covering the red 3M logo protection barrier.

While the membrane may be applied horizontally or vertically, horizontal installation is preferred. Best practice includes a "weatherboard" or "shingle fashion," starting with the first strip of membrane across the bottom of the wall. Moving up the wall, placing the next strip higher and overlapping the previous strip by 5.08 cm (2 inches).

3M[™] Vapour Permeable Air Barrier 3015VP Installation Guidelines

Penetration Window and door penetrations can be detailed pre or post-installation of the Areas membrane. Pre-installation, however, is recommended. All penetrations, including windows and doors, must be installed in proper sequence for appropriate moisture management. 3M recommends using either 3M[™] Air Barrier and Vapour Barrier 3015, 3M[™] Through Wall Flashing 3015TWF or 3M[™] All Weather Flashing Tape 8067 for flashing and detail work. Penetrations should be additionally sealed with 3M[™] Polyurethane Sealant 540 (or similar) to achieve a weather-tight result.

Vertical seams should be staggered from floor to floor, or separated by a horizontally applied strip of 3M[™] Vapour Permeable Air Barrier 3015VP.

For best air barrier membrane performance, roll the membrane with a rubber roller to ensure a tight seal against the wall and between overlapped edges. Best practice methods recommend sealing the leading edge of the membrane at the end of each work day. 3M recommends the use of 3M[™] Polyurethane Sealant 540 (or similar) to seal any exposed leading edge. Smooth the bead to the surface to avoid creating areas where water may collect.

Technical Information	The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.
Product Use	Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.
Warranty, Limited Remedy, and Disclaimer	Unless an additional warranty is specifically stated on the applicable 3M product packaging or product literature, 3M warrants that each 3M product meets the applicable 3M product specification at the time 3M ships the product. 3M MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY OR CONDITION ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE. If the 3M product does not conform to this warranty, then the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.
Limitation of Liability	Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted, including warranty, contract, negligence or strict liability.

3M

Industrial Adhesives and Tapes Division 3M Canada P.O. Box 5757 London, Ontario N6A 4T1

3M and 3M Science. Applied to Life. are trademarks of 3M. Used under license in Canada. © 2020, 3M. All rights reserved. 2002-16644 E