



S15i Multimedia Projector

Product Safety Guide

S15i Projecteur multimedia - Guide de Sécurité de Produit

S15i Multimedia-Projektor - Sicherheitsanleitung des Geräts

S15i Proyector de Multimedia - Guía de Seguridad del Producto

S15i Proiettore Multimediale - Guida di Sicurezza del Prodotto

S15i Multimedia Projector - Veiligheidsgids op Product

S15i Projector dos Multimedia - Guia da Segurança de Produto

S15i Multimedia-Projector- Bruksanvisning för Produktsäkerhets

S15i 多媒体投影机 - 产品安全指南

S15i 멀티미디어 프로젝터 - 제품 안전 가이드

S15i Multimediaprojektori - Laitteen turvaohjeet




Table of Contents

ENGLISH

Safety Information	5
Product Safety Labels	9
Lamp	10
Warranty	13

ENGLISH

Safety Information

Read, understand, and follow all safety information contained in the “Product Safety Guide” and in the “Operator’s Guide” prior to using the S15i Multimedia Projector. Service personnel must also read and understand the safety information contained in the “Service Manual”. Retain these instructions for future reference.

Intended Use

The 3M™ Multimedia Projector S15i was designed, built and tested for use indoors, using 3M brand lamps, 3M brand ceiling mount hardware and nominal local voltages. This projector is not intended for household use or use by children. The use of other replacement lamps, outdoor operation or different voltages has not been tested and could damage the projector or peripheral equipment and/or create a potentially unsafe operating condition.

Explanation of Signal Words and Symbols in Safety Labels and Instructions

WARNING: Indicates a potentially hazardous situation, which if not avoided, could result in death or serious injury.

CAUTION: Indicates a potentially hazardous situation, which if not avoided, may result in minor or moderate injury.



Warning: Hazardous Voltage



Warning: Hazardous High Temperature



Warning: High Pressure



Attention: Refer to Safety Instructions in Guides

 **WARNING**

- **To reduce the risk associated with choking:**
 - Keep the battery and battery holder away from children and pets.
- **To reduce the risk associated with exposure to hazardous voltage:**
 - Disconnect power cord when the projector is not in use, during lamp replacement, and while cleaning.
 - Do not remove any screws other than those specified in the lamp replacement instructions.
 - Do not store or operate this projector in wet environments.
 - **Do not modify this projector.**
 - Do not attempt to service the projector - there are no user serviceable parts, other than the lamp cartridge, inside the projector. Contact a 3M authorized service provider for service.
 - Do not allow water or other liquids to enter the projector.
- **To reduce the risk associated with environmental contamination due to mercury:**
 - Dispose of lamp cartridge in accordance with applicable federal, state and local regulations.
- **To reduce the risk associated with exposure to hazardous voltage and/or fire:**
 - Replace power cord if damaged.
 - Contact a 3M authorized service provider if the projector becomes damaged.
 - Use a grounded extension cord with a rating at least equal to that of the projector.
 - Connect this projector to a grounded outlet.
- **To reduce the risk associated with hazardous voltage, impact, tripping, and intense visible light:**
 - Do not use this projector around unsupervised children.
- **To reduce the risk associated with hot surface of lamp cartridge:**
 - Unplug the projector from the electrical outlet and allow the lamp to cool for 45 minutes before replacing the lamp.
- **To reduce the risk associated with a ruptured lamp:**
 - Always handle the fragile lamp module with care.
 - Remove the projector from the ceiling or wall mount before replacing the lamp.
 - Use care when replacing the lamp module in the event of a lamp rupture - small glass particles and small amounts of mercury may be present.
 - Ventilate the area where the lamp rupture occurred.
 - Wear safety goggles and gloves when cleaning up ruptured lamp debris.
 - Carefully collect the ruptured lamp debris in a closed container and dispose of the container and the expired lamp module in accordance with federal, state, and local regulations.
 - Wash your hands thoroughly after handling ruptured lamp debris.
 - Replace the lamp module when the lamp replacement message appears.
 - Never replace the lamp module with a previously used lamp module.


CAUTION


- **To reduce the risk associated with explosion, and/or chemicals from a leaking battery:**
 - Use only with battery type AA or equivalent.
 - Orient the battery's plus (+) and minus (-) terminals of the batteries according to the markings found on the remote control.
 - Do not leave the battery in the remote for an extended period of time.
 - Do not heat, disassemble, short, recharge, or expose to fire or high temperature.
 - Do not carry batteries loose in your pocket or purse.
 - Avoid eye and skin contact in the event that battery would leak.
 - Do not mix used and new batteries.
- **To reduce the risk associated with the impact of a falling projector:**
 - Use only the 3M™ brand wall/ceiling mounting hardware kit if wall or ceiling mounting is desired.
 - Installation of the 3M™ wall/ceiling kit must only be performed by qualified personnel.
 - Adhere strictly to the proper installation procedure as outlined in the installation instructions when installing the 3M™ wall/ceiling kit.
 - Always operate the unit on a flat, sturdy, and horizontal surface.
- **To reduce the risk associated with intense visible light:**
 - Avoid looking directly into the projector lens while the lamp is on.
- **To reduce the risk associated with tripping and/or impact:**
 - Position the power cord and data cable so that they cannot be tripped over.








Important Note

1. Always open the lens shutter or remove lens cap when the projection lamp is on.
2. To avoid premature lamp failure, do not change the mounting position of the projector (desktop ceiling mount or ceiling desktop mount) and continue to use the same lamp.
3. To avoid reduced lamp life, do not touch projection lamp with bare fingers.
4. To avoid reduced image quality, do not touch projection lens or other internal optical components.
5. Do not use detergents, chemicals, or any spray liquids for cleaning this unit, other than those referred to in the "Operators Guide".
6. For maximum lamp life, do not strike or drop, improperly handle, or scratch the lamp glass. Also, do not install an old or used lamp.
7. Keep air filter clean. Refer to the cleaning instructions contained in the "Operator's Guide".
8. Keep all ventilation openings free of any obstructions.
9. In some countries, the line voltage is NOT stable. This projector is designed to operate safely within a bandwidth of 100 to 120 volts / 220 to 240 volts (50 to 60 Hz) $\pm 10\%$, but could fail if power drops or surges of ± 10 volts occur. In these high-risk areas, it is recommended to install a power stabilizer unit.
10. Do not block intake or exhaust air vents. This will cause the projector to over heat and shut down.
11. Do not place the projector in direct sunlight or near a hot object such as a heater.
12. To prevent damaging the projector, always hold the projector whenever using the elevator buttons to adjust the elevator feet.
13. Use the accessory cable or a designated-type cable for the connection. Some cables have to be used with core set. A too long cable may cause certain picture degradation. Please consult with your dealer for details. For cables that have a core only at one end, connect the core to the projector.
14. Make sure that you connect devices to the correct port. Incorrect connection may result in malfunction and/or damage to the device and/or projector.
15. Do not place the projector in the side/front/rear-up position, except care of the air filter.

Product Safety Labels



 HIGH TEMPERATURE / HAUTE TEMPERATURE / HOCHTEMPERATUR / ALTA TEMPERATURA / ALTA TEMPERATURA **3M**

						
---	--	---	---	---	---	---

- When replacing lamp, turn off and unplug unit, wait 45 minutes to let lamp cool. High-pressure lamp when hot, may explode if improperly handled.
- Pour changer la lampe, éteindre et débrancher la machine. Attendre 45 minutes de manière à laissez refroidir la lampe. La lampe haute pression risque d'exploser si elle est manipulée sans précaution lorsqu'elle est encore chaude.
- Vor Austausch der Lampe, das Gerät abschalten und den Stecker herausziehen; 45 Minuten warten, um die Lampe abkühlen zu lassen. Falls die heiße Hochdrucklampe falsch gehandhabt wird, kann sie explodieren.
- Prima di sostituire la lampadina, spegnere il proiettore, scollegarne la presa di alimentazione ed attendere 45 minuti circa che la lampadina si raffreddi. Se calda, essa è sottoposta ad alta pressione interna e può esplodere.
- Cuando tenga que reemplazar la lámpara, desconecte la alimentación y desenchufe la unidad, y espere 45 minutos para dejar que se enfríe la lámpara. La lámpara, que está a alta presión cuando está caliente, puede explotar si se manipula indebidamente.

Lamp

Lamp Operation:

The following symptoms may indicate a lamp in need of replacement:

- LAMP indicator lights up red.

WARNING

- **To reduce the risk associated with environmental contamination due to mercury in the projection lamp:**
 - Dispose of lamp cartridge in accordance with applicable federal, state and local regulations.
 - The lamp in this product contains mercury. Dispose of projection lamp in a manner that is consistent with your local hazardous waste regulations for mercury.
 - For recycling and disposal information, contact your respective governmental agencies.
In U.S., contact the Electronic Industries Alliance at www.lamprecycle.org
In Canada, contact the Electronic Product Stewardship Canada at www.epsc.ca

Display Lamp Operation Hours

To determine the lamp operation hours, follow these steps:

1. While the projector is running, press the MENU button on the remote control. Choose the "OPTION" using the ▼ button, and press the ► button or the ENTER button. Choose the "LAMP TIME" using the ▼ button.
2. The operating time of the lamp will be displayed.
The lamp time is the time counted after the last resetting.

√ Note

Please reset the lamp time only when you have replaced the lamp, for a suitable indication about the lamp.

Reset Lamp Hours

- (1) Press the MENU button to display a menu. Only when the EASY MENU has appeared, please perform the next step (2).
- (2) Point at the "Go To Advance Menu ..." in the menu using ▼/▲ button, then press the ► button.
- (3) Point at the "OPTION" in the left column of the menu using ▼/▲ button, then press the ► button.
- (4) Point at the "LAMP TIME" using ▼/▲ button, then press the ► button. A dialog will appear.
- (5) Press the ▲ button to select "RESET" on the dialog. It performs resetting the lamp time.

Replacing Lamp

The glass lamp used in this projector contains small amounts of mercury and operates at high pressure and at high temperature and may unexpectedly shatter. Each lamp has a different lifetime and can fail in different ways, including a rupture with a loud bang or simply burn out. In the event of a lamp rupture, be sure to follow the instructions.

WARNING

- **To reduce the risk associated with exposure to hazardous voltage:**
 - Disconnect power cord when the projector is not in use, during lamp replacement, and while cleaning.
 - Do not remove any screws other than those specified in the lamp replacement instructions.
 - Do not attempt to service the projector - there are no user serviceable parts, other than the lamp cartridge, inside the projector. Contact a 3M authorized service provider for service.
- **To reduce the risk associated with hot surface of lamp cartridge:**
 - Unplug the projector from the electrical outlet and allow the lamp to cool for 45 minutes before replacing the lamp.
- **To reduce the risk associated with a ruptured lamp:**
 - Always handle the fragile lamp module with care.
 - Remove the projector from the ceiling or wall mount before replacing the lamp. In the case of a lamp rupture, small glass particles could fall out when the lamp door is opened or the projector is tilted.
 - Use care when replacing the lamp module in the event of a lamp rupture - small glass particles and small amounts of mercury may be present.
 - Ventilate the area where the lamp rupture occurred.
 - Wear safety goggles and gloves when cleaning up ruptured lamp debris.
 - Carefully collect the ruptured lamp debris in a closed container and dispose of the container and the expired lamp module in accordance with federal, state, and local regulations.
 - Wash your hands thoroughly after handling ruptured lamp debris.
 - Replace the lamp module when the lamp replacement message appears.
 - Never replace the lamp module with a previously used lamp module.
- **To reduce the risk associated with environmental contamination due to mercury:**
 - Dispose of lamp cartridge in accordance with applicable federal, state and local regulations.

CAUTION

- **To reduce the risk associated with explosion, and/or chemicals from a leaking battery:**
 - Use only with battery type AA or equivalent.
 - Orient the battery's plus (+) and minus (-) terminals of the batteries according to the markings found on the remote control.
 - Do not leave the battery in the remote for an extended period of time.
 - Do not heat, disassemble, short, recharge, or expose to fire or high temperature.
 - Do not carry batteries loose in your pocket or purse.
 - Avoid eye and skin contact in the event that battery would leak.
 - Do not mix used and new batteries.
- **To reduce the risk associated with intense visible light:**
 - Avoid looking directly into the projector lens while the lamp is on.

Important Note:

If the lamp breaks soon after the first time it is used, it is possible that there are electrical problems elsewhere besides the lamp. If this happens, contact your local dealer or a service representative.

√ **Note**

For maximum lamp life, do not strike or drop, improperly handle, or scratch the lamp glass. Also, do not install an old or previously used lamp.

1. **Remove lamp access door:** Please loosen the screw (marked by arrow) (1). Then, unhook the claws of the lamp door (2), and remove the lamp door (3).
2. **Retaining screws:** Use a screwdriver to unscrew the lamp module retaining screws. (4)


√ **Note**

All lamp module screws must be loosened. These screws are self-containing screws that cannot be removed from the lamp module or access door.

3. **Remove lamp module:** Slowly pick up the lamp module by the handles. (5)
4. **Insert lamp module:** Carefully insert (5) the new lamp module. Ensure that it is fully seated. Tighten the lamp module retaining screws (4) to secure the lamp module in place.
Optional Lamp: 78-6969-9812-5 (Contact 3M customer Service.)
Insert the hinge tabs on the bottom of the lamp access door (6), then push the center point of two claws (7) to fix the lamp door.

√ **Note**

Reset the lamp operation hours. See “Reset Lamp Hours” for details.



Warranty

LIMITED WARRANTY

This product will be free from defects in material and manufacture for a period of three (3) years from the date of purchase, subject to the following limitations. The following are exclusions to the above listed warranty or are subject to a different warranty as set forth below:

(a) The warranty for lamps that are included as original equipment in the projectors is for parts only and is effective for a period of 90 days after the date of purchase of the projector or 180 hours of lamp usage, whichever occurs first.

(b) The warranty period for LCD panels (including polarizers) is either 3 years from the date of purchase of the projector or 2500 hours of projector usage, whichever occurs first. If within 3 years from the date of purchase of the projector, the LCD panel requires replacement and is otherwise eligible for warranty coverage, but the projector has exceeded 2500 hours of usage, the 3M warranty will cover the cost of labor, but not the cost of parts that require replacement.

(c) 3M Digital Projectors are designed to operate in a typical indoor environment. Product Warranty is void if used outside of the following circumstances:

- 100V –240V AC, 50/60 Hz
- 16 °to 29 °C (60 °to 85 °F)
- 10 –80%RH (without condensation)
- 0 –1828m (0 –6000 feet) above sea level
- The ambient operating environment should be free of airborne smoke, grease, oil and other contaminants that can effect the operation or performance of the projector.

(d) The warranty will be void if you repair or modify the 3M Digital Projector or you otherwise damaged the product due to misuse, neglect, mishandling or other abuse.

LIMITATION OF LIABILITY

THE FOREGOING WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, AND 3M SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY AND FITNESS. 3M SHALL NOT BE LIABLE FOR ANY DAMAGES, DIRECT, CONSEQUENTIAL, OR INCIDENTAL, ARISING OUT OF THE USE OR INABILITY TO USE THIS PRODUCT.

Important: The above warranty shall be void if the customer fails to operate product in accordance with 3M's written instructions. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

FCC STATEMENT - CLASS B: This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual may cause interference to radio communications. It has been tested and found to comply with the limits for a Class "B" computing device pursuant to Subpart B of Part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference when operated in a residential installation.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- * Reorient or relocate the receiving antenna.
- * Increase the separation between the equipment and receiver.
- * Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- * Consult the dealer or an experienced radio/TV technician for help.

INSTRUCTIONS TO USERS: This equipment complies with the requirements of FCC equipment provided that the following conditions are met. The cables may have to be used with the core set to the projector side. Use the cables which are included with the projector or specified.

Note: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

EEC STATEMENT: This machine was tested against the 89/336/EEC (European Economic Community) for EMC (Electro Magnetic Compatibility) and fulfills these requirements.

Video Signal Cables: Double shielded coaxial cables (FCC shield cable) must be used and the outer shield must be connected to the ground. If normal coaxial cables are used, the cable must be enclosed in metal pipes or in a similar way to reduce the interference noise radiation.

Video Inputs: The input signal amplitude must not exceed the specified level.


PATENTS, TRADEMARKS & COPY RIGHTS

IBM is a registered trademark of International Business Machines Corporation. Apple Macintosh and Apple Powerbook are registered trademarks of Apple Computer, Inc. Microsoft and Windows 95 & Windows 98 are registered trademarks, and Windows and Windows for Workgroups are trademarks of the Microsoft Corporation. Toshiba is a registered trademark of Toshiba Corporation. Kensington is a trademark of Kensington Corporation. All other products are trademarks or registered trademarks of their respective companies.

Important Notice

All statements, technical information, and recommendations related to 3M's products are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use. Any statements related to the product which are not contained in 3M's current publications, or any contrary statements contained on your purchase order shall have no force or effect unless expressly agreed upon, in writing, by an authorized officer of 3M."

Let us help you make the most of your next presentation. We offer everything from presentation supplies to tips for better meetings. And we're the only transparency manufacturer that offers a recycling program for your used transparencies. For late-breaking news, handy reference and free product samples, call us toll-free in the continental United States and Canada, 24 hours a day, or visit our Internet Website.



**<http://www.3m.com/meetings>
e-mail: meetings@mmm.com**

3M Austin Center
Building A145-5N-01
6801 River Place Blvd.
Austin, TX 78726-9000

3M Canada
P.O. Box 5757
London, Ontario
N6A 4T1

3M Mexico, S.A. de C.V.
Apartado Postal 14-139
Mexico, D.F. 07000
Mexico

3M Europe
Boulevard de l'Oise
95006 Cergy Pontoise Cedex
France

Litho in **China**
© 3M 2006
78-6970-9451-0 Rev. A

QR67491