

# 3M™ Multi-gas Cartridge Filter 6099 A2B2E2K2HgFormP3

## Technical Data Sheet

### Description

3M™ Organic Vapour Filter 6099 is one of the 3M™ 6000 series gas/vapour cartridges. The 6099 filters are used in combination with 3M™ Full Face respirators only.

### Features

- 3M high performance activated carbon for effective filtration
- 3M™ Bayonet Connection System ensures precise and secure locking
- Low profile and well balanced twin filter design
- Suitable for use with 3M™ Full Face Respirators 6000/7000 Series

### Specifications

- Filter Rating: A2B2E2K2HgFormP3
- Provides protection against organic vapours (boiling point > 65°C)\*, inorganic & acid gases, ammonia and methylamine, mercury vapour and formaldehyde.
- Not to be used when spraying isocyanate based paints
- Also provides protection against dusts, mists and fumes – all particulates.
- Weight: 235g per pair of filters

### Hazards/Tasks

- For protection when working with a variety of chemicals such as organic vapours (boiling point > 65°C), chlorine, hydrogen chloride, sulphur dioxide, hydrogen fluoride, hydrogen sulphide, ammonia, methylamine, mercury vapour and formaldehyde.

### Materials

The following materials are used in this product:

- Filter Body - Polystyrene
- Gas/Vapour Filter element - Activated Carbon
- Particulate Filter Element - Fibreglass

\* Not to be used when spraying isocyanate based paints



### Standards

- Complies with AS/NZS 1716:2012 (Respiratory protective devices).
- Use in accordance with AS/NZS 1715 (Selection, use and maintenance of respiratory protective equipment).

### Fitting Instructions

Only new, unused filters from their original packaging should be fitted to your facepiece. Ensure that both filters are of the same type and class.

- A. Align 6099 filter notch with facepiece 3M logo and push together.
- B. Turn filter 1/4 turn clockwise to stop. Discard and replace both filters at the same time.
- C. To remove filter, turn 1/4 turn anticlockwise

### Disposal

Dispose in accordance with local and national regulations appropriate to the contaminants captured.

Low boiling point organic compounds are capable of migrating through 3M 6099 filters when not in use.

### Technical Specifications

When selected and used in accordance with the standard (AS/NZS 1715) and for the contaminants specified, this filter is capable of providing the following protection:

- With a 3M 6000/7800 Series Full Face Respirator: for concentrations of organic vapours (boiling point >65°C), inorganic & acid gases, ammonia and methylamine, formaldehyde and mercury vapour at levels up to 100 x the relevant Workplace Exposure Standard or 5000 ppm whichever is lower, and exposures less than the relevant IDLH (Immediately Dangerous to Life and Health) value for particles up to 100 x WES

## Warning and Limitations

Particular attention should be given to warning statements where indicated. Proper selection, fit, training, use and appropriate maintenance are essential in order for the product to help protect the wearer from certain airborne contaminants.

Failure to follow all instructions on the use of these respiratory protection products and/or failure to properly wear the complete product during all periods of exposure may adversely affect the wearer's health, lead to severe or life threatening illness or permanent disability.

Always be sure that the complete product is:

- Suitable for the application;
- Fit tested and fitted correctly;
- Worn during all periods of exposure;
- Replaced when necessary.

For suitability and proper use follow local regulations, refer to all information supplied or contact an occupational hygienist, safety professional or 3M representative on the Tech Assist Helpline - Australia 1800 024 464 or New Zealand 0800 364 357.

Use this respirator system strictly in accordance with all User Instructions:

- Do not submerge the filters in liquid.
- Do not use in atmospheres containing less than 19.5% oxygen. (3M definition. Individual countries may apply their own limits on oxygen deficiency. Seek advice if in doubt).
- Do not use these products in pure oxygen or oxygen enriched atmospheres.
- Do not use for respiratory protection against atmospheric contaminants and concentrations which have poor warning properties or are unknown or immediately dangerous to life and health (IDLH) or against contaminants/concentrations which generate high heats of reaction with chemical filters.
- Do not use in airborne concentrations above those specified in **Technical Specifications**.
- Leave the contaminated area immediately if:
  - o Any part of the system becomes damaged.
  - o Airflow to the face piece decreases or stops.
  - o Breathing becomes difficult or increased breathing resistance occurs.
  - o Dizziness or other distress occurs.
  - o You smell or taste contaminants or irritation occurs.
- Never alter, modify or repair this device.
- These products do not contain components made from natural rubber latex.

**NOTE:** Save all user instructions for continuing reference.

## Shelf Life, Storage and Transportation

Shelf life of the unopened product is five (5) years from date of manufacture when stored in temperature range -20°C to +25°C and at less than 80% relative humidity. Average storage conditions may exceed 25°C/80%RH for limited periods. They can reach 38°C/85%RH provided this is for no more than 3 months of the shelf life of the product.

End of shelf life date is marked on the product packaging. Before initial use, always check that the product is within the stated shelf life. When storing or transporting this product use original packaging provided.

Storing the filters in an airtight container will help prolong the service life by reducing exposure to moisture and contaminants.

As per AS/NZS1715:2009 Section 4.2.5.3, "All classes of gas filter shall be discarded no longer than six months after opening, irrespective of the number of periods of use".

## Additional Information

### 3M™ Organic Vapour Monitor 3500 and 3520

3M™ Organic Vapour Monitors are simple and effective personal sampling badges. The monitor captures a wide range of airborne organic vapours, enabling a laboratory to analyse and identify the type and level of exposure to the worker.



The airborne concentrations measured can be used as part of a risk management process to institute suitable controls, including assisting in determination of the type and service life of respiratory equipment appropriate to the contaminants (according to AS/NZS1715).

For more information, please contact 3M and request a copy of the 3M™ Organic Vapour Monitor 3500 and 3520 Tech Data Sheet.

### 3M™ Select & Service Life Software

3M have designed software to help you estimate how frequently certain 3M™ Gas and Vapour Cartridges should be replaced. You can then use this information to establish a cartridge change schedule. You will firstly need information on the chemical contaminants in your working environment

**For more information contact your 3M representative or call the 3M TechAssist Helpline:**

**3M Australia:** 1800 024 464

**3M New Zealand:** 0800 364 357

## Ordering Information

3M Code	Model #	Description
70071695210	6099	A2B2E2K2HgP3+Formaldehyde

## Important Notice

To the extent permitted by law, 3M shall not be liable for any loss or damage including any loss of business, loss of profits, or for any indirect, special, incidental or consequential loss or damage arising from reliance upon any information herein provided by 3M. The user is responsible for determining the suitability of the product for its intended use. Nothing in this statement will be deemed to exclude or restrict 3M's liability for death or personal injury arising from its negligence.



**3M Australia Pty Ltd**  
**Personal Safety Division**  
Bldg A, 1 Rivett Road  
North Ryde NSW 2113  
TechAssist Helpline: 1800 024 464  
Customer Service: 1300 363 565  
Email: techassist@mmm.com  
Web: [www.3M.com/au/ppesafety](http://www.3M.com/au/ppesafety)

**3M New Zealand Ltd**  
**Personal Safety Division**  
94 Apollo Drive, Rosedale  
Auckland 0632  
TechAssist Helpline: 0800 364 357  
Customer Service: 0800 252 627  
Email: techassist@mmm.com  
Web: [www.3M.com/nz/ppesafety](http://www.3M.com/nz/ppesafety)

3M is a trademark of 3M Company.  
Please recycle. Printed in Australia.  
© 3M 2019. All rights reserved.  
AV011467592