# 3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121

### **Product Description**

3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121 is a dipolymer made from hexafluoropropylene and vinylidene fluoride. FC 2121 has an incorporated bisphenol cure system.

### **Special Features**

- Composition: Dipolymer of vinylidene fluoride and hexafluoropropylene
- Low viscosity
- Process targets: injection and transfer moulding, extrusion and calendering
- Utilizes 3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2174 cure technology

Proprietary incorporated cure technology

### **Typical Applications**

3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121 is suitable for O-rings produced in an injection moulding process. An alternative product is 3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FE 5623.

### **Typical Polymer Properties**

| Property                          | Test method | Unit  | Value              |
|-----------------------------------|-------------|-------|--------------------|
| Fluorine Content                  | -           | %     | 65.9               |
| Specific Gravity                  | -           | g/cm³ | 1.80               |
| Colour                            | -           | -     | opaque off-white   |
| Solubility                        | -           | -     | Ketones and Esters |
| Mooney Viscosity ML 1+10 @ 121 °C | -           | MU    | approx. 24         |
|                                   |             |       |                    |

### **Storage and Handling**

Store and use all Dyneon Fluoroelastomers only in well-ventilated areas under cool and dry conditions.

The shelf life of FC 2121 is 3 years from date of manufacturing.

### **Delivery Form**

3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121 is delivered in slab form.

Packaging sizes are:

- 25 kg cardboard box, containing two PE-bags with 12.5 kg content each
- 600 kg bulk container, containing 48 PE-bags with 12.5 kg content each

#### **Processing Recommendations**

Dyneon FC 2121 can be compounded using standard water-cooled internal mixers or two-roll mills with standard fillers and ingredients utilized in typical fluoroelastomer formulations. The "dry" ingredients should be blended before adding to the masticated gum. For best results, FC 2121 should be banded on the mill several minutes prior to adding the blended dry ingredients. Once mixed, the compounded stocks have good scorch resistance and storage stability.



# **Product Data Sheet**

**Commercial Product** 

## 3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121

**Commercial Product** 

### **Typical Properties**

| Compound            | Amount (in Parts/100) |
|---------------------|-----------------------|
| FC 2121             | 100                   |
| N-990 MT Black      | 30                    |
| MgO, High Activity  | 3                     |
| Ca(OH) <sub>2</sub> | 6                     |
|                     |                       |

### Typical Rheological Properties (ASTM D5289)

## Moving Die Rheometer (MDR2000®)

100 cpm, 0.5° Arc, 6 minutes, 177  $^{\circ}\text{C}$ 

| Property                                 | Unit    | Value |
|--|---------|-------|
| ML, Minimum Torque                       | dNm     | 0.8   |
| Ts2, Time to 2 inch-lb rise from minimum | Minutes | 1.3   |
| ť 50, Time to 50 % cure                  | Minutes | 1.5   |
| ť 90, Time to 90 % cure                  | Minutes | 2.4   |
| MH, Maximum Torque                       | dNm     | 24.7  |
|  |         |       |

### **Typical Physical Properties** (ASTM D 412 Method A, Die D)

### Press Cure 7 minutes @ 177 °C Post Cure 16 hours @ 230 °C

| Property               | Unit    | Value |  |
|------------------------|---------|-------|--|
| Tensile Strength       | MPa     | 15.5  |  |
| 100 % Modulus          | MPa     | 7.0   |  |
| Elongation at Break    | %       | 180   |  |
| Hardness (ASTM D 2240) | Shore A | 78    |  |

### Compression Set on O-rings (ASTM D1414)

| Air aged 70 hours @ 200 °C         |              |     |  |
|------------------------------------|--------------|-----|--|
| Post cured 16 hours @ 230 °C       | %            | 20  |  |
| Post cured 24 hours @ 260 °C       | %            | 18  |  |
| Retraction at Lower Temperatures ( | ASTM D 1329) |     |  |
| TR10                               | °C           | -18 |  |



## 3M<sup>™</sup> Dyneon<sup>™</sup> Fluoroelastomer FC 2121

**Commercial Product** 

#### **Safety Instructions**

Follow the normal precautions observed with all fluoropolymer materials.

Please consult the Material Safety Data Sheet and Product Label for information regarding the safe handling of the material. By following all precautions and safety measures, processing these products poses no known health risks. General handling/processing precautions include: 1) Process only in well-ventilated areas. 2) Do not smoke in areas contaminated with powder/residue from these products. 3) Avoid eye contact. 4) If skin comes into contact with these products during handling, wash with soap and water afterwards. 5) Avoid contact with hot fluoropolymer.

Potential hazards, including release of toxic vapours, can arise if processing occurs under excessively high temperature conditions. Vapour extractor units should be installed above processing equipment. When cleaning processing equipment, do not burn off any of this product with a naked flame or in a furnace.

#### **Important Notice**

All information set forth herein is based on our present state of knowledge and is intended to provide general notes regarding products and their uses. It should not therefore be construed as a guarantee of specific properties of the products described or their suitability for a particular application. Because conditions of product use are outside Dyneon's control and vary widely, user must evaluate and determine whether a Dyneon product will be suitable for user's intended application before using it.

The quality of our products is warranted under our General Terms and Conditions of Sale as now are or hereafter may be in force.

Technical information, test data, and advice provided by Dyneon personnel are based on information and tests we believe are reliable and are intended for persons with knowledge and technical skills sufficient to analyze test types and conditions, and to handle and use raw polymers and related compounding ingredients.

No license under any Dyneon or third party intellectual rights is granted or implied by virtue of this information.

General recommendations on health and safety in processing, on work hygiene and on measures to be taken in the event of accident are detailed in our material safety data sheets.

You will find further notes on the safe handling of fluoropolymers in the brochure "Guide for the safe handling of Fluoropolymers Resins" (download link) by PlasticsEurope, Box 3, B-1160 Brussels, Tel. +32 (2) 676 17 32.

You can also download it with your smartphone using the QR code below.



#### **Customer Service**

| Europe  |                   |
|---------|-------------------|
| Phone:  | 00 800 396 366 27 |
| Fax:    | 00 800 396 366 39 |
| Italy   |                   |
| Phone:  | 800 7 910 18      |
| Fax:    | 800 7 810 19      |
| USA     |                   |
| Phone : | +1 800 810 8499   |
| Fax :   | +1 800 635 8061   |

Web Site: www.dyneon.eu



Dyneon GmbH

3M Advanced Materials Division Industrieparkstraße 1 84508 Burgkirchen Germany Phone: +49 8679 7 4709 Fax : +49 8679 7 5037 Technical Service Fluoroelastomers & Polymer Processing Additives 3M Belgium BVBA / SPRL

3M Advanced Materials Division Canadastraat 11, Haven 1005 2070 Zwijndrecht Belgium Phone: +32 3 250 7868 Fax: +32 3 250 7905

#### Technical Service PTFE Compounds

Dyneon B.V. 3M Advanced Materials Division Tunnelweg 95 6468 EJ Kerkrade The Netherlands Phone: +31 45 567 9600 Fax: +31 45 567 9619

We will gladly supply further contact details for our full network of global sales offices. Alternatively, find them here.

Printed in Germany © Dyneon 2013 Status: Dec. 2013 3M, Dyneon and Dynamar are Trademarks of 3M Company. All Rights reserved. The present edition replaces all previous versions. Its content is being continuously adjusted to reflect the current level of knowledge. Please make sure and inquire if in doubt whether you have the latest edition.