



## Instructions and Parts List

**3M-Matic**<sup>TM</sup>

**700a** Type 40800

**Adjustable  
Case Sealer**

**with**

**AccuGlide**<sup>TM</sup> **3**  
**Taping Heads**

Serial No. \_\_\_\_\_  
For reference, record machine serial number here.



**3M Industrial Adhesives and Tapes**  
3M Center, Building 220-5E-06  
St. Paul, MN 55144-1000



### Important Safety Information

BEFORE INSTALLING  
OR OPERATING THIS  
EQUIPMENT

Read, understand, and  
follow all safety and  
operating instructions.

### Spare Parts

It is recommended you  
immediately order the  
spare parts listed in the  
"Spare Parts/Service  
Information" section.

These parts are expected  
to wear through normal  
use, and should be kept  
on hand to minimize  
production delays.

"3M-Matic" and "AccuGlide" are Trademarks of,  
3M St. Paul, MN 55144-1000  
Printed in U.S.A.

© 3M 2011 44-0009-2074-2 (B062411-NA)



This instruction manual covers safety aspects, handling and transport, storage, unpacking, preparation, installation, operation, adjustments, maintenance, troubleshooting, repair work and servicing plus parts list of the **3M-Matic™ 700a** Adjustable case sealer.

**3M Industrial Adhesives and Tapes**  
**3M Center, Building 220-5E-06**  
**St. Paul, MN 55144-1000**

Edition June 2011

Copyright 3M 2011  
All rights reserved

The manufacturer reserves the right to change the product at any time without notice.

---

## Replacement Parts and Service Information

---

### To Our Customers:

This is the 3M-Matic™/AccuGlide™/Scotch® equipment you ordered. It has been set up and tested in the factory with Scotch® tapes. If technical assistance or replacement parts are needed, call or fax the appropriate number listed below.

Included with each machine is an Instructions and Parts List manual.

### Technical Assistance / Replacement Parts and Additional Manuals:

Contact your local service provider help line 1-800-328-1390. Provide the customer support coordinator with the model/machine name, machine type, and serial number that are located on the identification plate (For example: Model 700a - Type 40800 - Serial Number 13282).

### Identification Plate

<b>3M</b> 3M Company St. Paul, MN 55144 USA	Part Number	<b>3M-Matic™</b> For Commercial Use Only			 4000588
	Model	Year	Ampere	Watt	
Type	Serial Number	Volt	Hertz	Phase	



**3M Industrial Adhesives and Tapes**  
3M Center, Building 220-5E-06  
St. Paul, MN 55144-1000

3M-Matic™, AccuGlide™ and Scotch™ are  
Trademarks of  
3M St. Paul, MN 55144-1000  
Printed in U.S.A.

THIS PAGE IS BLANK

**TABLE OF CONTENTS - MANUAL 1: 700a Adjustable Case Sealer**  
**(For Taping Head Information - See MANUAL 2: AccuGlide™ 3 Taping Heads - 2 inch)**

<b>700a Adjustable Case Sealer</b>	<b>Page</b>
Cover Page	
Replacement Parts and Service Information .....	i - ii
Table of Contents .....	iii - v
Acronyms and Abbreviations .....	vi
<b>1. Introduction</b>	
1.1 Manufacturing Specifications / Description / Intended Use .....	1 - 2
1.2 How to Read and Use the Manual .....	2
1.2.1 Importance of the Manual .....	2
1.2.2 Manual Maintenance .....	2
1.2.3 Consulting the Manual .....	2
1.2.4 How to Update the Manual in Case of Modifications .....	2
<b>2. General Information</b>	
2.1 Identification Data .....	3
2.2 Warranty / Contents .....	4
<b>3. Safety</b>	
3.1 General Safety Information .....	5
3.2 Signal Words Explanation .....	5
3.3 Table of Warnings .....	6 - 7
3.4 Operator's Qualifications Definition .....	8
3.5 Number of Operators .....	8
3.6 Safe Use of the Machine Instructions .....	8
3.7 Residual Hazards .....	8
3.8 Prevent Other Hazards - Recommendations and Measures .....	8
3.9 Personal Safety Measures .....	8
3.10 Incorrect / Predictable Actions Not Allowed .....	8
3.11 Operator's Required Skill Levels .....	9
3.12 Component Locations .....	10
3.13 Table of Warnings and Replacement Labels .....	11
<b>4. Technical Specifications</b>	
4.1 Power Requirements .....	12
4.2 Operating Rate .....	12
4.3 Operating Conditions .....	12
4.4 Tape .....	12
4.5 Tape Width .....	12
4.6 Tape Roll Diameter .....	13
4.7 Tape Application Leg Length - Standard .....	13
Tape Application Leg Length - Optional	
4.8 Box Board .....	13
4.9 Box Weight and Size Capacities .....	13
4.10 Machine Noise Levels .....	14
4.11 Machine Dimensions .....	14
4.12 Set-Up Recommendations .....	14

THIS PAGE IS BLANK

## TABLE OF CONTENTS (continued)

---

### 5. Shipment, Handling, and Storage

5.1 Packed Machine Shipment and Handling .....	15
5.2 Overseas Shipment Packaging (Optional) .....	15
5.3 Handling and Transportation of Uncrated Machine .....	15
5.4 Machine Storage .....	15

### 6. Unpacking

6.1 Uncrating .....	16
6.2 Packaging Materials Disposal .....	16

### 7. Installation

7.1 Operating Conditions .....	17
7.2 Space Requirements for Machine Operation and Maintenance .....	17
7.3 Tool Kit Supplied with the Machine .....	17
7.4 Machine Positioning .....	17
7.5 Plastic Ties Removal .....	18
7.6 Assembly Completion .....	18
7.7 Taping Heads Completion .....	19
7.8 Outboard Tape Roll Holder .....	19
7.9 Preliminary Electric Inspection .....	19
7.10 Main Power Machine Connection and Inspection .....	19
7.11 Phases Inspection .....	19

### 8. Theory of Operation

8.1 Working Cycle Description .....	20
8.2 Running Mode Definition .....	20
8.3.1 Normal Stop Procedure .....	20
8.3.2 Emergency Stop .....	20

### 9. Controls

9.1 Box Width Adjusting Knobs .....	21
9.2 Box Height Adjusting Crank .....	21
9.3 Start / Stop Main Switch .....	21
9.4 Emergency Stop Button (Latching) .....	21

### 10. Safety devices

10.1 Blade Guards .....	22
10.2 Emergency Stop Button .....	22
10.3 Electric System .....	22

### 11. Set-Up and Adjustments

11.1 Box Width Adjustment .....	23
11.2 Box Height Adjustment .....	23
11.3 Top Flap Compression Roller Adjustment .....	23
11.4 Changing the Tape Leg Length .....	23
11.5 Run Boxes to Check Adjustment .....	24

THIS PAGE IS BLANK

**TABLE OF CONTENTS** (continued)

---

**12. Operation**

- 12.1 Operator’s Correct Working Position ..... 25
- 12.2 Starting the Machine ..... 25
- 12.3 Starting Production ..... 25
- 12.4 Tape Replacement ..... 25
- 12.5 Box Size Adjustment ..... 25
- 12.6 Cleaning ..... 25
- 12.7 Table of Adjustments ..... 25
- 12.8 Safety Devices Inspection ..... 25
- 12.9 Troubleshooting ..... 26 - 28

**13. Maintenance**

- 13.1 Safety Measures (see section 3) ..... 29
- 13.2 Tools and Spare Parts Supplied with Machine ..... 29
- 13.3 Maintenance Operations - Recommended Inspections and Frequency ..... 29
- 13.4 Inspections to be Performed Before and After Every Maintenance Operation ..... 29
- 13.5 Safety Features (Inspection Efficiency) ..... 29
- 13.6 Machine Cleaning ..... 29
- 13.7 Blade Cleaning ..... 29
- 13.8 Drive Belt Replacement ..... 30
- 13.9 Drive Pulley Ring ..... 32
- 13.10 Drive Belt Tension ..... 31 - 33
- 13.11 Maintenance Work Log ..... 34

**14. Additional Instructions**

- 14.1 Machine Disposal Information ..... 35
- 14.2 Fire emergency ..... 35

**15. Enclosures and Special Information**

- 15.1 Statement of Conformity ..... 35
- 15.2 Hazardous Substances Emission ..... 35

**16. Technical Documentation and Information**

- 16.1 Electric Diagrams ..... 37
- 16.2 Spare Parts / Ordering ..... 38 - 39

- Drawings and Parts Lists** ..... 41 - End of Manual

**TAPING HEAD INFORMATION -  
MANUAL 2: AccuGlide™ 3 Taping Heads - 2 inch (See MANUAL 2 for Table of Contents)**

## ABBREVIATIONS AND ACRONYMS

---

### LIST OF ABBREVIATIONS, ACRONYMS


3M-Matic	- Trademark of 3M St. Paul, MN 55144- 1000
AccuGlide	- Trademark of 3M St. Paul, MN 55144-1000
Scotch	- Trademark of 3M St. Paul, MN 55144-1000
Drw.	- drawing
Ex.	- for example
Fig.	- exploded view figure no. (spare parts)
Figure	- Illustration
Max.	- maximum
Min.	- minimum
Nr.	- number
N/A	- not applicable
OFF	- machine not operating
ON	- machine operating
PLC	- Programmable Logic Control
PP	- Polypropylene
PU/PU Foam	- Polyurethane Foam
PTFE	- Polytetraflourethelene
PVC	- Poly-vinyl chloride
W	- Width
H	- Height
L	- Length

## 1-INTRODUCTION

---

### 1.1 Manufacturing Specifications / Description / Intended Use

The **3M-Matic™ 700a Adjustable Case Sealer with AccuGlide™ 3 Taping Heads** is designed to apply a “C” clip of **Scotch®** pressure-sensitive film box sealing tape to the top and bottom center seam of regular slotted containers. The **700a** automatically adjusts to a wide range of box sizes (see "Specifications Section – Box Weight and Size Capacities").



#### **3M-Matic™ 700a Adjustable Case Sealer, Type 40800**

**Note** – Shown above is the lower tape supply roll and bracket assembly in the alternate location.

## 1-INTRODUCTION (continued)

---

### 1.1 Manufacturing Specifications / Description / Intended Use (continued)

The 3M-Matic case sealing machines have been designed in compliance with the legal requirements at the date of inception.

### 1.2 How to Read and Use the Instruction Manual

This instruction manual covers safety aspects, handling and transport, storage, unpacking, preparation, installation, operation, set-up and adjustments, technical and manufacturing specifications, maintenance, troubleshooting, repair work and servicing, electric diagrams, warranty information, disposal (ELV), a definition of symbols, plus a parts list of the 3M-Matic **700a** Adjustable case sealer 3M Industrial Adhesives and Tapes Division 3M Center, Bldg. 220-5E-06 St. Paul, MN 55144-1000 (USA) Edition June 2011 Copyright 3M 2011 All rights reserved. The manufacturer reserves the right to change the product at any time without notice **Publication © 3M 2011 44-0009-2074-2.**

#### 1.2.1 Importance of the Manual

The manual is an important part of the machine; all information contained herein is intended to enable the equipment to be maintained in perfect condition and operated safely. Ensure that the manual is available to all operators of this equipment and is kept up to date with all subsequent amendments. Should the equipment be sold or disposed of, please ensure that the manual is passed on. Electrical and pneumatic diagrams are included in the manual. Equipment using PLC controls and/or electronic components will include relevant schematics or programs in the enclosure and in addition, the relevant documentation will be delivered separately.

### 1.2.2 Manual Maintenance

Keep the manual in a clean and dry place near the machine. Do not remove, tear, or rewrite parts of the manual for any reason. Use the manual without damaging it. In case the manual has been lost or damaged, ask your after sale service for a new copy.

### 1.2.3 Consulting the Manual

The manual is composed of:

- Pages which identify the document and the machine
- Index of the subjects
- Instructions and notes on the machine
- Enclosures, drawings and diagrams
- Spare parts (last section)

All pages and diagrams are numbered. The spare parts lists are identified by the figure identification number. All the notes on safety measures or possible dangers are identified by the symbol:



### 1.2.4 How to Update the Manual in Case of Modifications to the Machine


Modifications to the machine are subject to manufacturer's internal procedures. The user receives a complete and up-to-date copy of the manual together with the machine. Afterwards the user may receive pages or parts of the manual which contain amendments or improvements made after its first publication. The user must use them to update this manual.

## 2-GENERAL INFORMATION

---

### 2.1 Data Identifying Manufacturer and Machine

<b>3M</b> <b>3M Industrial Adhesives and Tapes</b>  3M Center Bldg. 220-5E-06 St. Paul, MN 55144-1000 (USA)
---



<b>3M</b>	3M Company St. Paul, MN 55144 USA	Part Number	<b>3M-Matic™</b> For Commercial Use Only			 4000 563
Model			Year	Amps	Watt	
Type		Serial Number	Volt	Hertz	Phase	

## 2.2 Warranty

**Equipment Warranty and Limited Remedy: THE FOLLOWING WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, THE IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, A CUSTOM OR USAGE OF TRADE:**

3M sells its **3M-Matic™ 700a Adjustable Case Sealer, Type 40800** with the following warranties:

1. The drive belts and the taping head knives, springs and rollers will be free from all defects for ninety (90) days after delivery.
2. All other taping head parts will be free from all defects for three (3) years after delivery.
3. All other parts will be free from all defects for two (2) years after delivery.

If any part is proved to be defective within its warranty period, then the exclusive remedy and 3M's and seller's sole obligation shall be, at 3M's option, to repair or replace the part, provided the defective part is returned immediately to 3M's factory or an authorized service station designated by 3M. A part will be presumed to have become defective after its warranty period unless the part is received or 3M is notified of the problem no later than five (5) calendar days after the warranty period. If 3M is unable to repair or replace the part within a reasonable time, then 3M at its option, will replace the equipment or refund the purchase price. 3M shall have no obligation to provide or pay for the labor required to install the repaired or replacement part. 3M shall have no obligation to repair or replace (1) those parts failing due to operator misuse, carelessness, or due to any accidental cause other than equipment failure, or (2) parts failing due to non-lubrication, inadequate cleaning, improper operating environment, improper utilities or operator error.

**Limitation of Liability:** 3M and seller shall not be liable for direct, indirect, special, incidental or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability or any other legal theory.

The foregoing Equipment Warranty and Limited Remedy and Limitation of Liability may be changed only by a written agreement signed by authorized officers of 3M and seller.

---

### Contents—700a Adjustable Case Sealer

---

- (1) **700a** Adjustable Case Sealer, Type 40800
- (1) Tool and Spare Parts Kit
- (1) Instruction and Parts Manual


### 3-SAFETY

#### 3.1 General Safety Information

Read all the instructions carefully before starting work with the machine; please pay particular attention to sections marked by the symbol:



Figure 3-1



The machine is provided with a LATCHING EMERGENCY STOP BUTTON (**Figure 3-1**); when this button is pressed, it stops the machine at any point in the working cycle. Maintain clear access to power cord while machine is operating. Disconnect plug from power source before machine maintenance (**Figure 3-1**). Also disconnect air if the machine has a pneumatic system. Keep this manual in a handy place near the machine. This manual contains information that will help you to maintain the machine in a good and safe working condition.

#### 3.2 Explanation of Signal Word and Possible Consequences



This safety alert symbol identifies important messages in this manual. READ AND UNDERSTAND THEM BEFORE INSTALLING OR OPERATING THIS EQUIPMENT.



**CAUTION:** Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury and/or property damage.



**WARNING:** Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury and/or property damage.

3.3 Table of Warnings

	<b>WARNING</b>
<ul style="list-style-type: none"> <li>• <b>To reduce the risk associated with mechanical and electrical hazards:</b> <ul style="list-style-type: none"> <li>– Read, understand, and follow all safety and operating instructions before operating or servicing the case sealer.</li> <li>– Allow only properly trained and qualified personnel to operate and service this equipment.</li> </ul> </li> </ul>	

	<b>WARNING</b>
<ul style="list-style-type: none"> <li>• <b>To reduce the risk associated with hazardous voltage:</b> <ul style="list-style-type: none"> <li>– Position electrical cord away from foot and vehicle traffic.</li> </ul> </li> </ul>	

	<b>WARNING</b>
<ul style="list-style-type: none"> <li>• <b>To reduce the risk associated with pinches, entanglement and hazardous voltage:</b> <ul style="list-style-type: none"> <li>– Turn electrical supply off and disconnect before performing any adjustments, maintenance or servicing the machine or taping heads.</li> </ul> </li> </ul>	

	<b>WARNING</b>
<ul style="list-style-type: none"> <li>• <b>To reduce the risk associated with pinches and entanglement hazards:</b> <ul style="list-style-type: none"> <li>– Do not leave the machine running while unattended.</li> <li>– Push the machine off when not in use.</li> <li>– Never attempt to work on any part of the machine, load tape, or remove jammed boxes from the machine while the machine is running.</li> </ul> </li> </ul>	

	<b>SAFETY INSTRUCTIONS</b>
Figure 3-2	<ol style="list-style-type: none"> <li>1. Shut off machine before adjusting</li> <li>2. Unplug electric power before servicing</li> <li>3. Do not leave machine running unattended</li> <li>4. Refer to instruction manual for complete setup, operating, and servicing information</li> </ol>




Figure 3-3




Figure 3-4

 **WARNING**

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

**Important!** Tape cutting blade. Never remove the safety device which covers the blade on the top and bottom taping units. Blades are extremely sharp. Any error may cause serious injuries (**Figure 3-5**).

 **WARNING**



- **To reduce the risk associated with fire and explosion hazards:**
  - Do not operate this equipment in potentially flammable/explosive environments.

 **WARNING**

- **To reduce the risk associated with muscle strain:**
  - Use the appropriate rigging and material handling equipment when lifting or repositioning this equipment.
  - Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift.

 **CAUTION**

- **To reduce the risk associated with pinch hazards:**
  - Keep hands clear of the upper head support assembly as boxes are transported through the machine.
  - Keep hands, hair, loose clothing, and jewelry away from box compression rollers.
  - Always feed boxes into the machine by pushing only from the end of the box.
  - Keep hands, hair, loose clothing, jewelry away from moving belts and taping heads.



### 3.4 Operator's Qualifications

- Machine Operator
- Mechanical Maintenance Technician
- Electrical Maintenance Technician
- Manufacturer's Technician/Specialist  
(See Section 3)

### 3.5 Number of Operators

The operations described below have been analyzed by the manufacturer; the recommended number of operators for each operation provides the best and safest work performance.

**Note:** A smaller or greater number of operators could be unsafe.

### 3.6 Instructions for a Safe Use of the Machine / Definition of Operator's Qualifications

Only persons who have the skills described in the skill levels section should be allowed to work on the machine. It is the responsibility of the user to appoint the operators having the appropriate skill level and the appropriate training for each category of job.

### 3.7 Residual Hazards

The case sealer 700a incorporates various safety protections which should never be removed or disabled. It is essential that the operator and service personnel be warned that hazards exist which cannot be eliminated.

### 3.8 Recommendations and Measures to Prevent Other Hazards which Cannot be Eliminated

- The operator must stay on the working position shown in the Operation Section. He must never touch the running driving belts or put his hands inside any cavity.
- The operator must pay attention to the blades during the tape replacement.



## WARNING

- **To reduce the risk associated with mechanical and electrical hazards:**
  - Read, understand, and follow all safety and operating instructions before operating or servicing the case sealer.
  - Allow only properly trained and qualified personnel to operate and service this equipment.

### 3.9 Personal Safety Measures

Safety glasses, safety gloves, safety helmet, safety shoes, air filters, ear muffs - None is required except when recommended by the user.

### 3.10 Predictable Actions which are Incorrect and Not Allowed

- Never try to stop/hold the box while being driven by the belts.
- Never remove or disable the safety devices.
- Only authorized personnel should be allowed to carry out the adjustments, repairs or maintenance which require operation with reduced safety protections. During such operations, access to the machine must be restricted. When the work is finished, the safety protections must immediately be reactivated.
- The cleaning and maintenance operations must be performed after disconnecting the electric power.
- Do not modify the machine or any part of it.
- Clean the machine using only dry cloths or light detergents. Do not use solvents, petrols, etc.
- Install the machine following the suggested layouts and drawings.

**3.11 Operator's Skill Levels Required to Perform the Main Operations on the Machine**

The Table shows the minimum operator's skill for each machine operation.

**Important:** The factory manager must ensure that the operator has been properly trained on all the machine functions before starting work.

**Skill 1: Machine Operator**

This operator is trained to use the machine with the machine controls, to feed cases into the machine, make adjustments for different case sizes, to change the tape and to start, stop and restart production.

**Skill 2: Mechanical Maintenance Technician**

This operator is trained to use the machine as the MACHINE OPERATOR and in addition is able to:

- Work with the safety protection disconnected
- Check and adjust mechanical parts
- Carry out machine maintenance operations/repairs

He is not allowed to work on live electrical components

**Skill 2a: Electrical Maintenance Technician**

This operator is trained to use the machine as the MACHINE OPERATOR and in addition is able to:

- Work with the safety protection disconnected
- Check and adjust mechanical parts
- Carry out machine maintenance operations / repairs / adjustments / repair electrical components

He is allowed to work on live electrical panels, connector blocks, control equipment, etc.

**Skill 3: Specialist from the Manufacturer**

Skilled operator sent by the manufacturer or its agent to perform complex repairs or modifications (on agreement with the customer).


 <b style="font-size: 1.2em;">WARNING</b>
<ul style="list-style-type: none"> <li>• <b>To reduce the risk associated with mechanical and electrical hazards:</b> <ul style="list-style-type: none"> <li>- Allow only properly trained and qualified personnel to operate and service this equipment.</li> </ul> </li> </ul>

**Operator's Skill Levels Required to Perform the Main Operations on Machine**

Operation	Machine Status	Required Operator Skill	Number of Operators
Machine installation and setup	Running with safety protections disabled	2 and 2a	2
Adjusting box size	Stopped by pressing the EMERGENCY STOP button	1	1
Tape replacement	Stopped by pressing the EMERGENCY STOP button	1	1
Blade replacement	Electric power disconnected	2	1
Drive belt replacement	Electric power disconnected	2	1
Ordinary maintenance	Electric power disconnected	2	1
Extraordinary mechanical maintenance	Running with safety protections disabled	3	1
Extraordinary electrical maintenance	Running with safety protections disabled	2a	1

### 3.12 Component Locations

Refer to **Figure 3-9** below to acquaint yourself with the various components and controls of the case sealer. Also refer to Manual 2 for taping head components.



**Figure 3-9—700a Case Sealer Components (Left Front View)**

3.13 Table of Warnings and Replacements Labels (continued)




Figure 3-10 - Replacement Labels / 3M Part Numbers

## 4-SPECIFICATIONS

---

### 1. Power Requirements:

Electrical – 120 VAC, 60 Hz, 3.25 A

Pneumatic – 6.5 bar gauge pressure [95 PSIG], 2.5 SCFM


75 liter/minute @ 21° C., 1.01 bar maximum at maximum cycle rate.

A pressure regulator/filter is included.

The machine is equipped with two 1/6 HP gearmotors and comes with an 2.4 m [8 foot] standard neoprene covered power cord and a grounded plug. Contact your 3M Representative for power requirements not listed above. Contact your 3M Representative for power requirements not listed above.

### 2. Operating Rate:

Belt speed is 0.5m/s [100 F.P.M.]



Actual production rate is dependent on operator's dexterity. Boxes must be 18 inches (457mm) apart minimum.

### 3. Operating Conditions

Use in dry, relatively clean environments at 5° C to 50° C [40° F to 120° F] with clean, dry boxes.

**Note:** Machine should not be washed or subjected to conditions causing moisture condensation on components.

 <b>WARNING</b>
<ul style="list-style-type: none"><li>• <b>To reduce the risk associated with fire and explosion hazards:</b><ul style="list-style-type: none"><li>– Do not operate this equipment in potentially flammable or explosive environments.</li></ul></li></ul>

### 4. Tape

Scotch® pressure-sensitive film box sealing tapes.

### 5. Tape Width

36mm [1 1/2 inch] minimum to 48mm [2 inch] maximum

## 4-SPECIFICATIONS (continued)

---

### Specifications

#### 6. Tape Roll Diameter

Up to 405mm [16 inch] maximum on a 76mm [3 inch] diameter core.

(Accommodates all system roll lengths of **Scotch®** film tapes.)

#### 7. Tape Application Leg Length – Standard

70 mm ± 6mm [2.75 inch ± .25 inch ]

#### Tape Application Leg Length – Optional

50 mm ± 6mm [2 inch ± .25 inch]

(See "Removing Taping Heads Procedure – Changing the Tape Leg Length")

#### 8. Box Board

Style – regular slotted containers – RSC

125 to 275 P.S.I. bursting test, single wall or double wall B or C flute.

23-44 lbs. per inch of width Edge Crush Test (ECT)

#### 9. Box Weight and Size Capacities

A. Box Weight, filled: 5 lbs.–65 lbs. [2.3 kg–29.5 kg]. Contents must support flaps.

B. Box Size:	Minimum	Maximum
Length –	150mm [6.0 inch]	Unlimited
Width –	150mm [6.0 inch]*	550mm [21.5 inch]
Height –	120mm [4.75 inch]** ***	620mm [24.5 inch] ***

\* Cartons narrower than 250 mm [10 inch] in width may require more frequent belt replacement because of limited contact area.

\*\* 90 mm [3.5 inch] height with heads adjusted to apply 50 mm [2 inch] tape leg lengths.  
(See "Special Set-Up Procedure – Changing the Tape Leg Length")

\*\*\* 165 mm [6.5 inch] minimum to 725 mm [28.5 inch] maximum height with columns adjusted to upper position. (See "Special Set-Up Procedure – Box and Machine Bed Height Range",


**Note:** The case sealer can accommodate most boxes within the size range listed above. However, if the box length (in direction of seal) to box height ratio is 0.6 or less, test run several boxes to ensure proper machine performance.

#### DETERMINE THE BOX LIMITATIONS BY COMPLETING THIS FORMULA:

$$\frac{\text{BOX LENGTH IN DIRECTION OF SEAL}}{\text{BOX HEIGHT}} = \text{SHOULD BE GREATER THAN 0.6}$$

Any box ratio approaching this limitation should be test run to ensure performance.

4-SPECIFICATIONS (continued)



10. Machine Dimensions

	W	L	H	A*	B	C**	F
<b>Minimum</b>							
mm	790	1030	1350	460	610	100	625
[Inches]	[31]	[40.5]	[53]	[18]	[24]**	[4]	[24.5]
<b>Maximum</b>							
mm	--	--	2185	--	890	--	--
[Inches]	--	--	[86]**	--	[35]**	--	--

\* Infeed/Exit conveyors are optional

\*\* Casters are optional

\*\*\* When columns are adjusted to upper position, "B" minimum/maximum dimension decreases by 90 mm [3 1/2 inches] and "H" maximum dimension increases by 100 mm [4 inch]. (See "Special Set-Up Procedure – Box and Machine Bed Height Range".)

**Weight** – 180kg [400 lbs] crated (approximate)  
160kg [350 lbs] uncrated (approximate)

11. **Machine Noise Level:** Acoustic pressure measured at a distance of 1m. from machine with Scotch PVC adhesive tape in operation; 78dB Acoustic radiation pressure at 1.6m. height with Scotch PVC adhesive tape in operation; 73dB Measurement taken with appropriate instrument: (Type SPYRI-MICROPHON 11).

12. **Set-Up Recommendations:**

- Machine must be level.
- Customer supplied infeed and exit conveyors (if used) should provide straight and level box entry and exit.
- Exit conveyors (powered or gravity) must convey sealed boxes away from machine.

## 5-SHIPMENT-HANDLING-STORAGE, TRANSPORT

### 5.1 Shipment and Handling of Packed Machine

- The machine is fixed on the pallet with four (4) bolts and can be lifted by using a fork truck.
- The package is suitable to travel by land and by air.
- Optional sea freight package is available.

#### Packaging Overall Dimensions (Figure 5-1)

See Specifications.

During the shipment it is possible to stack a maximum of two (2) machines (Figure 5-2).

### 5.2 Packaging for Overseas Shipment (Optional - Figure 5-3)

The machines shipped by sea freight are covered by an aluminum/polyester/polythene bag which contains dehydrating salts.

### 5.3 Handling and Transportation of Uncrated Machine

The uncrated machine should not be moved except for short distances and indoors ONLY. Without the supporting pallet, the machine is exposed to damage and may cause injuries. To move the machine use belts or ropes, paying attention to place them in the points indicated using care to not interfere with the lower taping head (Figure 5-4).

### 5.4 Storage of the Packed or Unpacked Machine

If the machine is not used for a long period, please take the following precautions:

- Store the machine in a dry and clean place.
- If the machine is unpacked it is necessary to protect it from dust.
- Do not stack anything over the machine.
- It is possible to stack a maximum of 2 machines (if they are in their original packing).




Figure 5-1




Figure 5-2




Figure 5-3





Figure 5-4


## 6-UNPACKING

### 6.1 Uncrating


The envelope attached to the shipping box contains the uncrating instructions of the machine (**Figure 6-1**).



Cut straps. Cut out staple positions along the bottom of the shipping box (or remove staples with an appropriate tool - **Figure 6-2**)




After cutting out or removing the staples, lift the shipping box in order to clear the machine (two persons required).




Transport the machine with a fork-lift truck to the operating position. Lift the pallet at the point indicated in **Figure 6-3** (weight of machine + pallet = See Specifications).

### Removal of Pallet

Using a 10mm combination wrench, remove the fasteners that secure the case sealer legs to pallet at each leg (as shown in **Figure 6-4**).



A package is located under the machine body. Retrieve the instruction manual for additional procedures of the set up. The package also contains parts removed for shipping, spare parts and tools (**Figure 6-5**).



### 6.2 Disposal of Packaging Materials

The **700a** package is composed of:

- Wooden pallet
- Cardboard shipping box
- Wooden supports
- Metal fixing brackets
- PU foam protection
- PP plastic straps
- Dehydrating salts in bag
- Special bag of laminated polyester/aluminium/  
Polyethylene (sea freight package only)
- Polyethylene protective material

For the disposal of the above materials, please follow the environmental directives or the law in your country.

## 7-INSTALLATION

### 7.1 Operating Conditions

The machine should operate in a dry and relatively clean environment (See Specifications).

### 7.2 Space Requirements for Machine Operation and Maintenance Work

Minimum distance from wall (**Figure 7-1**):

A = 1000mm.

B = 700mm.

Minimum height = 2700mm.




Figure 7-1

### 7.3 Tool Kit Supplied with the Machine

A tool kit containing some tools are supplied with the machine. These tools should be adequate to set-up the machine, however, other tools supplied by the customer will be required for machine maintenance.



#### WARNING

- **To reduce the risk associated with mechanical and electrical hazards:**
  - Allow only properly trained and qualified personnel to operate and service this equipment.



#### WARNING

- **To reduce the risk associated with muscle strain:**
  - Use the appropriate rigging and material handling equipment when lifting or repositioning this equipment.
  - Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift.




Figure 7-2

### 7.4 Machine Set-Up / Bed Height

Adjust machine bed height. The case sealer is equipped with four (4) adjustable legs that are located at the corners of the machine frame. The legs can be adjusted to obtain different machine bed heights (See Specifications).

Refer to **Figure 7-3** and set the machine bed height as follows:

1. Raise and block up the machine frame to allow adequate leg adjustment.
2. Loosen, but do not remove, two (2) M8 x 16 socket head screws in one leg (use M6 hex wrench). Adjust the leg length for the desired machine bed height. Retighten the two screws to secure the leg. Adjust all four (4) legs equally.






Figure 7-3

### 7.5 Removal of Plastic Ties


Cut the plastic which attaches the top head to the frame and remove the polystyrene blocks (**Figure 7-4**).



Cut the plastic ties holding the lower taping head in position (**Figure 7-6**).




Cut the plastic strap which attaches the strip and the EMERGENCY STOP cable to the frame (**Figure 7-5**).



### 7.6 Assembly Completion

- 1 Crank - Install the crank handle on the top of the left column as shown (**Figure 7-7B**).
- 2 Tape Drum Bracket - Install the upper tape drum bracket on the top cross bar as shown (**Figure 7-7A**).
- 3 Stop Bracket - Raise upper head assembly (turn crank handle counterclockwise) and install the two stop brackets (provided in the parts bag). Use lower set of holes as shown in **Figure 7-7C**. The upper set of holes should only be used when both taping heads are adjusted to apply 50mm tape legs.



## 7-INSTALLATION (continued)

### 7.7 Completion of Taping Heads

See Manual 2 for Complete Instructions:

1. Place the Upper Taping Head in a convenient working position
2. Use **Figure 7-8** and tape threading label. Position the tape supply roll so the adhesive side of tape is facing the front of the taping head as it is pulled from the supply roll.
3. Attach the threading needle to the end of the roll. Guide the threading needle around the wrap roller (**Position 1**) then back around the one-way tension roller (**Position 2**).
4. Continue pulling the threading needle down and guide it between the two (2) rollers on the apply arm (**Position 3**).
5. Pull the threading needle down until the tape travels between the apply plate and the ears of the apply arm (**Position 4**) until it extends past the applying roller. When properly threaded the adhesive side of the tape should be facing the knurled rollers at position 2 and also position 3.
6. Cut away any excess tape and repeat steps for Lower Taping Head.

**Important** – Do not cut against the apply roller - roller damage could occur.

### 7.8 Outboard Tape Roll Holder


If you intend to use the outboard tape roll holder, proceed as follows:

- 1 - Remove the lower taping head from the machine.
- 2 - Remove the tape drum bracket assembly, stud spacer, and fasteners from the lower taping head.
- 3 - Install alternative wrap roller and bracket on the head in place of tape bracket. Replace lower head into machine.
- 4 - Install and secure tape drum bracket assembly on the entry end of the lower frame (as shown in **Figure 7-9**).

### 7.9 Preliminary Electric Inspection

Before connecting the machine to the mains please carry out the following operations:

- 7.9.1** Make sure that the socket is provided with an earth protection circuit and that both the mains voltage and the frequency match the specifications on the name plate.
- 7.9.2** Check that the connection of the machine to the mains meets the safety regulations in your country.
- 7.9.3** The machine is fitted with a main switch and a circuit breaker. The user should check that the electrical settings of the machine are compatible with all the components of the mains system.



### 7.10 Machine Connection to the Mains

For technical specifications: **See Section 4 - Specifications**

- Push the LATCHING EMERGENCY STOP BUTTON.
- The main switch is normally turned OFF (O).

Connect the power cord supplied with the machine to a wall socket using a plug which complies with the safety regulations of your country.

### 7.11 Inspection of Phases (For Three-Main Phases Only)

N/A for this machine.

## 8-THEORY OF OPERATION

### 8.1 Description of the Working Cycle

After having closed the top flaps of the carton, the operator pushes it under the top infeed end in order to avoid the opening of the top flaps. Further pushing causes the two top and bottom belts to drive the box through the taping heads which automatically seal the top and bottom seams. The carton is then expelled on the exit conveyor.




Figure 8-1

### 8.2 Definition of Running Mode

The case sealer **700a** has only one (automatic) operating mode with:

- The EMERGENCY STOP BUTTON unlocked (**Figure 8-1**)
- The main switch start switch "ON" (I) (**Figure 8-2**)




Figure 8-2

#### 8.3.1 Normal Stop Procedure

When the main switch is turned OFF (O), the machine stops immediately at any point of the working cycle. The same thing happens in case of electrical failure or when the machine is disconnected from the mains.

#### 8.3.2 Emergency Stop

The LATCHING EMERGENCY STOP BUTTON is located on the top center of the machine (**Figure 8-1**).




Figure 8-3

9.1 Box Width Adjusting Knobs




Figure 9-1

9.2 Box Height Adjusting Crank





Figure 9-2

9.3 Start / Stop Buttons



Start/Stop Button

Figure 9-3

9.4 Lockable Emergency Stop Button




Figure 9-4

## 10-SAFETY DEVICES OF THE MACHINE

### 10.1 Blade Guards

Both the top and bottom taping units have a blade guard. (See Manual 2: **AccuGlide™ 3 Taping Heads - 2 Inch**).



#### WARNING

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

### 10.2 Emergency Stop Button

The box drive belts are turned on and off with the electrical switch on the side of the machine frame.

The machine electrical supply can be turned off by pressing the latching emergency stop switch. To restart machine, rotate the emergency stop switch clockwise to release the switch latch. Restart machine by pushing the Start button (Figure 10-1).



#### WARNING

- **To reduce the risk associated with hazardous voltage:**
  - Position electrical cord away from foot and vehicle traffic.




Figure 10-1

### 10.3 Electric System / Circuit Breaker

The electric system is protected by a ground wire whose continuity has been tested during the final inspection. The system is also subject to insulation and dielectric strength tests.

#### Circuit Breaker

The case sealer is equipped with a circuit breaker which trips if the motors are overloaded. Located inside the electrical enclosure on the side of the machine frame just below the machine bed, the circuit breaker has been pre-set amps and requires no further maintenance.



#### WARNING

- **To reduce the risk associated with mechanical and electrical hazards:**
  - Allow only properly trained and qualified personnel to operate and service this equipment.

If circuit is overloaded and circuit breaker trips, unplug machine from electrical power:

1. Determine cause of overload and correct.
2. Plug in machine.
3. Press machine "On" (I) button to resume case sealing.

**Important:** The use of an extension cord is not recommended. However, if one is needed for temporary use, it must:

- Have a wire size of 1.5mm diameter [AWG 16]
- Have a maximum length of 30.5m [100 ft]
- Be properly grounded.

## 11 - SET UP AND ADJUSTMENTS

### 11.1 Box Width Adjustment

Place box on infeed end of frame bed and align top flap center seam with arrows on front of upper frame. Move in and lock the side by tightening the appropriate knobs (Figure 11-1).

### 11.2 Box Height Adjustment

Lower top head by turning the height adjustment crank clockwise until it lightly presses the case (Figure 11-2).

### 11.3 Adjustment of Top Flap Compression Rollers

Run the box through the machine and press the EMERGENCY STOP BUTTON when the box is adjacent to the compression rollers. Move the compression rollers in to firmly press the top flaps together. Release Emergency Stop Button and press electrical ON button (Figure 11-3).

### 11.4 Changing the Tape Leg Length

Taping heads are preset to apply 70mm [2.75 inches] long tape legs. To change tape leg length to 50mm [2.0 inches], refer to Instructions below and also to Manual 2, "Removing Taping Heads Procedure - Changing the Tape Leg Length".

**Case Sealer Frame** (Refer to Figure 11-4A)

1. Raise the upper head assembly by turning crank handle. Remove and retain the two screws and washers that secure the stop bracket in position "A".
2. Remount and secure the stop bracket in the lower position "A-A" with original fasteners through top holes of stop bracket. Relocate both right and left stop brackets.



### WARNING

- To reduce the risk associated with sharp blade hazards:
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

### Taping Heads

1. Remove tape from upper taping head and raise upper assembly to a convenient working height.
2. Lift retaining plate that secures the upper taping head shown in Figure 11-4B.
3. Hold upper taping head applying and buffing arms from under upper assembly, slide head forward and down to remove. See Figure 11-6
4. Raise upper assembly to provide working room around lower taping head and remove tape from taping head.
5. Lift the lower taping head, shown in Figure 11-5 and 11-4C, straight up to remove it from the case sealer bed.
6. Also refer to Manual 2, "Adjustments "




Figure 11-1




Figure 11-2






Figure 11-3



### 11.5 Special Set-Up Procedure for Outer Column Re-Positioning

Moving the outer columns up one set of mounting holes increases the maximum box height handled by the 700a case sealer and decreases the minimum conveyor bed height.

- 1 - Place solid blocks approx. 305mm high at the front and rear of the upper taping head assembly as shown in **Figure 11-7A**.
- 2 - Crank the upper taping head assembly down until it touches these blocks.
- 3 - Remove and retain the six screws and plain washers that fasten each column to the frame (**Figure 11-7B**).
- 4 - Turn the height adjustment crank clockwise to raise the outer columns up one set of mounting holes (100mm).
- 5 - Install and tighten the six screws and plain washers in each column. Crank upper taping head assembly up and remove blocks.



## 12-OPERATION

### 12.1 Operator's Correct Working Position and Operational Flow (Figure 12-1).





Figure 12-1

Once the box has been filled, close its top flaps and push it between the top and bottom drive belts. Always keep hands in position as shown in **Figure 12-2**.

The box will be automatically sealed with adhesive tape on the top and bottom box seams. Then the box will be expelled on the exit conveyor.

Figure 12-2

Hand  
position



### 12.2 Starting the Machine

**Important:** Before starting the machine, verify that no tools or other objects are on the conveyor bed.

Push the main switch ON (I) after the EMERGENCY BUTTON is released (**Figure 12-3**).




Figure 12-3

### 12.3 Starting Production

After having adjusted the machine according to the box dimensions (height-width), let the machine run without cartons and check its safety devices. Then start the working cycle.

### 12.4 Tape Replacement and Threading

#### Skill 1 - Operator

See Manual 2: **AccuGlide™ 3 Taping Heads - 2 Inch.**

Press the  
LATCHING EMERGENCY STOP BUTTON.



### WARNING

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

### 12.5 Box Size Adjustment

Repeat all the operations shown in **Section 11 - Set-Up and Adjustments.**

### 12.6 Cleaning

Before carrying out any cleaning or maintenance operation stop the machine by Pushing the OFF (O) switch on the main and disconnect the electric power (**Figure 12-3**).

### 12.7 Table of Operation Adjustments - Operator Qualifications

1	Tape loading and threading	1
2	Tape web alignment	1
3	Adjustment of one way tension roller	1
4	Adjustment to box size (H and W)	1
5	Top flap compression rollers	1
6	Adjustment of tape applying spring	1
7	Conveyor bed height adjustment	1
8	Special Adjustment-Changing tape leg length	2
9	Special Adjustment-Column re-positioning	2

### 12.8 Safety Devices Inspection

- 1 Taping units blade guard
- 2 Latching emergency stop button
- 3 STOP/OFF (O) main switch

12.9 Troubleshooting Guide

PROBLEM	CAUSE	CORRECTION
When pressing the ON button the machine does not start	The lockable emergency stop button is pressed	Release the emergency stop button  Check the electrical system
The magnetothermic protection opens the main switch	Motor under stress  Thermal cut-out not at correct amperage setting	Check that the drive belts are not blocked  Set the correct amperage
Drive belts do not convey boxes	Narrow boxes  Worn drive belts  Taping head applying spring holder missing  Taping head applying spring set too high	Check machine specifications Boxes are narrower than recommended, causing slippage and premature belt wear  Replace drive belts  Adjust the box height adjustment with the crank  Reduce spring pressure
Drive belts do not turn	Worn or missing friction rings  Drive belt tension too low  Electrical disconnect  Motor not turning	Replace friction rings  Adjust belt tension  Check power and electrical plug  Evaluate problem and correct

(continued on next page)

12.9 Troubleshooting Guide (continued)

PROBLEM	CAUSE	CORRECTION
Drive belts break	Worn belt	Replace belt
Squeaking noise as boxes pass through machine	Dry compression rollers Defective column bearings	Lubricate compression rollers Replace column bearings
Tape not centered on box seam	Tape drum not centered Centering guides not centered Box flaps not of equal length	Reposition tape drum Adjust centering guides Check box specifications
The tape leg on the front of the case is too long	The tape is threaded incorrectly The tape tension is too low The knurled roller drags Tape tracks to one side or drags on the support tabs of applying frame Taping heads is not set up properly	Check machine specifications Boxes are narrower than recommended, causing slippage and premature belt wear Replace drive belts Adjust the box height adjustment with the crank Reduce spring pressure

(continued on next page)

12.9 Troubleshooting Guide (continued)

PROBLEM	CAUSE	CORRECTION
<p>The blade does not cut tape or the tape end is jagged or shredded</p>	<p>The blade is dull and/or has broken teeth</p> <p>Tape tension is insufficient</p> <p>Adhesive has built up on the blade</p> <p>The blade is in backwards</p> <p>One or both cutter springs are missing or stretched</p>	<p>Replace the blade</p> <p>Increase tape tension by adjusting the one-way roller</p> <p>Clean and adjust the blade</p> <p>Make sure the blade is bottomed out against the mounting bolts</p> <p>Lubricate the blade oiler pad on the blade guard</p> <p>Mount the blade so that the beveled edge is away from the entrance end of the head</p> <p>Replace the defective spring(s)</p>
<p>Tape is tabbing on the trailing leg on the back of the box</p>	<p>There is excess on the tape drum assembly and/or the on-way tension roller assembly</p> <p>Rollers in the tape path do not rotate freely</p> <p>The blade is not cutting tape properly</p> <p>The tape is threaded incorrect</p> <p>Applying mechanism spring has too little tension</p>	<p>Adjust the one-way tension roller and/or tape drum assembly</p> <p>Clean adhesive deposits from the surface ends and shafts of the rollers. Remove all lubricant from roller surfaces</p> <p>Refer to tape cutting problems</p> <p>Rethread tape</p> <p>Move spring hook to next tighter hole</p>

## 13-MAINTENANCE AND REPAIRS

### 13.1 Safety Measures (see section 3)

Carrying out maintenance and repairs may imply the necessity to work in dangerous situations.

### 13.2 Tools and Spare Parts Supplied with the Machine

See Spare Parts Order Section.

### 13.3 Recommended Frequency of Inspection and Maintenance Operations

Operation	Frequency	Qualification	Sections
Inspection safety features	daily	1	13.4
Cleaning of machine	weekly	1	13.5
Cleaning of cutter blade	weekly	2	13.6
Oiling of felt pad	weekly	2	13.7
Lubrication	monthly	2	13.7-13.8
Blade replacement	when worn	2	See Manual 2
Drive belt replacement	when worn	2	13.10

### 13.4 Inspections to be Performed Before and After Every Maintenance Operation

Before every maintenance operation, Push the main switch OFF (O) and disconnect. During the maintenance operation, only properly trained and qualified personnel must work on the machine. At the end of every maintenance operation check the safety devices.

### 13.5 Check Efficiency of Safety Features

1. Blade guard assembly upper taping head
2. Blade guard assembly lower taping head
3. Latching Emergency stop button with mechanical lock (interrupt supply of electrical power)
4. Push the main switch STOP/OFF (O)
5. Safety guards top drive belts

### 13.6 Cleaning of Machine

#### Qualification 1

A weekly cleaning with dry rags or diluted detergents is necessary. Cardboard boxes produce a significant quantity of dust and paper chips when processed or handled in case sealing equipment. If this dust is allowed to build up on machine components, it can cause component wear and over-heating of drive motors. The dust build up is best removed from the machine with a vacuum cleaner. Depending on the number of cartons processed, this cleaning should be done weekly. Excessive build-up that cannot be removed by vacuuming should be removed with a damp cloth.

### 13.7 Cleaning of Cutter Blade

#### Qualification 2

Should tape adhesive build-up occur, carefully wipe clean with oily cloth or brush (**Figure 13-1**). Oil prevents the build-up of tape adhesive.

(See manual 2.)



## WARNING

- **To reduce the risk associated with mechanical and electrical hazards:**
  - Read, understand, and follow all safety and operating instructions before operating or servicing the case sealer.
  - Allow only properly trained and qualified personnel to operate and service this equipment.
- **To reduce the risk associated with pinches, entanglement and hazardous voltage:**
  - Turn electrical supply off and disconnect before performing any adjustments, maintenance or servicing the machine or taping heads.

### 13.6 Cleaning of Machine

#### Qualification 1

A weekly cleaning with dry rags or diluted detergents is necessary. Cardboard boxes produce a significant quantity of dust and paper chips when processed or handled in case sealing equipment. If this dust is allowed to build up on machine components, it can cause component wear and over-heating of drive motors. The dust build up is best removed from the machine with a vacuum cleaner. Depending on the number of cartons processed, this cleaning should be done weekly. Excessive build-up that cannot be removed by vacuuming should be removed with a damp cloth.

### 13.7 Cleaning of Cutter Blade

#### Qualification 2

Should tape adhesive build-up occur, carefully wipe clean with oily cloth or brush (**Figure 13-1**). Oil prevents the build-up of tape adhesive.

**Important!** Use care when working near blades as they are extremely sharp. If care is not taken, severe injury to personnel could result. Worn or damaged cutter blades must be replaced promptly in order to guarantee a perfect cut of the tape. Lubricate the felt pad on the blade guard without saturating it.

### 13.8 Lubrication

Most of the machine bearings, including the drive motor, are permanently lubricated and sealed and do not require additional lubricant.

Figures illustrate the taping head and frame points which should be lubricated every 250 hours of operation. Lubricate the rotating and pivoting points noted by the arrows with Silicone. At the same time, a small amount of Silicone should be applied to the end of each spring where the loop is secured to an eyelet (**Figures 13-2 and 13-3**).

**Note:** Wipe off excess Silicone. It will attract dust which can cause premature equipment wear and jamming. Take care that Silicone is not left on the surface of rollers around which tape is threaded, as it can contaminate the tape's adhesive.

### 13.9 Lubrication Products

- Grease; Type metal/plastic; Synthetic Silicone




Figure 13-1




Figure 13-2




Figure 13-3



**WARNING**

- **To reduce the risk associated with mechanical and electrical hazards:**
- Turn electrical supply off and disconnect before performing any adjustments, maintenance or servicing the machine or taping heads.

**13.10 Box Drive Belt Replacement**

**Note** – 3M recommends the replacement of drive belts in pairs, especially if belts are unevenly worn.

**Lower Drive Belts (Figure 13-4)**

1. Remove and retain center plate (A) and four (4) screws.
2. Remove and retain side cover (B) and fasteners.
3. Loosen, but do not remove lock nut (C).
4. Loosen tension screw (D) until all belt tension is removed.
5. Pull belt splicing pin (E) out and remove belt.
6. Place new belt over pulleys with laced splice at top. Insert splicing pin.

**Important** – Pin must not extend beyond edge of belt.


7. Adjust belt tension as explained in "Adjustments - Box Drive Belt Tension."
8. Replace side cover and center plate and secure with original fasteners.

**Upper Drive Belts (Figure 13-5)**


1. Remove and retain front cover (A) and four (4) screws.
2. Loosen, but do not remove lock nut (C).
3. Loosen tension screw (D) until all tension is removed from belt.
4. Move compression roller assembly out to full open position.
5. Remove 4 screws on side of belt guard (E) and slide belt guard out to expose belt.
6. Pull belt splicing pin (F) out and remove belt.
7. Place new belt over pulleys with laced splice at top. Insert splicing pin.

**Important** – Pin must not extend beyond edge of belt.

8. Adjust belt tension as explained in "Adjustments – Box Drive Belt Tension."
9. Replace front cover and belt guard(s) and secure with original fasteners.




**Figure 13-4 Lower Drive Belt Replacement**



**Figure 13-5 Upper Drive Belt Replacement**

### 13.11 Box Drive Belt Tension and Drive Pulley Rings

Before installing a new belt, check the orange plastic drive pulley rings for wear. If torn, broken, or worn smooth, replace the rings (**Figure 13-6**).



### WARNING


- **To reduce the risk associated with mechanical and electrical hazards:**
  - Turn electrical supply off and disconnect before performing any adjustments, maintenance or servicing the machine or taping heads.

### 13.12 Box Drive Belt Tension

The four (4) continuously moving drive belts convey boxes through the tape applying mechanism. The box drive belts are powered by an electric gear motor.

Tension adjustment of these belts may be required during normal operation. Belt tension must be adequate to positively move the box through the machine and the belts should run fully on the surface of the pulleys at each end of the frame. The idler pulleys on the infeed end are adjusted in or out to provide proper belt tension. Each belt is adjusted separately.



Belt tension is obtained by tightening the adjustment screw so that a moderate pulling force of 3.5kg [7lbs.] applied at the mid span, as shown in **Figure 13-7**, will deflect the belt 25mm [1 inch]. This will assure positive contact between the belt and the drive pulley on the discharge end of the drive assembly.



## 13-MAINTENANCE AND REPAIRS (continued)

Refer to **Figure 13-8** and **13-9** and adjust belt tension as follows:

1. Remove and retain center plate/front cover and four screws.
2. Loosen, but do not remove, M10 lock nut with a 17mm open end wrench.
3. Reset the tension on the drive belts as needed. Adjust the M8 tension screws in (clockwise) to **increase** tension or out (counterclockwise) to **decrease** tension. Tighten lock nut to secure tension setting.
4. Replace center plate/front cover and secure with original screws.





**14.1 Information for Disposal of Machine (ELV)**

The machine is composed of the following materials:

- Steel structure
- Nylon rollers
- Drive belts in PVC
- Nylon pulleys

For machine disposal, follow the regulations published in each country.

**14.2 Emergency Procedures**

In case of danger/fire:  
Disconnect plug of power cable from power supply.  
**(Figure 14-1)**

**IN CASE OF FIRE**



Use a fire extinguisher that is rated for electrical fires  
**(Figure 14-2).**

**15.1 Statement of Conformity**

Not Applicable.

**15.2 Emission of Hazardous Substances**


Nothing to report



THIS PAGE IS BLANK

# 16-TECHNICAL DIAGRAMS

## 16.1 Electric Diagram



## 16.2 Spare Parts Order

### Replacement Parts Ordering Information and Service

Refer to the first page of this instruction manual "Replacement Parts and Service Information".

#### Order parts by quoting the following information:

(Refer to the Identification Plate on the Machine)

- MACHINE MODEL
- SERIAL NUMBER
- FIGURE NO.
- POSITION
- 3M PART NO. (11 DIGITS)
- DESCRIPTION
- QUANTITY

Refer to Manual 2 for recommended taping head spare parts.

#### ***Important!***

The machine is constantly revised and improved by our designers. The spare parts catalogue is also periodically updated. It is very important that all the orders of spare parts make reference to the serial number of the machine (located on the identification plate on the machine).

The manufacturer reserves the right to modify the machine at any time without notice.

**It is suggested that the following spare parts be ordered and kept on hand.**

#### 700a

<b>Qty.</b>	<b>3M-Part Number</b>	<b>Description</b>
2	78-8070-1531-4	Belt-Drive W/Hook

**See Manual 2**

#### **Tool Kit**

A tool kit, part number TBA, is available as a stock item. The kit contains the necessary open end and hex socket wrenches for use with the metric fasteners on the case sealer. The threading tool, part number 78-8076-4726-4, contained in above kit is also available as a replacement stock item.

#### **Labels**

In the event that any labels are damaged or destroyed, they must be replaced to ensure operator safety.

**700a Adjustable Case Sealer, Type 40800  
Frame Assemblies**

**To Order Parts:**

1. Refer to first illustration, **Frame Assemblies**, for the **Figure Number** that identifies a specific portion of the machine.
2. Refer to the appropriate **Figure or Figures** to determine the parts required and the parts reference number.
3. The Parts List that follows each illustration, includes the **Reference Number, Part Number** and **Part Description** for the parts on that illustration.

**Note** – The complete description has been included for standard fasteners and some commercially available components. This has been done to allow obtaining these standard parts locally, if desired.

4. Order parts by Part Number, Part Description and Quantity required. Also include the model/machine name, machine type, and serial number that are located on the identification plate.
5. Refer to the first page of this instruction manual “**Replacement Parts and Service Information**” for replacement parts ordering information.


**Important** – Not all the parts listed are normally stocked items. Some parts or assemblies shown are available only on special order. Contact 3M/Tape Dispenser Parts to confirm item availability.

**Options and Accessories**

For additional information on the options and accessories listed below, contact your 3M Representative.

<b>Part Number</b>	<b>Option/Accessory</b>
70-0064-2997-4	Box Hold Down Attachment
78-8069-3983-7	Caster Kit Attachment
78-8069-3924-1	Conveyor Extension Attachment
78-8069-3926-6	Low Tape Sensor Kit
70-0064-4963-4	AccuGlide™ 3 Upper Taping Head - 2 inch, Type 10800
70-0064-4962-6	AccuGlide™ 3 Lower Taping Head - 2 inch, Type 10800
78-8114-0940-4	Three Flap Folder Kit
70-0064-1097-4	Tape Application Monitor
78-8095-4854-4	2-Inch Tape Edge Fold Attachment, Upper Head
78-8095-4855-1	2-Inch Tape Edge Fold Attachment, Lower Head

THIS PAGE IS BLANK



Frame  
Assemblies




Figure 2796

**700a****Figure 2796**

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
2796-1	78-8070-1536-3	Support – Guide Arm
2796-2	78-8010-7169-3	Screw – Hex Hd, M6 x 12
2796-3	26-1000-0010-3	Washer – Flat, M6
2796-4	78-8070-1537-1	Lever With Pivot
2796-5	78-8070-1538-9	Bushing
2796-6	26-1003-8816-9	Screw – Set, M5 x 6
2796-7	78-8070-1539-7	Link – Guide
2796-8	78-8017-9074-8	Washer – 15 mm, Nylon
2796-9	78-8052-6733-9	Ring – M10, Special
2796-10	78-8070-1540-5	Support – Lever
2796-11	78-8032-0382-3	Screw – Soc Hd, M5 x 16
2796-12	78-8070-1541-3	Guide Arm – Front, Right
2796-13	78-8070-1542-1	Guide Arm – Front, Left
2796-14	78-8070-1543-9	Guide Arm – Rear
2796-15	78-8076-4505-2	Screw – Set, M6 x 8
2796-16	78-8070-1544-7	Guide – Right
2796-17	78-8113-6792-5	Guide – Left, W/English Language Label
2796-19	78-8070-1546-2	Cap – Guide
2796-20	26-1003-7953-1	Screw – Soc Hd, M5 x 30
2796-21	78-8070-1547-0	Shaft - Guide
2796-22	78-8070-1548-8	Washer – 20 x 12, 5 x 1 Nylon
2796-23	26-1003-5852-7	Screw – Hex Hd, M10 x 40
2796-24	26-1004-5510-9	Washer – Plain, M10
2796-25	78-8070-1549-6	Knob – VTR-B-M10
2796-26	78-8005-5735-3	Washer – Lock, M5
2796-27	78-8032-0375-7	Screw – Hex Hd, M6 x 16




Figure 2806

700a

Figure 2806

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
2806-1	78-8076-4626-6	Compression Roller Assembly
2806-2	78-8076-4627-4	Support – Compression Roller
2806-3	78-8076-4628-2	Roller – Compression
2806-4	78-8076-4629-0	Shaft – Roller
2806-5	26-1003-5841-0	Screw – M8 x 16
2806-6	78-8017-9318-9	Washer – Plain 8 mm
2806-7	78-8076-4630-8	Plate – Tube, Roller
2806-8	78-8076-4631-6	Screw – M10 x 35
2806-9	78-8076-4632-4	Cap – Support
2806-10	78-8017-9074-8	Washer – Nylon 15 mm
2806-11	26-1004-5510-9	Washer – Plain, M10
2806-12	78-8070-1549-6	Knob – VTR-B-M10




Figure 10440

700a

Figure 10440

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
10440-1	78-8070-1564-5	Tape Roll Bracket Assembly
10440-2	78-8070-1565-2	Tape Drum Bracket Assembly
10440-3	78-8070-1566-0	Bracket – Tape Drum
10440-4	78-8070-1395-4	Bracket – Bushing Assembly
10440-5	78-8070-1568-6	Cap – Bracket
10440-6	78-8076-4519-3	Shaft – Tape Drum
10440-7	78-8017-9169-6	Nut – M18 x 1
10440-8	78-8098-8827-0	Tape Drum Sub-Assembly - 2 Inch
10440-9	78-8098-8749-6	Tape Drum
10440-10	78-8098-8817-1	Leaf Spring
10440-11	26-1002-5753-9	Screw – Self Tapping
10440-12	78-8060-8172-1	Washer – Friction
10440-13	78-8052-6271-0	Washer – Tape Drum
10440-14	78-8100-1048-4	Spring – Core Holder
10440-15	78-8017-9077-1	Nut – Self Locking, M10 x 1
10440-16	78-8032-0375-7	Screw – Hex Hd, M6 x 16
10440-17	78-8070-1215-4	Spacer – Stud
10440-18	26-1000-0010-3	Washer – Flat, M6
10440-19	78-8010-7169-3	Screw – Hex Hd, M6 x 12
10440-20	78-8060-8474-1	Tape Drum Assembly – 2 Inch Head
10440-21	26-1004-5510-9	Washer - Plain, M10
10440-22	78-8098-8816-3	Latch - Tape Drum




Figure 3433

700a

Figure 3433

Ref. No.	3M Part No.	Description
3433-1	78-8091-0309-2	Conveyor Bed Assembly
3433-2	78-8091-0310-0	Bed – Conveyor
3433-3	78-8091-0307-6	Support – Drive
3433-4	26-1003-5842-8	Screw – Hex Hd M8 x 20
3433-5	78-8017-9318-9	Washer – Plain 8 mm
3433-6	78-8076-5381-7	Leg Assembly – Inner W/Stop
3433-7	78-8076-5382-5	Leg – Inner
3433-8	78-8060-8480-8	Pad – Foot
3433-9	78-8055-0867-4	Screw – Hex Hd M8 x 30
3433-10	78-8017-9313-0	Nut – Self Locking M8
3433-11	78-8076-5383-3	Stop – Leg
3433-12	26-1003-7963-0	Screw – Soc Hd M8 x 16
3433-13	78-8060-8481-6	Label – Height
3433-14	78-8052-6677-8	Clamp – Inner
3433-15	78-8052-6676-0	Clamp – Outer
3433-16	78-8076-5392-4	Support – Tape Drum
3433-17	78-8060-8483-2	Support – Outboard Roll
3433-18	78-8060-8484-0	Shaft – Roller
3433-19	78-8060-8485-7	Roller
3433-20	78-8032-0375-7	Screw – Hex Hd M6 x 16
3433-21	26-1000-0010-3	Washer – Flat M6
3433-22	26-1003-7957-2	Screw – Soc Hd M6 x 16
3433-23	78-8076-4620-9	Plane – Conveyor Bed
3433-24	78-8060-8486-5	Bushing
3433-25	78-8010-7211-3	Screw – Soc Hd M6 x 25
3433-26	78-8060-8487-3	Cover – Switch
3433-27	78-8060-8087-1	Screw – M5 x 10
3433-28	78-8010-7417-6	Nut – Hex M5
3433-29	78-8060-8488-1	Screw – Hex Hd M5 x 20
3433-30	78-8046-8217-3	Washer – Special
3433-31	78-8005-5741-1	Washer – Flat M5
3433-32	78-8076-4701-7	Cap – /28
3433-35	78-8098-9076-3	Caster
3433-36	26-1009-9096-4	Caster – Dual Locking
3433-37	26-1009-9094-9	Washer – Spring, Helical, M12
3433-38	26-1009-9095-6	Nut – M12




Figure 3434

Figure 3434

Ref. No.	3M Part No.	Description
3434-1	78-8060-8489-9	Column – Outer
3434-2	78-8060-8490-7	Plate – Column Mounting
3434-3	26-1003-7964-8	Screw – Soc Hd Hex Soc Dr, M8 x 20
3434-4	78-8017-9318-9	Washer – Plain 8 mm
3434-5	78-8060-8491-5	Cap – Column
3434-6	26-1002-4955-1	Screw – Self Tap 8P x 13
3434-7	78-8005-5740-3	Washer – Plain 4 mm
3434-8	78-8060-8492-3	Stop – Height
3434-9	78-8076-5482-3	Plate – Nut Stop
3434-10	78-8060-8087-1	Screw – M5 x 10
3434-11	78-8060-8494-9	Column Assembly – Inner
3434-12	78-8060-8495-6	Column – Inner
3434-13	78-8054-8617-8	Bearing – Special
3434-14	78-8054-8589-9	Screw – Special
3434-15	26-1003-6916-9	Nut – Locking, Plastic Insert M6
3434-16	78-8060-8496-4	Lead Screw
3434-17	78-8054-8997-4	Spring
3434-18	78-8054-8970-1	Bed Plate – Spring
3434-19	78-8054-8571-7	Nut – Plastic
3434-20	78-8054-8968-5	Nut – Special
3434-21	78-8054-8585-7	Collar
3434-22	78-8054-8586-5	Pin
3434-23	78-8054-8584-0	Spacer
3434-24	78-8054-8583-2	Bushing
3434-25	78-8060-8497-2	Bushing – Lead Screw
3434-26	78-8059-5617-0	Set Screw – M6 x 8
3434-27	78-8060-8498-0	Bushing – Inner Column
3434-28	78-8060-8499-8	Sprocket – 3/8" Z = 13
3434-29	26-1003-7946-5	Screw – Soc Hd M4 x 25
3434-30	78-8070-1501-7	Chain – 3/8" P = 156
3434-31	78-8113-6755-2	Housing – Chain, W/English Language Label
3434-32	78-8060-7878-4	Idler Screw
3434-33	78-8070-1503-3	Roller – Chain Tensioning
3434-34	78-8042-2919-9	Washer – Triple M6
3434-35	26-1003-5829-5	Screw – Hex Hd M6 x 12
3434-36	26-1000-0010-3	Washer – Flat M6
3434-37	78-8070-1504-1	Cover
3434-38	78-8010-7157-8	Screw – Hex Hd M4 x 10
3434-39	78-8070-1505-8	Cap – Inner Column
3434-40	78-8070-1506-6	Cover – Screw
3434-41	78-8076-4807-2	Crank Assembly
3434-42	78-8076-5422-9	Crank
3434-43	78-8070-1509-0	Shaft – Crank
3434-44	26-1005-5316-8	Screw – Flat Hd Hex Dr M5 x 16
3434-45	78-8070-1510-8	Washer – Nylon
3434-46	78-8070-1511-6	Bushing
3434-47	78-8070-1512-4	Knob – VTR-B-M12
3434-48	78-8076-4800-7	Washer – Crank
3434-49	78-8076-4809-8	Washer – Crank
3434-50	78-8076-4821-3	Key – Stop
3434-51	78-8054-8821-6	End Cap
3434-52	26-1004-5507-5	Washer – M8




Figure 15234 / 1

700a

Figure 15234 / 1

Ref. No.	3M Part No.	Description
15234-1	78-8100-1128-4	Drive Assembly – BTM, W /O Motor
15234-2	78-8070-1580-1	Frame – Drive
15234-3	78-8070-1514-0	Spacer
15234-4	26-1003-5829-5	Screw – Hex Hd, M6 x 12
15234-7	78-8052-6710-7	Roller – Idler
15234-8	78-8052-6709-9	Washer – Special
15234-9	78-8010-7435-8	Washer – Lock M6
15234-10	26-1003-7957-2	Screw – Soc Hd M6 x 16
15234-11	78-8070-1518-1	Spacer – Shaft
15234-12	26-1003-6918-5	Nut – Hex Plastic Insert M10
15234-13	78-8070-1519-9	Screw – Soc Hd, Hex Hd, M8 x 70
15234-14	78-8017-9318-9	Washer – Plain, 8 mm
15234-15	78-8070-1520-7	Guide – Drive Belt
15234-16	26-1005-4757-4	Screw – Flat Hd, Soc Dr, M x 20
15234-17	78-8137-0938-9	Support – Gearbox
15234-18	26-1003-7964-8	Screw – Soc Hd, Hex Soc Dr, M8 x 20
15234-19	78-8070-1522-3	Gearmotor – 115V, 60HZ
15234-20	78-8076-4515-1	Capacitor – 115V Gearmotor
15234-21	78-8070-1523-1	Screw – 1/4-28 x 1/2 SHCS
15234-22	78-8042-2919-9	Washer – Triple
15234-23	78-8137-0936-3	Sprocket – 3/8 ", Z=17
15234-24	78-8137-0940-5	Screw – Set W/End Cup, M6 x 10
15234-25	78-8070-1526-4	Cover – Chain
15234-26	78-8010-7209-7	Screw – Soc Hd, M6 x 12
15234-27	26-1000-0010-3	Washer – Flat M6







Figure 15234 / 2

700a

Figure 15234 / 2

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
15234-28	78-8076-4562-3	Cover – Bottom
15234-29	26-1003-5820-4	Screw – Hex Hd, M5 x 12
15234-30	78-8005-5741-1	Washer – Flat, M5
15234-31	78-8070-1527-2	Shaft – With Drive Pulleys
15234-32	78-8070-1528-0	Shaft – Gearbox
15234-33	78-8057-5811-3	Key – 6 x 6 x 20 mm
15234-34	78-8054-8986-7	Sprocket – 3/8" Pitch 28 Teeth
15234-35	78-8054-8984-2	Bushing
15234-36	78-8070-1529-8	Support – Shaft
15234-37	78-8070-1530-6	Bearing – 6205-2RS
15234-38	78-8057-5739-6	Key – M5 x 5 x 30 mm
15234-39	78-8076-5105-0	Pulley Assembly – Drive
15234-40	78-8052-6713-1	Ring – Polyurethane
15234-41	78-8060-8416-2	Nut – Special M20 x 1
15234-42	78-8054-8987-5	Chain – 3/8" P=57
15234-43	78-8070-1531-4	Belt – Drive With Hook
15234-44	78-8070-1584-3	Cover – Drive, Front
15234-45	78-8113-6794-1	Cover – Drive, Rear, W/English Language Label
15234-46	26-0001-5862-1	Screw – Flat Hd Soc, M5 x 12
15234-47	26-1005-5316-8	Screw – Flat Hd, Hex Dr, M5 x 16
15234-48	78-8070-1534-8	Stud – Side Plate
15234-49	78-8060-8488-1	Screw – Hex Hd, M5 x 20
15234-50	26-1003-5841-0	Screw – M8 x 16
15234-51	78-8076-4500-3	Stud – Mounting
15234-52	78-8076-4715-7	Cord Grip
15234-53	78-8076-5211-6	Set Nut – GMP 113.5
15234-54	78-8060-7885-9	End Cap – /25 x 1,2
15234-55	78-8100-1236-5	Belt Tensioning Assembly – R/H
15234-56	78-8100-1237-3	Belt Tensioning Assembly – L/H
15234-57	78-8100-1238-1	Belt Tensioning – R/H
15234-58	78-8100-1239-9	Belt Tensioning – L/H




Figure 15235 / 1

Figure 15235 / 1

Ref. No.	3M Part No.	Description
15235-1		Upper Drive Assembly – W /O Motor
15235-2	78-8070-1588-4	Frame – Drive, Upper
15235-3	78-8070-1520-7	Guide – Drive Belt
15235-4	26-1005-4757-4	Screw – Flat Hd M5 x 20
15235-5	78-8070-1589-2	Clamp – Upper Head
15235-6	78-8070-1590-0	Shaft – Roller
15235-7	26-1003-7948-1	Screw – Soc Hd M5 x 10
15235-8	78-8070-1514-0	Spacer
15235-9	78-8010-7169-3	Screw – Hex Hd M6 x 12
15235-10	26-1000-0010-3	Washer – Flat M6
15235-11	78-8100-1130-0	Tube – Roller
15235-12	78-8052-6641-4	Roller
15235-13	78-8070-1592-6	Spacer – Roller
15235-14	78-8100-1131-8	Shaft – Roller
15235-15	78-8100-1132-6	Nut – Special, M8
15235-16	78-8017-9318-9	Washer – Plain 8 mm
15235-17	78-8060-7693-7	Roller – 32 x 38
15235-18	78-8070-1593-4	Spacer – Roller
15235-19	26-1003-5820-4	Screw – Hex Hd, M5 x 12
15235-20	78-8005-5741-1	Washer – Flat, M5
15235-21	78-8070-1599-1	Tube – Compression Roller
15235-22	78-8052-6652-1	Cap – End
15235-23	26-1003-5841-0	Screw – M8 x 16
15235-26	78-8052-6710-7	Roller – Idler
15235-27	78-8052-6709-9	Washer – Special
15235-28	78-8010-7435-8	Washer – Lock M6
15235-29	26-1003-7957-2	Screw – Soc Hd M6 x 16
15235-30	78-8070-1518-1	Spacer – Shaft
15235-31	26-1003-6918-5	Nut – Hex Plastic Insert M10
15235-32	78-8070-1594-2	Screw – Hex Hd M8 x 60
15235-33	78-8070-1527-2	Shaft – With Drive Pulleys
15235-34	78-8070-1528-0	Shaft – Gearbox




Figure 15235 / 2

Figure 15235 / 2

Ref. No.	3M Part No.	Description
15235-35	78-8057-5811-3	Key – 6 x 6 x 20 mm
15235-36	78-8054-8986-7	Sprocket – 3/8" Pitch 28 Teeth
15235-37	78-8054-8984-2	Bushing
15235-38	78-8070-1529-8	Support – Shaft
15235-39	78-8070-1530-6	Bearing – 6205-2RS
15235-40	78-8057-5739-6	Key – M5 x 5 x 30 mm
15235-41	78-8076-5105-0	Pulley Assembly – Drive
15235-42	78-8052-6713-1	Ring – Polyurethane
15235-43	78-8060-8416-2	Nut – Special, M20 x 1
15235-44	78-8137-0939-7	Support – Drive
15235-45	26-1003-5842-8	Screw – Hex Hd, M8 x 20
15235-46	78-8070-1522-3	Gearmotor – 115V, 60HZ
15235-47	26-1011-8828-7	Capacitor – 115V Gearmotor
15235-48	78-8137-0936-3	Sprocket – 3/8" Z=17
15235-49	78-8137-0940-5	Set Screw – W/End Cup M6 x 10
15235-50	78-8070-1523-1	Screw – 1/4-28 x 1/2 SHCS
15235-51	78-8042-2919-9	Washer – Triple, M6
15235-52	78-8137-0937-1	Chain – 3/8" P=65
15235-53	78-8070-1598-3	Cover
15235-54	26-1002-4955-1	Screw – Self Tap 8P x 13
15235-55	78-8005-5740-3	Washer – Plain 4 mm
15235-56	78-8070-1596-7	Union – Elbow, PG 13,5
15235-57	78-8076-4622-5	Cover – Rear Upper
15235-58	78-8060-8087-1	Screw – M5 x 10
15235-59	78-8070-1531-4	Belt – Drive, With Hook
15235-60	78-8113-6791-7	Cover – Upper, Front, W/English Language Label
15235-61	78-8113-6790-9	Guard – Belt, R/H, W/English Language Label
15235-62	78-8113-6789-1	Guard – Belt, L/H, W/English Language Label
15235-63	78-8076-4625-8	Screw – Special, M5 x 16
15235-64	78-8076-4702-5	Grommet – /28
15235-65	78-8054-8821-6	End – Cap
15235-66	78-8076-4500-3	Stud – Mounting
15235-67	78-8100-1042-7	Washer – /15 x 6.35 x 2
15235-68	78-8100-1236-5	Belt Tensioning Assembly – R/H
15235-69	78-8100-1237-3	Belt Tensioning Assembly – L/H
15235-70	78-8100-1238-1	Belt Tensioning – R/H
15235-71	78-8100-1239-9	Belt Tensioning – L/H




Figure 5669

700a

Figure 5669

Ref. No.	3M Part No.	Description
5669-1	78-8091-0660-8	Housing – Wire
5669-2	78-8076-4702-5	Grommet – /28
5669-3	26-1003-7963-0	Screw – Soc Hd M8 x 16
5669-4	78-8076-4636-5	Strap – Wire
5669-5	78-8010-7163-6	Screw – Hex Hd M5 x 10
5669-6	78-8005-5741-1	Washer – Plain M5
5669-7	78-8010-7417-6	Nut – Hex M5
5669-8	78-8100-1135-9	Bracket – Strap
5669-9	78-8076-4520-1	Union PG13 – Sleeve /16
5669-10	78-8076-4521-9	Sleeving – Wire, 900 mm /16
5669-11	78-8076-4638-1	Union PG 13.5 – Sleeve /14
5669-12	78-8076-4640-7	Sleeving – Wire, 11 mm /14
5669-13	78-8060-8029-3	Clamp – 140 x 3,5
5669-14	78-8076-4641-5	Cover
5669-15	78-8010-7157-8	Screw – Hex Hd M4 x 10
5669-16	78-8017-9018-5	Washer – Plain M4




Figure 5670

700a

Figure 5670

Ref. No.	3M Part No.	Description
5670-1	78-8094-6379-3	Support – Box
5670-2	78-8113-6759-4	Box – W/English Language Label
5670-3	78-8094-6381-9	Screw – Soc Hd, Hex Hd, M4 x 15
5670-4	78-8005-5740-3	Washer – Plain, 4 mm
5670-5	26-1003-6914-4	Nut – Plastic Insert, M4
5670-6	78-8076-4715-7	Cord Grip
5670-7	78-8076-5211-6	Set Nut – GMP 13.5
5670-9	78-8094-6382-7	Guide – Mounting
5670-10	78-8028-8208-0	Screw – 6P x 9,5
5670-11	78-8017-9018-5	Washer – Plain, M4
5670-12	78-8094-6383-5	Contactora – Allen Bradley 110V, 60HZ
5670-13	78-8076-5378-3	Circuit Breaker-Allen Bradley 1.6 – 2.5A
5670-14	78-8094-6384-3	Ground Clamp – VGPE 4/6
5670-15	78-8076-4968-2	Terminal
5670-16	78-8028-7909-4	Power Cord – U.S.A.
5670-17	78-8076-5176-1	Cable – FROR 07 3X0.75, 5 Mt
5670-18A	78-8076-5273-6	Cable – 3X1, 5Mt
5670-18B	78-8060-8052-5	Cable – 4X1.5 5Mt 3 Ph
	78-8091-0433-0	Cable – 3X1.5 1 Ph, 5 Mt
5670-19	26-1003-7957-2	Screw – Soc Hex Hd, M6 x 16
5670-20	26-1000-0010-3	Washer – Flat, M6
5670-21	78-8076-5194-4	Box – E-Stop, Yellow
5670-22	78-8094-6386-8	Switch – On/Off, DM3N-C-01/10
5670-23	78-8100-1039-3	Support – On/Off Switch
5670-24	78-8017-9257-9	Screw – Phillips Head, M4 x 10
5670-25	78-8060-8087-1	Screw – M5 x 10
5670-26	78-8010-7417-6	Nut – Hex, M5
5670-27	26-1014-5845-8	E-Stop – 800EM-MTS644-3LX01
5670-28	78-8091-0538-6	Screw – Hex Hd, M4 x 25
5670-29	78-8076-4716-5	Star Washer – M4
5670-30	78-8010-7416-8	Nut – Hex, M4
5670-31	78-8100-1234-0	Collar
5670-32	78-8114-4896-4	Box – On/Off, Grey

THIS PAGE IS BLANK



## Instructions and Parts List

**3M-Matic**<sup>™</sup>

**Accuglide**<sup>™</sup> **3**

**Upper and**

**Lower**

**High Speed**

**Taping Heads**

**2 Inch**

**Type 10800**

Serial No. \_\_\_\_\_

For reference, record taping head(s) serial number(s) here.



**3M Industrial Adhesives and Tapes**

3M Center, Building 220-5E-06  
St. Paul, MN 55144-1000



### Important Safety Information

BEFORE INSTALLING  
OR OPERATING THIS  
EQUIPMENT

Read, understand, and  
follow all safety and  
operating instructions.

### Spare Parts

It is recommended you  
immediately order the  
spare parts listed in the  
"Spare Parts/Service  
Information" section.

These parts are expected  
to wear through normal  
use, and should be kept  
on hand to minimize  
production delays.

AccuGlide™ is a Trademark of  
3M, St. Paul, MN 55144-1000  
Printed in U.S.A.

© 3M 2012 44-0009-2070-0 (E010712-NA)



---

## Replacement Parts and Service Information

---

### To Our Customers:

This is the 3M-Matic™/AccuGlide™/Scotch® equipment you ordered. It has been set up and tested in the factory with Scotch® tapes. If technical assistance or replacement parts are needed, call or fax the appropriate number listed below.

Included with each machine is an Instructions and Parts List manual.

### Technical Assistance / Replacement Parts and Additional Manuals:

Call the 3M-Matic™ Help line at 1-800 328-1390. Provide the customer support coordinator with the model/machine name, machine type, and serial number that are located on the identification plate (For example: Model 200a - Accuglide 3 - 2 inch - Type 10800 - Serial Number 13282).

#### United States -

3M Tape Dispenser Parts

241 Venture Drive

1-800-344-9883

Amery, WI 54001-1325

Fax: 1-715-268-8153

#### Identification Plate

	3M Company St. Paul, MN 55144 USA	Part Number <input type="text"/>	<b>3M-Matic™</b>			
Model <input type="text"/>		Year <input type="text"/>	Ampere <input type="text"/>	Watt <input type="text"/>		
Type <input type="text"/>	Serial Number <input type="text"/>	Volt <input type="text"/>	Hertz <input type="text"/>	Phase <input type="text"/>		

Minimum billing on parts orders will be \$25.00. Replacement part prices available on request.  
\$10.00 restocking charge per invoice on returned parts

Note : Outside the U.S., contact the local 3M subsidiary for parts ordering information.



#### 3M Industrial Adhesives and Tapes

3M Center, Building 220-5E-06  
St. Paul, MN 55144-1000

3M-Matic™, AccuGlide™ and Scotch™  
are Trademarks of  
3M St. Paul, MN 55144-1000  
Printed in U.S.A.

THIS PAGE IS BLANK

## Replacement Parts And Service Information

---


To Our Customers:

This is the 3M-Matic™/AccuGlide™/Scotch® equipment you ordered. It has been set up and tested in the factory with Scotch® tapes. If any problems occur when operating this equipment and you desire a service call or phone consultation, call, write, or fax the appropriate number listed below.

Included with each machine is an Instructions and Parts List manual.

### SERVICE, REPLACEMENT PARTS, AND ADDITIONAL MANUALS

AVAILABLE DIRECT FROM:



Order parts by part number, part description, and quantity required. Also, when ordering parts or additional manuals, include model/machine name, machine type, and serial number that are located on the identification plate.



**3M Industrial Adhesives and Tapes**

3M Center, Building 220-5E-06  
St. Paul, MN 55144-1000

3M-Matic™, AccuGlide™ and Scotch™  
are Trademarks of  
3M, St. Paul, MN 55144-1000  
Printed in U.S.A.

THIS PAGE IS BLANK

# Instruction Manual

## AccuGlide™ 3 High Speed 2 Inch Upper and Lower Taping Heads Type 10800

<b>Table of Contents</b>	<b>Page</b>
Replacement Parts and Service Information .....	i - ii
Table of Contents.....	iii
Equipment Warranty and Limited Remedy.....	iv
Intended Use .....	1
Taping Head Contents / How to Use Manual.....	3
Important Safeguards.....	4 - 5
Specifications .....	6 - 7
Dimensional Drawing .....	7
Installation .....	8
Receiving and Handling .....	8
Installation Guidelines.....	8
Tape Leg Length .....	8
Tape Width Adjustment .....	8
Operation.....	9 - 11
Tape Loading – Upper Taping Head.....	10
Tape Loading – Lower Taping Head.....	10 - 11
Maintenance .....	12 - 13
Blade Replacement.....	12
Blade Guard .....	12
Blade Oiler Pad .....	12
Cleaning.....	13
Applying/Buffering Roller Replacement.....	13
Adjustments.....	14 - 16
Tape Latch Alignment.....	14
Tape Drum Friction Brake .....	14
Applying Mechanism Spring.....	15
One-Way Tension Roller .....	15
Tape Leg Length .....	16
Leading Tape Leg Length Adjustment .....	16
Changing Tape Leg Length From 70 to 50 mm [2-3/4 to 2 Inch] .....	16
Troubleshooting Guide .....	17 - 18
Spare Parts/Service Information.....	19
Recommended Spare Parts.....	19
Replacement Parts and Service.....	19
Replacement Parts Illustrations and Parts List.....	Yellow Section 20 - 37

## Warranty

---

### Equipment Warranty and Limited Remedy:

**Equipment Warranty and Limited Remedy: THE FOLLOWING WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE AND ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM OR USAGE OF TRADE:**

3M sells its **AccuGlide™ 3 High Speed 2 Inch Upper and Lower Taping Heads, Type 10800** with the following warranty:

1. The Taping Head blade, springs and rollers will be free from defects in material and manufacture for ninety (90) days after delivery.
2. All other Taping Head parts will be free from defects in material and manufacture for three (3) years after delivery.

If any part is defective within this warranty period, your exclusive remedy and 3M's and seller's sole obligation shall be, at 3M's option, to repair or replace the part. 3M must receive actual notice of any alleged defect within a reasonable time after it is discovered, but in no event shall 3M have any obligation under this warranty unless it receives such notice within five (5) business days after the expiration of the warranty period. All notices required hereunder shall be given to 3M solely through the 3M-Matic™ Help line (800-328-1390). To be entitled to repair or replacement as provided under this warranty, the part must be returned as directed by 3M to its factory or other authorized service station designated by 3M. If 3M is unable to repair or replace the part within a reasonable time after receipt thereof, 3M, at its option, will replace the equipment or refund the purchase price. 3M shall have no obligation to provide or pay for the labor required to remove any part or equipment or to install the repaired or replacement part or equipment. 3M shall have no obligation to repair or replace those parts failing due to normal wear, inadequate or improper maintenance, inadequate cleaning, non-lubrication, improper operating environment, improper utilities, operator error or misuse, alteration or modification, mishandling, lack of reasonable care, or due to any accidental cause.

**Limitation of Liability:** Except where prohibited by law, 3M and seller will not be liable for any loss or damage arising from this 3M equipment, whether direct, indirect, special, incidental, or consequential, regardless of the legal theory asserted, including breach of warranty, breach of contract, negligence, or strict liability.

**Note:** The foregoing Equipment Warranty and Limited Remedy and Limitation of Liability may be changed only by a written agreement signed by authorized representatives of 3M and seller.

**AccuGlide™, Scotch™, and 3M-Matic™** are Trademarks of 3M, St. Paul, Minnesota 55144-1000

---


## Intended Use

---

The intended use of the AccuGlide™ 3 Upper and Lower Taping Heads - 2 Inch is to apply a "C" clip of Scotch® pressure-sensitive film box sealing tape to the top and/or bottom center seam of regular slotted containers.

These taping heads are incorporated into most standard 3M-Matic™ case sealers. The compact

size and simplicity of the taping head also makes it suitable for mounting in box conveying systems other than 3M-Matic™ case sealers. This includes replacement of other types of taping, gluing or stapling heads in existing case sealing machines. The AccuGlide™ 3 Upper and Lower Taping Heads - 2 Inch have been designed and tested for use with Scotch® pressure-sensitive film box sealing tape.



**AccuGlide™ 3 Upper Taping Head - 2 inch, Type 10800**

THIS PAGE IS BLANK

---

## Taping Head Contents

---

**AccuGlide™ 3 High Speed 2 Inch Upper and Lower Taping Heads consist of:**

<b>Qty.</b>	<b>Part Name</b>
1	Taping Head Assembly
1	Tape Drum and Bracket Assembly
1	Hardware and Spare Parts Kit
1	Threading Tool

---

## General Information

---

This instruction manual covers safety aspects, handling and transport, storage, unpacking, preparation, installation, operation, set-up and adjustments, technical and manufacturing specifications, maintenance, troubleshooting, repair work and servicing, electric diagrams, warranty information, disposal (ELV), a glossary with a definition of symbols, plus a parts list of the 3M-Matic™ Accuglide 3 (2 inch) 3M Industrial Adhesives and Tapes Division 3M Center, Bldg. 220-5E-06 St. Paul, MN 55144-1000 (USA) Edition January 2012/Copyright 3M 2012. All rights reserved The manufacturer reserves the right to change the product at any time without notice.

---

## How to use this Manual

---

The manual is an important part of the machine; all information contained herein is intended to enable the equipment to be maintained in perfect condition and operated safely. Ensure that the manual is available to all operators of this equipment and the manual is kept up to date with all subsequent amendments. Should the equipment be sold or disposed of, please ensure that the manual is passed on with the machine.

Electrical and pneumatic diagrams are included in the manual. Equipment using PLC controls and/or electronic components will include relevant schematics or programs in the enclosure (or will be delivered separately as needed)

Keep the manual in a clean and dry place near the machine. Do not remove, tear or rewrite parts of the manual for any reason. Use the manual without damaging it. However, if the manual has been lost or damaged, ask your after sale service for a new copy (if it is possible, please have the manual name, part number, and revision information and/or model/machine name, machine type, and serial number) that are located on the identification plate **(For example: Model 200a - Accuglide 3 - 2" - Type 10800 - Serial Number 13282).**

**Note:**

All the important warning notes related to the operation of the machine are identified by the symbol:



## Updating the Manual

Modifications to the machine are subject to manufacturer's internal procedures. The user may receive pages or parts of the manual which contain amendment made after its first publication. The user must use them to update this manual.

---

## Important Safeguards

---



This safety alert symbol identifies important safety messages in this manual. **READ AND UNDERSTAND THEM BEFORE INSTALLING OR OPERATING THIS EQUIPMENT.**

### Explanation of Signal Word Consequences



**CAUTION:** Indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury and/or property damage.



**WARNING:** Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury and/or property damage.



## WARNING

- **To reduce the risk associated with mechanical hazards:**
  - Read, understand and follow all safety and operating instructions before operating or servicing the case sealer
  - Allow only properly trained and qualified personnel to operate and/or service this equipment
- **To reduce the risk associated with shear, pinch, and entanglement hazards:**
  - Turn air and electrical supplies off on associated equipment before performing any adjustments, maintenance, or servicing the taping heads
  - Never attempt to work on the taping head or load tape while the box drive system is running
- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.




## CAUTION

- **To reduce the risk associated with muscle strain:**
  - Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift
- **To reduce the risk associated with impact hazards:**
  - Place the taping head on a smooth level surface when maintaining or servicing this equipment

(Important Safeguards continued on next page)

**Important Safeguards** (continued)

**Important** - In the event the following safety labels are damaged or destroyed, they must be replaced to ensure operator safety. See "Replacement Parts Illustrations and Parts Lists" for label part numbers.



**Figure 1-1 Replacement Labels/3M Part Numbers**

---

## Specifications

---

1. **Tape:**

For use with Scotch® pressure-sensitive film box sealing tapes.

2. **Tape Width:**

36mm or 1-1/2 inches minimum to 48mm [2 inches] maximum.

3. **Tape Roll Diameter:**

Up to 405mm [16 inches] maximum on a 76.2mm [3 inch] diameter core.  
(Accommodates all system roll lengths of Scotch® film tapes.)

4. **Tape Application Leg Length - Standard:**

70mm ± 6mm [2-3/4 inches ± 1/4 inch]

**Tape Application Leg Length - Optional:**

50mm ± 6mm [2 inches ± 1/4 inch] (See "Adjustments – Tape Leg Length.")

5. **Box Size Capacities:**

For use with center seam regular slotted containers.

Length – 443mm [17.44 inches] w/ Guard

Height – 406mm [16 inches] w/ Guard

Width – 107mm [4.2 inches]

When upper and lower taping heads are used on “**3M-Matic**” case sealers, refer to the respective instruction manual specifications for box weight and size capacities.

6. **Operating Rate:**

Conveyor speeds up to 0.5 m/s [100 feet per minute].

7. **Operating Conditions:**

Use in dry, relatively clean environments at 5° to 40°C [40° to 105°F] with clean dry boxes.


**Important** – Taping heads should not be washed down or subjected to conditions causing moisture condensation on components.

8. **Taping Head Dimensions:**

Length	–	442mm [17 3/8 inches]
Height	–	648mm [25 1/2 inches] (with tape drum)
Width	–	105mm [4-1/8 inches] (without mounting spacers)
Weight	–	Packaged: 8.6kg [19 lbs.] Unpackaged: 7.7kg [17 lbs.]

(Specifications continued on next page.)

Specifications



\* This dimension can be reduced to 90mm [3-1/2 in.] when both heads are converted to 50mm [2 in.] tape leg lengths.

Figure 2/1 Dimensional Drawing

## Installation



### WARNING

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards.  
The blades are extremely sharp

### Receiving And Handling

After the taping head assembly has been unpackaged, examine the unit for damage that might have occurred during transit. If damage is evident, file a damage claim immediately with the transportation company and also notify your 3M Representative.

### Installation Guidelines

The taping head assembly can be used in converting existing or in custom made machinery. It can be mounted for top taping or bottom taping. Refer to "Box Size Capacities," as well as **Figure 2-1** in the Specifications section, for the following points in making such installations:



### CAUTION

- **To reduce risk associated with muscle strain:**
  - Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift

**Important** – Always conduct a hazard review to determine appropriate guarding requirements when the installation is in an application other than 3M-Matic™ equipment

1. The box conveying system must positively propel the box in a continuous motion, not exceeding 0.40 m/s [80 feet per minute], past the taping head assembly since the box motion actuates the taping mechanism.
2. If a pusher or cleated conveyor is being used, steps should be taken in the conveyor design to prevent the pusher from contacting the applying or buffing roller arms resulting in damage to the taping head.

3. **Figure 2-1** illustrates the typical mounting relationship for opposing taping head assemblies to allow taping of box heights down to 90mm [3-1/2 inches]. To tape box heights down to 70mm [2-3/4 inches], the taping heads must be completely staggered so only one tape seal is being applied at one time.

**Note**—AccuGlide™ 3 High Speed Upper Taping Head is supplied with a buffing arm guard. Adjustments to this guard may be required to install the taping head into some older design 3M-Matic™ case sealers.

4. Mounting studs are provided with the taping head, but special installations may require alternate means for mounting.
5. Box hold-down or guide skis should be provided and the taping head mounted so that the side plates are 6mm [1/4 inch] maximum away from the ski surface on which the box rides.

### Tape Leg Length

Taping heads are factory set to apply standard 70mm [2-3/4 inch] tape legs. The heads can be converted to apply 50mm [2 inch] tape legs if desired but both upper and lower heads must be set to apply the same tape leg length. See "Adjustments – Changing Tape Leg Length From 70 to 50mm [2-3/4 to 2 Inches]."

Also, the conveyor speed at which the product moves through the taping heads, affects the leading and trailing tape leg length. See "Adjustments section – Leading Tape Leg Length Adjustment."

### Tape Width Adjustment

Taping heads are factory set to apply 48mm [2 inch] wide tape. If it is necessary to align the tape or to apply narrower tapes, refer to "Adjustments – Tape Web Alignment" for set-up procedure.

Operation




Figure 3-1 Taping Head Components/Threading Diagram - Upper Head (Left Side) View




Figure 3-2 Taping Head Components/Threading Diagram - Lower Head (Left Side) View



## WARNING

- **To reduce the risk associated with shear, pinch, and entanglement hazards:**
  - Turn air and electrical supplies off on associated equipment before performing any adjustments, maintenance, or servicing the machine or taping heads
  - Never attempt to work on the taping heads or load tape when the box drive system is running
- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards.  
The blades are extremely sharp

It is recommended that the detailed instructions and sketches in this manual be referred to the first few times the taping head is loaded/threaded until the operator becomes thoroughly familiar with the tape loading operation.

**Note** – Remove tape roll before removing taping head from machine to minimize weight.



## CAUTION

- **To reduce the risk associated with muscle strain:**
  - Use proper body mechanics when removing or installing taping heads that are moderately heavy or may be considered awkward to lift
- **To reduce the risk associated with impact hazards:**
  - Place the taping head on a smooth level surface when maintaining or servicing this equipment

### Tape Loading – Upper Taping Head

1. Place the upper taping head in a convenient working position.
2. Use **Figures 3-3 to 3-5** and tape threading label. Position the tape supply roll so the adhesive side of tape is facing the front of the taping head as it is pulled from the supply roll.
3. Attach the threading needle to the end of the roll. Guide the threading needle around the wrap roller (Position 1) then back around the one-way tension roller (Position 2).
4. Continue pulling the threading needle down and guide it between the two rollers on the apply arm (Position 3).

5. Pull the threading needle down until the tape travels between the apply plate and the ears of the apply arm (Position 4) until it extends past the applying roller. When properly threaded the adhesive side of the tape should be facing the knurled rollers at position 2 and also position 3.
6. Cut away any excess tape.


**Important** – Do not cut against the apply roller - roller damage could occur.

### Tape Loading – Lower Taping Head

1. Remove the lower taping head from the conveyor bed or associated equipment and place it a convenient working position.
2. The lower taping head is loaded and threaded in the same manner as the upper head. Follow the upper taping head tape loading/threading procedure.

**Figure 3-3**


Insert threading needle through rollers in direction indicated by arrows.



**Figure 3-3 – Tape Loading/Threading**

**Figure 3-4**

Place tape roll on tape drum to dispense tape with adhesive side forward. Seat tape roll fully against back flange of drum. Adhere tape lead end to threading needle as shown.




**WARNING**

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

Manually turn tape roll to create slack tape while pulling threading needle through tape applying mechanism until needle is through and tape is in alignment with applying roller.

Excess tape can be cut with a scissors at applying roller.





## WARNING

- **To reduce the risk associated with shear, pinch, and entanglement hazards:**
  - Turn air and electrical supplies off on associated equipment before performing any adjustments, maintenance, or servicing the taping heads
  - Never attempt to work on the taping head or load tape while the box drive system is running
- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp

The AccuGlide™ 3 High Speed 2 Inch Taping Head has been designed for long, trouble free service. The taping head will perform best when it receives routine maintenance and cleaning. Taping head components that fail or wear excessively should be promptly repaired or replaced to prevent damage to other portions of the head or to the product.

### Blade Replacement, Upper and Lower Taping Heads – Figure 4-1



## WARNING

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

1. Loosen, but do not remove, the blade screws (A). Remove and discard old blade.
2. Mount the new blade (B) with the beveled side away from the blade holder.




Figure 4-1 – Blade Replacement

3. Bottom the blade slots against the screws. (This will position the blade at the correct angle.) Tighten the blade screws to secure the blade.

**Note** – Check the blade position to insure proper clearance between blade and guard by slowly pivoting the blade guard back.

### Blade Guard

The blade guard covers the blade whenever a box is not being taped. Periodically check to be sure the blade guard is functioning properly and returning to cover the blade. Replace any defective parts.

### Blade Oiler Pad



## WARNING

- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

To reduce adhesive build-up, the taping heads are equipped with a factory pre-lubricated felt oiler pad that provides a film of oil on the cutting edge of the blade. Blade maintenance should include keeping the felt oiler pad saturated with SAE #30 non-detergent oil.

Should tape adhesive build-up occur on blade, carefully wipe clean with an oily cloth.

(Maintenance continued on next page.)



## WARNING

- **To reduce the risk associated with shear, pinch, and entanglement hazards:**
  - Turn air and electrical supplies off on associated equipment before performing any adjustments, maintenance, or servicing the taping heads
  - Never attempt to work on the taping head or load tape while the box drive system is running
- **To reduce the risk associated with sharp blade hazards:**
  - Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp

### Cleaning


Regular slotted containers produce a great deal of dust and paper chips when conveyed through taping heads. If this dust is allowed to build-up on the heads, it can cause wear on the moving parts. Excessive dirt build-up should be wiped off with a damp cloth. Cleaning should be done once per month, depending on the number and type of boxes used. If the boxes used are dirty, or if the environment in which the heads operate is dusty, cleaning on a more frequent basis may be necessary.

**Note** – Never attempt to remove dirt from taping heads by blowing it out with compressed air. This can cause the dirt to be blown inside the components onto sliding surfaces. Dirt in these areas can cause serious equipment damage. Never wash down or subject taping heads to conditions causing moisture condensation on components. Serious equipment damage could result.

### Applying/Buffering Roller Replacement

Replacing roller requires removal of shaft and mounting screws. With no area on the shaft to grip, the shaft often turns when attempting to remove the second screw.

To ease removal of second screw, a 5mm hex socket has been provided at the bottom of the threads in both ends of the shaft. Insert a 4mm hex key wrench into this socket after removing one screw to hold the shaft for removal of the second screw. See **Figure 4-2**.





**WARNING**

- To reduce the risk associated with shear, pinch, and entanglement hazards:
  - Turn air and electrical supplies off associated equipment before performing any adjustments, maintenance, or servicing the machine or taping heads.
  - Never attempt to work on the taping head or load tape while the box drive system is running

**Tape Latch Alignment – Figure 5-1**

The Latching tape drum assembly is pre-set to accommodate 48mm [2 inch] wide tape. The tape drum assembly is adjustable to provide alignment of narrower tapes.

To move the latch to a position that corresponds to a new tape core width (**Figure 5-1**):

1. Remove screw from the latch.
2. Move to the latch to the position that corresponds to the tape core width.
3. Replace screw in the new latch location.

To adjust or center the tape width on the centerline of the taping head, and therefore box center seam, (**Figure 5-2**):


1. Loosen the locking hex nut behind tape drum bracket on tape drum shaft. Use an adjustable wrench or 25mm open end wrench.
2. Turn tape drum shaft in or out to center the tape web (use 5mm hex wrench).
3. Tighten locking hex nut to secure the adjustment.

No other components require adjustment for tape web alignment.


**Tape Drum Friction Brake – Figure 5-3**

The tape drum friction brake on each taping head is pre-set for normal operation to prevent tape roll over travel. Should tension adjustment be required, turn the self-locking nut on the shaft to vary compression of the spring. Turn the nut clockwise to increase the braking force, and counterclockwise to decrease the braking force. Adjust brake to minimum tension to prevent excessive tape roll over travel.


**Note** – Excess braking force will cause poor tape application and may lead to tape tabbing on the trailing tape leg.



**Figure 5-1 – Tape Latch Alignment**



**Figure 5-2 – Tape Web Alignment**



**Figure 5-3 – Tape Drum Friction Brake**

(Adjustments continued on next page.)



**WARNING**

- **To reduce the risk associated with shear, pinch, and entanglement hazards:**
  - Turn air and electrical supplies off associated equipment before performing any adjustments, maintenance, or servicing the machine or taping heads.
  - Never attempt to work on the taping head or load tape while the box drive system is running

**Applying Mechanism Spring**

To obtain access to the spring, remove the taping head cover (four mounting screws). Replace cover when finished.

The applying mechanism spring, shown in **Figures 5-4A and 5-4B**, controls applying and buffing roller pressure on the box and returns the mechanism to the reset position. The spring pressure is pre-set, as shown in **Figure 5-4A** for normal operation, but is adjustable.

If a tape gap appears on the trailing surface of the box increase spring pressure. If the front of the box is being crushed by the applying roller decrease spring pressure.


Removing the spring end loop from the spring holder and placing loop in other holes provided, as shown in **Figure 5-4B**, will adjust the spring pressure.

**One-Way Tension Roller**  
**Figure 5-5**


The one-way tension roller is factory set. When replacing this assembly, the roller must have 0,5 kg [1 lb.] minimum tangential force when turning.

To Adjust Tension:

1. Wrap a cord or small strap (non-adhesive) 4-6 turns around the tension roller.
2. Attach a spring scale to the end of the cord or strap.
3. Turn the adjusting nut with the socket wrench provided, until a force of approximately 0.5 kg to 0.9 kg [1 to 2 lbs.] is required to turn the roller by pulling on the spring scale.



**Figure 5-4 – Applying Mechanism Spring**



**Figure 5-5 – One-Way Tension Roller**

(Adjustments continued on next page.)



**WARNING**

- To reduce the risk associated with shear, pinch, and entanglement hazards:
- Turn air and electrical supplies off associated equipment before performing any adjustments, maintenance, or servicing the machine or taping heads.
- Never attempt to work on the taping head or load tape while the box drive system is running

**Tape Leg Length**



**WARNING**

- To reduce the risk associated with sharp blade hazards:
- Keep hands and fingers away from tape cutoff blades under orange blade guards. The blades are extremely sharp.

**Leading Tape Leg Length Adjustment – Figure 5-6**


The one-way tension roller position is adjustable to control the leading tape leg length.

Moving this roller farther away from the box top or bottom surface will decrease the leading leg length. Moving it closer to the box top or bottom surface will increase the leading leg length.


**Changing Tape Leg Length from 70 to 50mm [2-3/4 to 2 Inches] – Figure 5-7**

**Note** – When changing tape leg length, both upper and lower heads must be adjusted to apply the same leg lengths.

1. Remove and retain two hex head screws and remove the brush from normal position “A” on side frame.
2. Remount and secure brush in position “A-A” on side frame forward of normal location using original fasteners.
3. Remove cut-off bracket extensions from position “B”.
4. Remount cut-off bracket extensions in forward position “B-B”.
5. Remove and retain the one-way tension roller assembly from slot “C” in frame.
6. Remount tension roller assembly near top of slot “C-C” in frame using original fasteners.
7. Adjust tension roller according to "Leading Tape Leg Length Adjustment" above.



**Figure 5-6 – Leading Tape Leg Length**



**Figure 5-7 – Changing Tape Leg Length**

---

## Troubleshooting

---

### Troubleshooting Guide

<b>Problem</b>	<b>Cause</b>	<b>Correction</b>
The tape leg on the front of the case is too long	The tape is threaded incorrectly	The tape must go around the wrap roller before going around the one-way tension roller
	The tape tension is too low	Adjust the one-way tension roller
	The knurled roller drags	Check for adhesive build-up between the knurled roller and its shaft. Clean and lubricate shaft. Remove all lubricant from roller surfaces.
	Tape tracks to one side or drags on the support tabs of applying frame	Adjust the tape web alignments
	The one-way tension roller is not correctly positioned	Position the roller in its mounting slot so that the tape extends just beyond the centerline of the applying roller
	Taping head is not set up properly	Check leg length adjustments
The blade does not cut tape or the tape end is jagged or shredded	The blade is dull and/or has broken teeth	Replace the blade
	Tape tension is insufficient	Increase tape tension by adjusting the one-way tension roller
	Adhesive has built up on the blade	Clean and adjust the blade
	The blade is not positioned properly	Make sure the blade is bottomed out against the mounting bolts
	The blade is dry	Lubricate the blade oiler pad on the blade guard
	The blade is in backwards	Mount the blade so that the beveled edge is away from the entrance of the head
	One or both cutter springs are missing or stretched	Replace the defective spring(s)
	Tension roller surface is not fully contacting the taping head frame	Make sure one-way bearing is below the surface of the tension roller. If not, press bearing further into roller or replace roller.

**Troubleshooting** (continued)

---

**Troubleshooting Guide**

<b>Problem</b>	<b>Cause</b>	<b>Correction</b>
Tape is tabbing on the trailing leg on the back of the box	There is excess tension on the tape drum assembly and/or the one-way tension roller assembly	Adjust the one-way tension roller and/or the tape drum assembly
	Rollers in the tape path do not rotate freely	Clean adhesive deposits from the surface, ends, and shafts of the rollers. Then lubricate roller shafts. Remove all lubricant from roller surfaces.
	The blade is not cutting tape properly	Refer to tape cutting problems
	The tape is threaded incorrectly	Re thread the tape
The tape end does not stay in application position in front of the applying roller	Applying mechanism spring has too little tension	Move spring hook to next tighter hole
	The tape is incorrectly threaded	Re thread the tape
	Flanged knurled roller overruns on return of applying mechanism to its rest position	Adjust tension roller position in mounting slot to lengthen tape leg
	Applying roller overruns on return of applying mechanism to its rest position	There should be a slight drag when rotating the applying roller. If not, check friction springs and/or friction pins and replace if necessary
	The one-way tension roller is not correctly positioned	Position roller in its mounting slot so that tape end extends beyond centerline of applying roller
Tape not centered on box seam	The one-way tension roller is defective	Replace the one-way tension roller
	Tape drum not centered	Reposition tape drum
	Centering guides not centered	Adjust centering guides
	Box flaps not of equal length	Check box specifications

---

## Spare Parts/Service Information

---

### Recommended Spare Parts

Listed are a set of spare parts that will periodically require replacement due to normal wear. These parts should be ordered to keep the taping heads in production:

#### AccuGlide™ 3 Upper Taping Head - 2 inch

Qty.	Part Number	Description
4	78-8076-4500-3	Stud – Mounting
1	78-8137-3311-6	Spring – Upper Extension
1	78-8017-9173-8	Blade – 65mm/2.56 Inch
2	78-8052-6602-6	Spring – Cutter
1	78-8076-4726-4	Tool – Tape Threading

---

#### AccuGlide™ 3 Lower Taping Head - 2 inch

Qty.	Part Number	Description
1	78-8017-9173-8	Blade – 65mm/2.56 Inch
2	78-8052-6602-6	Spring – Cutter
4	78-8076-4500-3	Stud – Mounting
1	78-8137-3312-4	Spring – Lower Extension
1	78-8076-4726-4	Tool – Tape Threading

---

In addition to the above set of spare parts supplied with the taping head, it is suggested that the following spare parts be maintained which will require replacement under normal wear of the taping head.

Qty.	Part Number	Description
1	78-8057-6179-4	Roller – Applying
1	78-8057-6178-6	Roller – Buffing
1	78-8113-7030-9	Spring – Torsion

---

### Replacement Parts and Service

Refer to the first page of this instruction manual “**Replacement Parts and Service Information**”.

## Replacement Parts Illustrations and Parts Lists

AccuGlide™ 3 High Speed 2 Inch Upper Taping Head, Type 10800

AccuGlide™ 3 High Speed 2 Inch Lower Taping Head, Type 10800


1. Refer to the **Taping Head Assemblies** Figure to find all the parts illustrations identified by **figure numbers**.
2. Refer to the figure or figures to determine the **individual parts** required and the **parts reference number**.
3. The **replacement parts list**, that follows each illustration, includes the **part number** and **part description** for the parts in that illustration.

**Note** – The complete description has been included for standard fasteners and some commercially available components. This has been done to allow obtaining these standard parts locally, should the customer elect to do so.

4. Refer to the first page of this instruction manual "**Replacement Parts and Service Information**" for replacement parts ordering information.

**Important** – Not all the parts listed are normally stocked items. Some parts or assemblies shown are available only on a special order basis. Contact 3M/Tape Dispenser Parts to confirm item availability.

Tape Head -  
AccuGlide™ 3 - 2 inch






Figure 10925 – Upper Head

## AccuGlide™ 3 - 2"

Figure 10925 – 2" Upper Head

Ref. No.	3M Part No.	Description
10925-1	78-8137-3294-4	Frame – Tape Mount Upper Assembly
10925-2	78-8137-3295-1	Frame – Front Upper Assembly
10925-3	78-8068-4143-9	Guide – #1
10925-4	78-8068-4144-7	Guide – #2
10925-5	78-8060-7818-0	Screw – Hex Hd, M4 x 12
10925-6	78-8010-7416-8	Nut – Hex Jam, M4
10925-7	78-8070-1251-9	Spacer – Spring
10925-8	78-8137-3298-5	Shaft - Pivot 90mm
10925-9	78-8052-6560-6	Spacer – Front
10925-10	78-8060-7936-0	Brush Assembly
10925-11	78-8052-6564-8	Shaft – Tension Roller
10925-12	78-8052-6568-9	Shaft – Wrap Roller
10925-13	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10925-15	78-8100-1009-6	Washer – Special
10925-16	78-8052-6565-5	Roller – Top Tension
10925-17	26-1004-5510-9	Washer – Plain, M10
10925-18	78-8052-6567-1	Spring – Compression
10925-19	78-8017-9077-1	Nut – Self Locking, M10 x 1
10925-20	78-8052-6569-7	Roller – Wrap
10925-21	26-1000-1613-3	Ring – Retaining, Tru-Arc #1-420-0120-100
10925-22	78-8076-4500-3	Stud – Mounting (not shown)
10925-23	78-8076-5242-1	Stop – Cut-Off Frame
10925-24	78-8060-8179-6	Screw – Flat Hd Hex, M6 x 20
10925-25	78-8076-5477-3	Washer – Special /6.5 x 20 x 4
10925-26	78-8137-3299-3	Guard – Head
10925-27	78-8060-8087-1	Screw – M5 x 10
10925-28	78-8005-5741-1	Washer – Flat, M5
10925-29	78-8133-9615-3	Bumper
10925-30	78-8133-9605-4	Label – Threading, English Language
10925-31	78-8076-4716-5	Star Washer 4mm




Figure 10922 – Upper and Lower Heads

**AccuGlide™ 3 - 2"**

**Figure 10922 – 2" Upper and Lower Heads**

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
10922-1	78-8133-9509-8	Applying Arm #1
10922-2	78-8133-9510-6	Applying Arm #2
10922-3	78-8070-1221-2	Plate – Tape
10922-4	78-8070-1309-5	Shaft Roller
10922-5	78-8070-1367-3	Roller – Knurled Assembly
10922-6	78-8070-1266-7	Roller – Wrap
10922-7	78-8052-6580-4	Spacer
10922-8	78-8017-9082-1	Bearing – Special, 30 mm
10922-9	78-8017-9106-8	Screw – Bearing Shoulder
10922-10	78-8052-6575-4	Shaft – Roller
10922-11	78-8017-9074-8	Washer – Nylon, 15 mm
10922-12	26-1004-5510-9	Washer – Friction
10922-13	78-8052-6567-1	Spring – Compression
10922-14	78-8137-1438-9	Assembly– Applying Roller
10922-15	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10922-16	78-8094-6151-6	Washer - Flat, 6.5 ID x 15 OD x 0.5 Thk




Figure 10919 – Upper Head

## AccuGlide™ 3 - 2"

Figure 10919 – 2" Upper Head

Ref. No.	3M Part No.	Description
10919-1	78-8137-3300-9	Buffing Arm – Sub Assembly
10919-2	78-8137-3301-7	Buffing Arm – Sub Assembly
10919-3	78-8052-6575-4	Shaft – Roller
10919-4	78-8137-1398-5	Roller - Buffing Assembly
10919-5	78-8070-1220-4	Spacer – Spring
10919-6	78-8052-6580-4	Spacer
10919-7	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10919-8	78-8137-3311-6	Spring – Upper (100 fpm)
10919-9	78-8070-1244-4	Holder – Spring




Figure 10923 – Upper and Lower Heads

**AccuGlide™ 3 - 2"**

**Figure 10923 – 2" Upper and Lower Heads**

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
10923-1	78-8137-3302-5	Link – Assembly
10923-3	78-8137-3304-1	Shaft – Pivot, Buffing
10923-4	78-8017-9082-1	Bearing – Special 30 mm
10923-5	78-8017-9106-8	Screw – Bearing Shoulder
10923-6	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10923-7	78-8137-3305-8	Spacer – Applying Pivot
10923-8	78-8137-3306-6	Shaft – Pivot, Applying
10923-9	78-8094-6151-6	Washer - Flat, 6.5 ID x 15 OD x 0.5 Thk




Figure 10921 – Upper and Lower Heads

## AccuGlide™ 3 - 2"

Figure 10921 – 2" Upper and Lower Heads

Ref. No.	3M Part No.	Description
10921-1	78-8137-3307-4	Frame – Cut-Off Weldment
10921-2	78-8017-9173-8	Blade – 65 mm/2.56 Inch
10921-3	26-1003-8596-7	Screw - Hex Hd M5 x 8 w/ Ext. Tooth Lockwasher
10921-4	78-8070-1371-5	Blade Guard Assembly – W/English Language Label
10921-5	78-8052-6597-8	Shaft – Blade Guard
10921-7	26-1005-4758-2	Screw – Flat Hd, Soc Dr, M4 x 10
10921-8	78-8017-9135-7	Shaft – Spacer
10921-9	78-8052-6600-0	Spacer
10921-10	78-8070-1269-1	Bumper
10921-11	26-1005-4757-4	Screw – Flat Hd, Soc Dr, M5 x 20
10921-12	78-8052-6602-6	Spring – Cutter
10921-13	78-8017-9132-4	Pivot – Cutter Lever
10921-14	26-1003-5828-7	Screw – Spec, Hex Hd, M6 x 10
10921-15	78-8137-3308-2	Slide – Extension
10921-16	26-1008-6574-5	Screw – Flat Hd, Phil Dr, M4 x 10
10921-17	78-8113-7031-7	Bushing – 58.5mm Long
10921-18	78-8113-7030-9	Spring – Torsion
10921-19	78-8070-1335-0	Label – Warning, English






Figure 10401 – Upper and Lower Heads

## AccuGlide™ 3 - 2"

Figure 10401 – 2" Latch Upper and Lower Heads

Ref. No.	3M Part No.	Description
10401-1	78-8070-1395-4	Bracket – Bushing Assembly
10401-2	78-8076-4519-3	Shaft – Tape Drum, 50mm
10401-3	78-8017-9169-6	Nut – M18 x 1
10401-4	78-8098-8827-0	Tape Drum Sub Assembly – 2 Inch Wide
10401-5	78-8098-8749-6	Tape Drum
10401-6	78-8098-8817-1	Leaf Spring
10401-7	26-1002-5753-9	Screw – Self Tapping
10401-8	78-8060-8172-1	Washer – Friction
10401-9	78-8052-6271-0	Washer – Tape Drum
10401-10	78-8100-1048-4	Spring – Core Holder
10401-11	78-8017-9077-1	Nut – Self Locking, M10 x 1
10401-12	78-8100-1046-8	Spacer – Bracket
10401-13	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10401-14	78-8098-8814-8	Tape Drum Assembly – 2 Inch Head
10401-15	26-1004-5510-9	Washer – Plain, M10
10401-16	78-8098-8816-3	Latch – Tape Drum




Figure 10924 – Lower Head

## AccuGlide™ 3 - 2"

Figure 10924 – 2" Lower Head

Ref. No.	3M Part No.	Description
10924-1	78-8137-3296-9	Frame – Tape Mount Lower Assembly
10924-2	78-8137-3297-7	Frame – Front Lower Assembly
10924-3	78-8068-4144-7	Guide – #2
10924-4	78-8068-4143-9	Guide – #1
10924-5	78-8060-7818-0	Screw – Hex Hd, M4 x 12
10924-6	78-8010-7416-8	Nut – Hex, M4
10924-7	78-8070-1251-9	Spacer – Spring
10924-8	78-8054-3298-5	Spacer – 10 x 10 x 90 mm
10924-9	78-8052-6560-6	Spacer – Front
10924-10	78-8060-7936-0	Brush Assembly
10924-11	78-8052-6564-8	Shaft – Tension Roller
10924-12	78-8052-6568-9	Shaft – Wrap Roller
10924-13	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10924-15	78-8100-1009-6	Washer – Special
10924-16	78-8052-6606-7	Roller – Tension Bottom
10924-17	26-1004-5510-9	Washer – Plain, M10
10924-18	78-8052-6567-1	Spring – Compression
10924-19	78-8017-9077-1	Nut – Self Locking, M10 x 1
10924-20	78-8052-6569-7	Roller – Wrap
10924-21	26-1000-1613-3	Ring – Retaining, Tru-Arc #1-420-0120-100
10924-22	78-8076-4500-3	Stud – Mounting (not shown)
10924-23	78-8076-5242-1	Stop – Cut-Off Frame
10924-24	78-8060-8179-6	Screw – Flat Hd Hex, M6 x 20
10924-25	78-8076-5477-3	Washer – Special /6.5 x 20 x 4
10924-26	78-8137-3299-3	Guard – Head
10924-27	78-8060-8087-1	Screw – M5 x 10
10924-28	78-8005-5741-1	Washer – Flat, M5
10924-29	78-8076-4734-8	Bumper
10924-30	78-8133-9606-2	Label – Threading, English Language
10924-31	78-8076-4716-5	Star Washer 4mm




Figure 10920 – Lower Head

**AccuGlide™ 3 - 2"**

**Figure 10920– Lower Head**

<b>Ref. No.</b>	<b>3M Part No.</b>	<b>Description</b>
10920-1	78-8137-3300-9	Buffing Arm – Sub Assembly
10920-2	78-8137-3301-7	Buffing Arm – Sub Assembly
10920-3	78-8052-6575-4	Shaft – Roller
10920-4	78-8137-1398-5	Roller - Buffing Assembly
10920-5	78-8070-1220-4	Spacer – Spring
10920-6	78-8052-6580-4	Spacer
10920-7	26-1003-5829-5	Screw – Hex Hd, M6 x 12
10920-8	78-8137-3312-4	Spring – Lower (100 fpm)
10920-9	78-8070-1244-4	Holder – Spring

THIS PAGE IS BLANK



