3M

$\textbf{Quick Term II}^{\text{TM}}$

Hi-K Silicone Rubber Termination Kit, 15 kV

Instruction Sheet

IEEE Std. No. 48, 1975

Class 3 Termination 15 kV Class


Kit Contents:

1 Hi-K Silicone Rubber Termination

1 Packet of Silicone Grease

1 Instruction Sheet

	DIMENSION TABLE									
Kit No.	Α	В	С	15kV Cond. Size Range (A W G -k c m i l)	Primary Insul. O.D. Range (inch-mm)					
5 6 71	9-1/4" (235 mm)	Depth of Lug or	8" (203 mm)	#2 - 250	.637 - 1.120" (16.2 - 28.4 mm)					
5 6 72	9-1/4" (235 mm)	Stem Connector Barrel	8" (203 mm)	250 - 1000	.940" - 1.810" (23.9 - 46.0 mm)					



For use on 15 kV Concer Jacketed Concentric Neu Conductor Size Range #2 AWG-1000 kcmil	Primary Insulation O.D. Range:		Hi-K Silicone Rubber Termination Kits for CN and JCN Cable 15 kV Class 5671 5672		
Number of Pages: 4	Scale: Not to Scale				
Issue Date: 9/9/97	Issue: A	78-8111	-0807-1		

A. Prepare Cable

- 1. Check to be sure cable size fits within the kit range as shown in the table below.
- 2. For JCN cable remove cable jacket at a distance of A plus depth of lug or terminal B. See Figure 1a and Dimension Table below.
- 3. Bind concentric neutral wires from cable end a distance of A plus B. See Figure 1b and Dimension Table below. Allow sufficient neutral wire length for neutral connection.
- 4. Remove semi-conductive jacket for a distance of C plus B. See Figure 1a, 1b and Dimension Table.




Figure 1a (JCN Cable)




Figure 1b (CN Cable)

- 5. Remove cable insulation for a distance of B. See Figure 1.
- 6. CLEAN CABLE USING STANDARD PRACTICE.
 - a. Wipe the cable insulation with a solvent such as 1, 1, 1 trichloroethane in the Scotch Brand A-2 Cable Prep Kit. Do not allow solvent to touch semi-con.
 - b. If abrasive must be used:
 - 1) Use on insulation only. DO NOT USE ON SEMI-CON JACKET.
 - 2) Use only 120 grit aluminum oxide such as in A-2 Cable Prep Kit or Scotch Brand A-3 Electricians Abrasive Roll.
 - 3) Be careful not to reduce the cable insulation diameter below that allowed by the kit.

B. Install Termination

- Cover the edge of the semi-conducting material with a liberal coating of silicone grease. NOTE: ON THIS PRODUCT THE SILICONE GREASE DOES NOT SERVE AS A LUBRICANT. IT MUST BE USED TO FILL THE STEP AT THE SEMI-CON CUTOFF. Spread silicone grease over the entire exposed primary insulation.
- 2. Slide the termination body onto the cable.

3. Remove termination core by unwinding counter-clockwise starting with the loose end. Make sure the termination body is butted up to the edge of the neutral wires. (Figure 2a, 2b.) Note: An occasional tug of the strand while unwinding will aid in core removal. Wipe off excess silicone grease from the exposed insulation.





Figure 2a (JCN Cable)

Figure 2b (CN Cable)

4. Twist one neutral wire around base of termination. IN NO CASE SHOULD THE STRAND BE TWISTED ABOVE THE SEMI-CON CUTOFF. See figure 3.






Figure 3b (CN Cable)

C. Install Lug or Connector

1. Install lug or connector per manufacturer's instructions. See Crimping Table below when using 3M type lugs.

Conductor	3M Stem	Recommended Crimping Tools					
Size	Conn. No.	Manufacturer	Mech. Tool	Die (No. Crimps)	Hydraulic Tool	Die (No. Crimps)	
#1 Sol #1 ,#2	SC0002 SC0001	BURNDY KEARNY	MD6 O-51,O-52	BG(4).W-243(4) 5/8 (4)	Y35,Y39,Y45**	U25ART(2),U243(2)	
1/0	SC0010	T &B ANDERSON	TBM8 -	OLIVE (2)	TBM 15 VC 6	50*(2) UNIVERSAL (2)	
2/0 3/0	SC0020 SC0030	BURNDY KEARNY	MD6 O-51 .O-52	W660(3),840(5) 840(5)*	Y35,Y39,Y45** WH-1 ,WH-2	U28ART(2) 840(2)	
4/0	SC0040	T &B ANDERSON	TBM8	WHITE(4)	TBM 15 VC 6	66(3) UNIVERSAL (2)	

NOTE: when installing in enclosed switchgear or transformers maintain clearances required by manufacturers.

'3M', 'Cold Shrink and 'Scotchlok' are trademarks of 3M

Important Notice to Purchaser:

All statements, technical information and recommendations related to the Seller's products are based on information believed to be reliable, but the accuracy or completeness thereof is not guaranteed. Before utilizing the product, the user should determine the suitability of the product for its intended use. The user assumes all risks and liability whatsoever in connectron with such use.

Any statements or recommendations of the Seller which are not contained in the Seller's current publications shall have no force or effect unless contained in an agreement signed by an authorized officer of the Seller. The statements contained herein are made in lieu of all warranties expressed or implied, including but not limited to the implied warranties of merchantability and fitness for a particular purpose which warranties are hereby expressly disclaimed.

SELLER SHALL NOT BE LIABLE TO THE USER OR ANY OTHER PERSON UNDER ANY LEGAL THEORY INCLUDING BUT NOT LIMITED TO NEGLIGENCE OR STRICT LIABILITY, FOR ANY INJURY OR FOR ANY DIRECT OR CONSEQUENTIAL DAMAGES SUSTAINED OR INCURRED BY REASON OF THE USE OF ANY OF THE SELLERS PRODUCTS.

