

Branding Disclaimer: Please refer to your countries brand guidelines when making use of these assets
Reviews Disclaimer: Reviews shown here may or may not apply/be meaningful to these products in your region.
Amazon Link: <https://www.amazon.com/dp/B007VBXB48>



Everyday Laminating: 3 mil Thickness

3 mil pouches offer basic document protection for everyday laminating uses. Recommended for your child's artwork, labeling, document organization, certificates, and reference materials.



Everyday Laminating:
3 mil Thickness



Long Lasting Laminating:
5 mil Thickness



Long Lasting Laminating: 5 mil Thickness

5 mil pouches offer a longer lasting and more durable laminating finish. Recommended for ID cards, menus, recipe cards, photos, reusable classroom materials, and dry erase surface applications.



Everyday Laminating:
3 mil Thickness



Long Lasting Laminating:
5 mil Thickness

Laminating with Scotch™ Laminators can be fast and easy, let us show you how.



Make sure your machine is warm and ready to go.

- The on/off button can be found either as a toggle switch on the back or a push button on the top
- Choose your pouch setting, either 3 mil or 5 mil depending on the thickness of the pouch you are working with
- Warm up times can take between 1-6 minutes depending on your machine, your machine is warm enough to start laminating once the ready light illuminates.
- If your machine has a feeding tray, ensure it is extended in the ready position

Place your project inside the laminating pouch.

- Center your item inside the pouch checking that you leave laminate margin on every side for best sealing results
- Have some fun with it by stacking multiple layers of colorful paper, confetti or lettering on top of one another



Place the **Sealed End** of the pouch into the machine, with the open end following behind.

- Check to make sure the pouch lines up to the opening to prevent an uneven or angled feed through
- Remove any objects that could get in the way of your project as it feeds out of the machine

Let the laminator do its thing!

- Avoid pulling or obstructing the pouch as it feeds through the laminator
- Your project will be hot when it exits the machine so use caution

Helpful tip: Cut/trim pouches only AFTER feeding through the machine



	TL901 Laminator	TL1302 Laminator	TL906 Laminator	TL1306 Laminator
Never Jam Technology			X	X
3 and 5 mil Settings	X	X	X	X
Auto-Shut Off		X	X	X
Warm Up Time	5-8 Minutes	1 min	5-6 min	1 min
Rollers	2	2	2	4
Max Input Width	9-inches	13-inches	9-inches	13-inches
Pouch Feed Tray			X	X
Carry Handle		X		
Cord Wrap Storage	X	X	X	X