

**3M** Science.  
Applied to Life.™



# Standard Operating Procedures

for Marine Aftermarket

# Standard Operating Procedures for Marine Aftermarket

## Think about your health

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000




























3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Gelcoat Surface Preparation and Application Process		Product List
<b>1</b>	<b>Cleaning</b> 	<p>1. Pressure wash the repair area. 2. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials, with approved cleaner to remove any inorganic materials.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ Perfect-It™ Boat Wash</b>                      PN09034E 473ml                      PN09035E 946ml                 </div> <div style="text-align: center;">   <b>3M™ Perfect-It™ High Performance Cloth, Yellow</b>                      PN50400                 </div> </div>
<b>2</b>	<b>Sanding</b> 	<p>1. Sand the old or new gelcoat to remove surface imperfections using a DA sander with abrasive discs 3M™ Hookit™ 737U Cubitron™ II grade 80+. 2. Apply dry guide coat to surface and re-sand gelcoat to ensure an even texture of surface is being repaired. 3. Clean the repair area with approved cleaner or blow off the repair area using pressured air.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs</b>                      PN51369 (80+)                 </div> <div style="text-align: center;">   <b>3M™ Sander</b>                      PN28508 152mm 5mm orbit                      PN28509 152mm 2.5mm orbit                 </div> <div style="text-align: center;">   <b>3M™ Hookit™ Soft Interface Pad</b>                      PN51126 5mm                      PN51127 10mm                 </div> </div>
<b>3</b>	<b>Filler application</b> 	<p>1. If needed, mix 3M™ Marine Blister Repair Filler per manufacturer's recommendation. 2. First apply a tight coat then apply filling coats. Fill 85% of the cavity leaving space for 3M™ Marine Premium Filler to be applied later in the process. 3. After 30 minutes feather the repair with 3M™ Hookit™ 737U Cubitron™ II abrasive disc grade 80+. 4. Apply dry guide coat to surface and re-sand gelcoat to ensure an even texture of surface is being repaired. 5. Clean the repair area with approved cleaner or blow off the repair area using pressured air.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ Marine Blister Repair Filler</b>                      PN46013                 </div> <div style="text-align: center;">   <b>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs</b>                      PN51369 (80+)                 </div> <div style="text-align: center;">   <b>3M™ Dry Guide Coat</b>                      PN09650 Black                      PN50416 Orange                 </div> </div>
<b>4</b>	<b>Final filler application</b> 	<p>1. Mix 3M™ Marine Premium Filler according to manufacturer's specification. 2. Apply 3M™ Marine Premium Filler to the repair area making sure to apply a tight coat first. 3. After the filler has cured, sand the repair with 3M™ Hookit™ 737U Cubitron™ II 120+ grade abrasive discs, removing high spots in the repair. 4. Finish by sanding the repair area with 3M™ Hookit™ 737U Cubitron™ II grade 220+.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ Marine Premium Filler</b>                      PN46005                 </div> <div style="text-align: center;">   <b>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs</b>                      PN51370 (120+)                      PN51423 (220+)                 </div> <div style="text-align: center;">   <b>3M™ Sander</b>                      PN28508 152mm 5mm orbit                      PN28509 152mm 2.5mm orbit                 </div> </div>
<b>5</b>	<b>Masking</b> 	<p>1. Ensure that the surface is completely dry prior to applying 3M™ masking products. 2. Taking care to keep the repair area as small as possible, first mask the areas that require 3M™ Precision Masking Tape. 3. Mask the rest of the repair, backing up the 3M™ Precision Masking Tape with masking tape*. 4. Mask entire surface with 3M™ Purple Premium Plus Masking Film.</p> <p><small>*3M™ Scotch™ 3030 Masking Tape (internal use) or 3M™ Scotch Blue™ 2090 Painter's Tape (internal and external use)</small></p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ Purple Premium Plus Masking Film</b>                      PN50988                 </div> <div style="text-align: center;">   <b>3M™ Precision Masking Tape</b> </div> <div style="text-align: center;">   <b>3M™ Scotch™ 3030 Masking Tape</b> </div> <div style="text-align: center;">   <b>3M™ Scotch Blue™ 2090 Painter's Tape</b> </div> </div>
<b>6</b>	<b>Gelcoat application</b> 	<p>1. Mix gelcoat in appropriate 3M™ PPS™ Series 2.0 disposable spray cup, according to manufacturer recommendation. Remember to remove filter in the lid of disposable paint system 2. Adjust 3M™ Performance Spray Gun air pressure, fan and fluid setting to achieve desired fan pattern and atomisation. 3. Hold spray gun 15cm - 20cm away from surface and apply gelcoat to the repair area according to manufacturer's recommendation for micron thickness.</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">   <b>3M™ PPS™ Series 2.0 Spray Cup System</b> </div> <div style="text-align: center;">   <b>3M™ Performance Spray Gun</b>                      PN26832                 </div> <div style="text-align: center;">   <b>3M™ Performance Gravity HVLP Atomising Head Red</b>                      PN26720                 </div> </div>
<b>7</b>	<b>Gelcoat finishing</b> 	<p>For gelcoat finishing process please refer to the following page.</p>

# Standard Operating Procedures for Marine Aftermarket

**Think about your health**

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000





























3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Gelcoat Finishing Process*		Product List
<b>1</b> Cleaning	 <p>1. Pressure wash the repair area. 2. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials. 3. Clean the repair area with approved cleaner to remove any inorganic materials.</p>	  <p><b>3M™ Perfect-It™ Boat Wash</b> PN09034E 473ml PN09035E 946ml</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Yellow</b> PN50400</p>
<b>2</b> Sanding	 <p>1. Sand gelcoat surface with P800 grade 3M™ Hookit™ Flexible Abrasive Foam Disc on a dual action sander. When sanding use a 50% overlap with each pass of the sander.</p>	    <p><b>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs</b> PN51369 (80+)</p> <p><b>3M™ Hookit™ Flexible Abrasive Foam Discs</b> PN33540 (P800)</p> <p><b>3M™ Hookit™ Soft Interface Pad</b> PN51126 5mm PN51127 10mm</p> <p><b>3M™ Sander</b> PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>3</b> Sand scratch refinement	 <p>1. Refine the P800 grade sand scratch using the P1200 grade 3M™ Hookit™ Flexible Abrasive Foam Discs on a dual action sander. When sanding use a 50% overlap with each pass of the sander.</p>	   <p><b>3M™ Hookit™ Flexible Abrasive Foam Discs</b> PN33542 (P1200)</p> <p><b>3M™ Hookit™ Soft Interface Pad</b> PN51126 5mm PN51127 10mm</p> <p><b>3M™ Sander</b> PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>4</b> Compounding	 <p>1. Compound the abraded surface with 3M™ Perfect-It™ Gelcoat Heavy Cutting Compound and 3M™ Perfect-It™ Low Linting Wool Compounding Pad. Use a Rotary Polishing machine at a speed of 1400 - 1800 rpm's.</p>	    <p><b>3M™ Perfect-It™ Gelcoat Heavy Cutting Compound</b> PN36101 473ml PN36102E 946ml PN36103 3.6L</p> <p><b>3M™ Perfect-It™ Quick Connect Double Sided Wool Compounding Pad</b> 230mm PN33279</p> <p><b>3M™ Quick Connect Adaptor</b> PN05752</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Yellow</b> PN50400</p>
<b>5</b> Polishing	 <p>1. 3M™ Perfect-It™ Gelcoat Compound + Polish and 3M™ Perfect-It™ Low Linting Wool Compounding Pad. Use the rotary polishing machine at a speed of 1400 - 1800 rpm's.</p>	    <p><b>3M™ Perfect-It™ Gelcoat Compound + Polish</b> PN30344E 946ml PN30345E 3.6L</p> <p><b>3M™ Perfect-It™ Quick Connect Double Sided Wool Compounding Pad</b> 230mm PN33279</p> <p><b>3M™ Quick Connect Adaptor</b> PN05752</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Blue</b> PN50486</p>
<b>6</b> Protection	 <p>1. Apply 3M™ Perfect-It™ Boat Wax to protect the surface. When applying Boat Wax, apply in a 10cm x 10cm area and wipe area clean before the wax dries.</p>	   <p><b>3M™ Perfect-It™ Boat Wax</b> PN09034E 473ml PN09035E 946ml</p> <p><b>3M™ Perfect-It™ High Gloss Polishing Pad</b> PN09378</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Blue</b> PN50486</p>

\* Two options (5 or 6 steps)

# Standard Operating Procedures for Marine Aftermarket

## Think about your health

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000
























3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Gelcoat Finishing Process*		Product List
<b>1</b> Cleaning	 <p>1. Pressure wash the repair area. 2. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials. 3. Clean the repair area with approved cleaner to remove any inorganic materials.</p>	  <p><b>3M™ Perfect-It™ Boat Wash</b> PN09034E 473ml PN09035E 946ml</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Yellow</b> PN50400</p>
<b>2</b> Sanding	 <p>1. Sand gelcoat surface with P800 grade 3M™ Hookit™ Flexible Abrasive Foam Disc on a dual action sander. When sanding use a 50% overlap with each pass of the sander.</p>	    <p><b>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs</b> PN51369 (80+)</p> <p><b>3M™ Hookit™ Flexible Abrasive Foam Discs</b> PN33540 (P800)</p> <p><b>3M™ Hookit™ Soft Interface Pad</b> PN51126 5mm PN51127 10mm</p> <p><b>3M™ Sander</b> PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>3</b> Sand scratch refinement	 <p>1. Refine the P800 grade sand scratch using the P1200 grade 3M™ Hookit™ Flexible Abrasive Foam Discs on a dual action sander. When sanding use a 50% overlap with each pass of the sander.</p>	   <p><b>3M™ Hookit™ Flexible Abrasive Foam Discs</b> PN33542 (P1200)</p> <p><b>3M™ Hookit™ Soft Interface Pad</b> PN51126 5mm PN51127 10mm</p> <p><b>3M™ Sander</b> PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>4</b> Compounding & Polishing	 <p>1. Compound the abraded surface with 3M™ Perfect-It™ Gelcoat Compound + Polish and 3M™ Perfect-It™ Low Linting Wool Compounding Pad. Use a Rotary Polishing machine at a speed of 1400 - 1800 rpm's.</p>	    <p><b>3M™ Perfect-It™ Gelcoat Compound + Polish</b> PN30344E 946ml PN30345E 3.6L</p> <p><b>3M™ Perfect-It™ Quick Connect Double Sided Wool Compounding Pad</b> 230mm PN33279</p> <p><b>3M™ Quick Connect Adaptor</b> PN05752</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Yellow</b> PN50400</p>
<b>5</b> Protection	 <p>1. Apply 3M™ Perfect-It™ Boat Wax to protect the surface. When applying Boat Wax, apply in a 10cm x 10cm area and wipe area clean before the wax dries.</p>	   <p><b>3M™ Perfect-It™ Boat Wax</b> PN09034E 473ml PN09035E 946ml</p> <p><b>3M™ Perfect-It™ High Gloss Polishing Pad</b> PN09378</p> <p><b>3M™ Perfect-It™ High Performance Cloth, Blue</b> PN50486</p>

\* Two options (5 or 6 steps)

# Standard Operating Procedures for Marine Aftermarket

## Think about your health

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000























3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Marine Paint Surface Preparation and Application Process		Product List
<b>1</b> Cleaning		<p>1. Pressure wash the repair area. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials. Clean the repair area with approved cleaner to remove any inorganic materials.</p>   <p>3M™ Perfect-It™ Boat Wash PN09034E 473ml PN09035E 946ml</p> <p>3M™ Perfect-It™ High Performance Cloth, Yellow PN50400</p>
<b>2</b> Sanding		<p>1. Using a DA sander with 3M™ Hookit™ 737U Cubitron™ II 80+ grade abrasive discs, sand the repair area to remove any oxidized paint. 2. Clean the repair area with approved cleaner or blow off the repair area using pressured air.</p>   <p>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs PN51369 (80+)</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>3</b> Filler application		<p>1. As an alternative to Epoxy Fillers use mixed 3M™ Marine Premium Filler per manufacturer's recommendation. 2. Apply 3M™ Marine Premium Filler to the surface. 3. After 30 mins (12-24hrs for Epoxy Filler) apply dry guide coat to the surface and sand the filler with 3M™ Hookit™ 737U Cubitron™ II 120+ grade abrasive discs. 4. Apply dry guide coat to surface and re-sand filler to ensure even texture of surface being repaired. 5. Finish by sanding filler with 3M™ Hookit™ 737U Cubitron™ II 220+ grade abrasive discs. 6. Clean the surface with approved cleaner or blow off the surface with pressured air.</p>    <p>3M™ Marine Premium Filler PN46005</p> <p>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs PN51370 (120+) PN51423 (220+)</p> <p>3M™ Dry Guide Coat PN09650 Black PN50416 Orange</p>
<b>4</b> Masking		<p>1. Ensure that the surface is completely dry prior to applying 3M™ masking products. 2. Taking care to keep the repair area as small as possible, mask the areas that require 3M™ Precision Masking Tape first. 3. Mask the rest of the repair, backing up the 3M™ Precision Masking Tape with masking tape*. 4. Mask entire surface with 3M™ Purple Premium Plus Masking Film. *3M™ Scotch™ 3030 Masking Tape (internal use) or 3M™ Scotch Blue™ 2090 Painter's Tape (internal and external use)</p>     <p>3M™ Purple Premium Plus Masking Film PN50988</p> <p>3M™ Precision Masking Tape</p> <p>*3M™ Scotch™ 3030 Masking Tape 3M™ Scotch Blue™ 2090 Painter's Tape</p>
<b>5</b> Primer Application		<p>1. Mix primer in appropriate 3M™ PPS™ Series 2.0 disposable spray cup. 2. Adjust 3M™ Performance Spray Gun air pressure, fan and fluid setting to achieve desired fan pattern and atomisation. 3. Hold spray gun 15cm - 20cm away from surface and apply primer to the repair area according to manufacturer's recommendation for micron thickness.</p>    <p>3M™ PPS™ Series 2.0 Spray Cup System</p> <p>3M™ Performance Spray Gun PN26832</p> <p>3M™ Performance Gravity HVLP Atomising Heads</p>
<b>6</b> Primer Sanding		<p>1. Apply dry guide coat to surface and sand primer with 3M™ Hookit™ 737U Cubitron™ II 320+ grade abrasive discs to prepare for paint application. 2. Apply dry guide coat to surface. 3. Repeat sanding with 3M™ Hookit™ 737U Cubitron™ II abrasive discs grade 400+. 4. Clean the surface with approved cleaner or blow off the repair area using pressured air.</p>    <p>3M™ Dry Guide Coat PN09650 Black PN50416 Orange</p> <p>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs PN51426 (320+) PN51428 (400+)</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>7</b> Marine Paint Application		<p>1. Mix paint in appropriate 3M™ PPS™ Series 2.0 disposable spray cup. 2. Adjust 3M™ Performance Spray Gun air pressure, fan and fluid setting to achieve desired fan pattern and atomisation. 3. Hold spray gun 15cm - 20cm away from surface and apply paint to the repair area according to manufacturer's recommendation for micron thickness.</p>    <p>3M™ PPS™ Series 2.0 Spray Cup System</p> <p>3M™ Performance Spray Gun PN26832</p> <p>3M™ Performance Gravity HVLP Atomising Heads</p>
<b>8</b> Marine paint finishing		<p>For Marine Paint Finishing process please refer to the following page.</p>

# Standard Operating Procedures for Marine Aftermarket

## Think about your health

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000





























3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Marine Paint and Clearcoat Finishing Process		Product List
<b>1</b> Cleaning	 <p><b>Maintenance*</b></p> <p>1. Pressure wash the repair area. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials. Clean the repair area with approved cleaner to remove any inorganic materials.</p> <p><small>*Dry or Wet Sanding option</small></p>	  <p>3M™ Perfect-It™ Boat Wash PN09034E 473ml PN09035E 946ml</p> <p>3M™ Perfect-It™ High Performance Cloth, Yellow PN50400</p>
<b>2</b> Sanding	 <p><b>Dry Sanding*</b></p> <p>1. Sand with 3M™ Hookit™ Purple Finishing Film Disc 260L+ P1200/1500 grade with DA sander. Use 3M™ Hookit™ Soft Interface Pad.</p> <p><b>Wet Sanding*</b></p> <p>1. Sand with 3M™ Trizact™ Hookit™ Clear Coat Sanding Disc grade 1500 with DA sander, use 3M™ Hookit™ Soft Interface Pad. When using 3M™ Trizact™ Abrasives, use a light mist of water while sanding to avoid clogging of the disc.</p> <p><small>*Dry or Wet Sanding option</small></p>	    <p>3M™ Hookit™ Film Disc 260L+ PN51158 PN51154</p> <p>3M™ Trizact™ Hookit™ Clear Coat Sanding Disc PN05600</p> <p>3M™ Hookit™ Soft Interface Pad PN51126 5mm PN51127 10mm</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>3</b> Scratch refinement	 <p><b>Dry Sanding*</b></p> <p>1. Refine the 1200 grade abrasive sand scratches with 3M™ Hookit™ Flexible Abrasive Foam Disc P2000 grade on DA sander. 2. Clean the surface prior to compounding application.</p> <p><b>Wet Sanding*</b></p> <p>1. Refine the 1500 grade abrasive sand scratches with 3M™ Trizact™ Hookit™ Foam Abrasive Disc 443S grade 3000 on DA sander, use 3M™ Hookit™ Soft Interface Pad. When using 3M™ Trizact™ Abrasives, use a light mist of water while sanding to avoid clogging of the disc. 2. Clean the surface prior to the compounding application. <small>*Dry or Wet Sanding option</small></p>	    <p>3M™ Hookit™ Flexible Abrasive Foam Discs PN33544</p> <p>3M™ Trizact™ Hookit™ Foam Abrasive Disc 443SA PN50414</p> <p>3M™ Hookit™ Soft Interface Pad PN51126 5mm PN51127 10mm</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>4</b> Compounding	 <p>1. Compound the abraded surface with 3M™ Perfect-It™ Fast Cut Plus Extreme and 3M™ Perfect-It™ Low Linting Wool Compounding Pad or 3M™ Perfect-It™ Green Foam Compounding Pad. Use a Rotary Polishing machine at a speed of 1400 - 1800 rpm's.</p>	    <p>3M™ Perfect-It™ Fast Cut Plus Extreme 1kg 865ml PN51815</p> <p>3M™ Perfect-It™ Quick Connect Double Sided Wool Compounding Pad 230mm PN33279</p> <p>3M™ Quick Connect Adaptor PN05752</p> <p>3M™ Perfect-It™ Quick Connect Double Sided Foam Convuluted Green Compounding Pad 216mm PN50874</p> <p>3M™ Perfect-It™ High Performance Cloth, Yellow PN50400</p>
<b>5</b> Polishing	 <p>1. Polish compounded surface with 3M™ Perfect-It™ Ultrafina SE Polish and 3M™ Perfect-It™ Wool Polishing Pad or 3M™ Perfect-It™ Ultrafine Polishing Pad. Use the rotary polishing machine at a speed of 1400 - 1800 rpm's.</p>	   <p>3M™ Perfect-It™ Ultrafina SE Polish 1L PN50383</p> <p>3M™ Perfect-It™ Quick Connect Double Sided Foam Convuluted Blue Polishing Pad 216mm PN50708</p> <p>3M™ Quick Connect Adaptor PN05752</p> <p>3M™ Perfect-It™ High Performance Cloth, Blue PN50486</p>
<b>6</b> Protection	 <p>1. Apply 3M™ Perfect-It™ Boat Wax to protect the surface. When applying Boat Wax, apply in a 10cm x 10cm area and wipe area clean before the wax dries.</p>	   <p>3M™ Perfect-It™ Boat Wax PN09034E 473ml PN09035E 946ml</p> <p>3M™ Perfect-It™ High Gloss Polishing Pad PN09378</p> <p>3M™ Perfect-It™ High Performance Cloth, Blue PN50486</p>

# Standard Operating Procedures for Marine Aftermarket

**Think about your health**

3M™ E-A-R™ Ultrafit™ Earplugs, 32 dB, Corded, 50 Pairs/Box, UF-01-000






















3M™ Maintenance Free Half Mask, FFA2P3 R D Filters, 4255+



3M™ SecureFit™ 400 Safety Glasses, Black/Green frame, Anti-Scratch / Anti-Fog, Clear Lens, SF401AS/AF-EU



Not a complete list. Select protective eyewear, appropriate gloves, hearing protection, respirator and protective clothing based on your job and exposure assessment.

Marine Bottom Paint (Antifouling) Preparation and Application Process		Product List
<b>1</b> Cleaning	 <p>1. Pressure wash the repair area. 2. Clean the repair area with 3M™ Perfect-It™ Boat Wash to remove any organic materials. Clean the repair area with approved cleaner to remove any inorganic materials.</p>	  <p>3M™ Perfect-It™ Boat Wash PN09034E 473ml PN09035E 946ml</p> <p>3M™ Perfect-It™ High Performance Cloth, Yellow PN50400</p>
<b>2</b> Sanding	 <p>1. Sand the old bottom paint using a dual action sander with 3M™ Hookit™ 737U Cubitron™ II 80 grade abrasive discs to remove old loose bottom paint. 2. Clean the repair area with approved cleaner or blow off the repair area using pressured air.</p>	   <p>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs PN51369 (80+)</p> <p>3M™ Hookit™ Soft Interface Pad PN51126 5mm PN51127 10mm</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>3</b> Filler application	 <p>1. Mix 3M™ Marine Premium Filler according to manufacturer's specification. 2. Apply 3M™ Marine Premium Filler to the repair area making sure to apply a tight coat first. 3. After the filler has cured, sand the repair with 3M™ Hookit™ 737U Cubitron™ II 120+ grade abrasive discs, removing high spots in the repair. 4. Finish by sanding the repair area with 3M™ Hookit™ 737U Cubitron™ II 220+ grade abrasive disc.</p>	   <p>3M™ Marine Premium Filler PN46005</p> <p>3M™ Hookit™ 737U Cubitron™ II Abrasive Discs PN51426 (320+) PN51428 (400+)</p> <p>3M™ Sander PN28508 152mm 5mm orbit PN28509 152mm 2.5mm orbit</p>
<b>4</b> Masking	 <p>1. Ensure that the surface is completely dry prior to applying 3M™ masking products. 2. Taking care to keep the repair area as small as possible, mask the areas that require 3M™ Precision Masking Tape first. 3. Mask the rest of the repair, backing up the 3M™ Precision Masking Tape with masking tape*. 4. Mask entire surface with 3M™ Purple Premium Plus Masking Film.</p> <p>*3M™ Scotch™ 3030 Masking Tape (internal use) or 3M™ Scotch Blue™ 2090 Painter's Tape (internal and external use)</p>	   <p>3M™ Purple Premium Plus Masking Film PN50988</p> <p>3M™ Precision Masking Tape</p> <p>3M™ Scotch Blue™ 2090 Painter's Tape</p>
<b>5</b> Bottom paint application	 <p>1. Mix bottom paint in appropriate 3M™ PPS™ Series 2.0 disposable spray cup, according to manufacturer recommendation. Remember to remove filter in the lid of disposable paint system. 2. Adjust 3M™ Performance Spray Gun air pressure, fan and fluid setting to achieve desired fan pattern and atomisation. 3. Hold spray gun 15cm - 20cm away from surface and apply bottom paint to the repair area according to manufacturer's recommendation for micron thickness.</p>	   <p>3M™ PPS™ Series 2.0 Spray Cup System</p> <p>3M™ Performance Spray Gun PN26832</p> <p>3M™ Performance Gravity HVLP Atomising Head Red PN26720</p>

**Product Selection and Use:** Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. As a result, customer is solely responsible for evaluating the product and determining whether it is appropriate and suitable for customer's application, including conducting a workplace hazard assessment and reviewing all applicable regulations and standards (e.g., OSHA, ANSI, etc.). Failure to properly evaluate, select, and use a 3M product in accordance with all applicable instructions and with appropriate safety equipment, or to meet all applicable safety regulations, may result in injury, sickness, death, and/or harm to property.

**Disclaimer:** 3M industrial and occupational products are intended, labeled, and packaged for sale to trained industrial and occupational customers for workplace use. Unless specifically stated otherwise on the applicable product packaging or literature, these products are not intended, labeled, or packaged for sale to or use by consumers (e.g., for home, personal, primary or secondary school, recreational/sporting, or other uses not described in the applicable product packaging or literature), and must be selected and used in compliance with applicable health and safety regulations and standards (e.g., U.S. OSHA, ANSI), as well as all product literature, user instructions, warnings, and other limitations, and the user must take any action required under any recall, field action or other product use notice. For help with product selection and use, consult your on-site safety professional, industrial hygienist, or other subject matter expert. For additional product information, visit [www.3M.com](http://www.3M.com).



**3M United Kingdom plc  
Automotive Aftermarket**  
3M Centre, Cain Road,  
Bracknell, RG12 8HT  
Phone: +44 (0)161 237 6391  
[aadukenquiries@mmm.com](mailto:aadukenquiries@mmm.com)  
[www.3M.co.uk/paintapplication](http://www.3M.co.uk/paintapplication)

**3M Ireland Limited  
Automotive Aftermarket**  
The Iveagh Building, The Park,  
Carrickmines, Dublin 18  
Phone: +353 12160301  
[aadukenquiries@mmm.com](mailto:aadukenquiries@mmm.com)  
[www.3M.co.uk/paintapplication](http://www.3M.co.uk/paintapplication)

Please recycle. © 3M 2021. All rights reserved.  
3M, 3M Science, Applied to Life., Cubitron II, Finesse-It, Hookit,  
Perfect-It, PPS, Quick Connect, Roloc, Scotch, Stikit, Trizact,  
Wetordry are trademarks of the 3M Company.