



Product Care Guide

Your vehicle windows are installed with 3M™ Window Tint. The best choice for this application!

To ensure that our product performs for as long as possible, follow these instructions below:

- Give the 3M™ Window Tint time to bond to the window. To ensure product adheres properly, **DO NOT** open/close your windows or clean your windows for at least 48 hours after installation.
- When cleaning, use a soft, non-abrasive cloth or towel. A soft microfiber towel is recommended for drying.
- Only use clean water. Sand and other dust particles from dirty water may scratch the window tint.
- Standard pH neutral glass cleaners that are commercially available can be used as long as they do not contain abrasives. We recommend using Meguiar's® brand window cleaning products.

Note: Because installation companies often do not have dust-free areas available, small dust inclusions are unavoidable.

3M.com/PersonalAutoCare