



Product Care Guide

Your vehicle is wrapped with 3M™ Paint Protection Film. The best choice for this application!

To ensure that our product performs for as long as possible, follow these instructions below:

Cleanliness is Key – Wipe off any fuel spills immediately to avoid degrading the vinyl and adhesive. Then, hand wash, rinse and dry as soon as possible.

Give Your Car a Loving Home – Store your wrapped vehicle indoors, in a shaded area, or under a cover whenever possible. Storage will help preserve and protect the film from heat and UV exposure.

Spot Treat Stains – Soften difficult contaminants, like tree sap, by soaking them for several minutes with hot, soapy water. Then, rinse thoroughly and dry. Do not use rough scrubbing or abrasive tools, which will scratch the film.

Hand Washing is Best – Hand wash your vehicle whenever possible (think of it as a spa day for your car). If you must send it through the car wash, choose the touchless option as brush car washes may dull and scratch the film as well as lift the edge of the graphics. Do not wash for first 72 hours after installation.

Giving your vehicle proactive love and attention will keep your wrap looking its best for years down the road, ensuring that you'll always be ready for the spotlight.

[3M.com/PersonalAutoCare](https://www.3M.com/PersonalAutoCare)