# 3M<sup>™</sup> Cold Shrink QT-III Silicone Rubber Indoor Tubular Termination Kit

# With High-K Stress Relief

# For Tape Shield, Wire Shield and UniShield<sup>®</sup> Cable

7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110


# Instructions

### IEEE Std. No. 48

Class 1 Termination 15 kV Class 110 kV BIL

### A CAUTION

Working around energized systems may cause serious injury or death. Installation should be performed by personnel familiar with good safety practice in handling electrical equipment. De-energize and ground all electrical systems before installing product.





## **1.0 Kit Contents**

3 High-K, Tracking Resistant, Silicone Rubber Terminations

3 Pre-formed Ground Braids

3 Constant Force Springs

3 3M<sup>™</sup> EMI Copper Foil Shielding Tape 1181 Strips, 1/2" x 10"

6 Strips Scotch® Mastic Strip 2230 (black with white release liners, bagged)

1 3M<sup>™</sup> Cable Cleaning Preparation Kit CC-2

1 Instruction Sheet

Note: Do not use knives to open plastic bags.

## **Kit Selection Tables**

NOTE: Final Determ	OTE: Final Determination Factor is cable insulation diameter.										
For Use With Compression Lugs or Connectors											
Conductor Size Range (AWG & kcmil) Primary Insulation											
Kit Number	0.D. Range	Jacket O.D. Range	5 kV	8 kV	15 kV						
7622–T–110	0.64" – 1.08"	0.97" – 1.48"	4/0 – 400	3/0 – 300	2 – 2/0						
	(16,3 – 27,4 mm)	(24,6 – 37,7 mm)		—	(35 – 70 mm²)						
7623–T–110	0.72" – 1.29"	1.04" – 1.60"	300 – 500	250 – 500	2/0 – 300						
	(18,3 – 32,8 mm)	(26,4 – 40,6 mm)	—	—	(70 – 150 mm²)						
7624–T–110	0.83" – 1.53"	1.12" – 1.87"	500 – 750	350 – 700	4/0 – 500						
	(21,1 – 38,9 mm)	(28,4 – 47,5 mm)	—		(120 – 240 mm²)						
7625–T–110	1.05" – 1.80"	1.39" – 2.40"	700 – 1500	600 – 1250	500 – 1000						
	(26,7 – 45,7 mm)	(35,2 – 61,0 mm)	—	—	(240 – 500 mm²)						
7626–T–110	1.53" – 2.32"	1.84" – 2.80"	1750 – 2000	1500 – 2000	1250 – 2000						
	(38,9 – 58,9 mm)	(46,7 – 71,1 mm)		—	(625 – 1000 mm²)						

	For Use With 3M™ Mechanical Shearbolt Lugs QL2 Series: Two Hole										
Kit Number	Primary Insulation O.D. Range	Jacket O.D. Range	Conductor Size Range (AWG & kcmil) 15 kV	3M™ Shearbolt Lugs QL2 Series: Two Hole Part Number							
7622–T–110(L)	0.69" - 1.22" (17,5 - 31,0 mm)	0.97" – 1.48" (24,6 – 37,7 mm)	1/0 – 4/0 (60 – 120 mm²)	QL2-A-2-250							
7623–T–110	0.72" - 1.29"         1.04" - 1.60"         2/0 - 250           (18,3 - 32,8 mm)         (26,4 - 40,6 mm)         (70 - 150 mm²)			QL2-A-2-250							
7624–T–110	0.83" – 1.53" (21,1 – 38,9 mm)	1.12" – 1.87" (28,4 – 47,5 mm)	4/0 – 350 (120 – 150 mm²)	QL2-A-1/0-350							
7625–T–110	1.05" – 1.80" (26,7 – 45,7 mm)	1.39" – 2.40" (35,2 – 61,0 mm)	500 (240 mm²)	QL2-A-4/0-600							
7625–T–110	1.05" – 1.80" (26,7 – 45,7 mm)	1.39" – 2.40" (35,2 – 61,0 mm)	500 – 750 (240 – 325 mm²)	QL2-A-350-750							
7625–T–110(L)	1.15" – 1.98" (29,2 – 50,3 mm)	1.39" – 2.40" (35,2 – 61,0 mm)	750 – 1000 (400 – 500 mm²)	QL2-A-500-1000							
7626–T–110	7626-T-110         1.53" - 2.32"         1.84" -           (38,9 - 58,9 mm)         (46,7 - 7)		1250 (625 mm²)	QL2-A-1000-1250							

# 2.0 Instructions for Tape Shielded Cable

## **Prepare Cable**

- 2.1 Check to be sure cable size fits within kit range as shown in Table 1. (For Use With Compression Lugs or Connectors), or Table 2 (For Use With 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole).
- 2.2 Prepare cable using dimensions shown in Figure 1. **BE SURE TO ALLOW FOR DEPTH OF TERMINAL LUG OR CONNECTOR.** If necessary to prevent tape shield from unrolling, hold down edge with a single wrap of 3M EMI Copper Foil Shielding Tape 1181.
- 2.3 **If using a Crimp Type (Compression) lug**, measure the depth of the barrel, or if using a Crimp Type (Compression) connector, measure to the barrel center stop/midpoint, and see the NOTE below, and Table 3, concerning Aluminum Lug and Connector growth allowances, in order to calculate the Insulation Removal Length. Table 6 (located in the final pages of this Instruction document) can used to assist in calculating the total Jacket Removal Length when using a compression lug or connector.

If using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, proceed to Step 2.4.

NOTE: Provide additional exposed conductor distance to account for growth during crimping of ALUMINUM lugs or connectors as follows:

Aluminum Lug and Connector Growth Allowance	2 - 350 1/4" (6 mm)	400 - 650 1/2" (13 mm)	750–1000 3/4" (19 mm)	1250 - 2000 Field determined
		<b>T</b> 1 1 0		

Table 3

NOTE: It is imperative to remove all remnants of the semi-con layer, even if the semi-con layer comes off as one layer. There should not be any remaining black areas, or particles, on the cable insulation layer.




Figure 1

2.4 If using 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, refer to the Instructions that are packed with the Shearbolt product for the Insulation Cutback length for the specific Shearbolt Lug or Connector being used. Table 7 (located in the final pages of this Instruction document) can used to assist in calculating the total Jacket Removal Length when using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Shearbolt Connector QCI Series.

## 3.0 Install Ground Braid

3.1 Select a Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Using light tension, apply a **SINGLE WRAP** of mastic around the cable jacket 1/4" (6 mm) from cut edge (Figure 2). Cut off excess.




Figure 2

3.2 Position pre-formed ground braid with short tail over tape shield directly adjacent to cable jacket cut edge. PLEASE NOTE: The ground braid needs to make full contact with the metallic tape shield. Position long tail of ground braid, extending over cable jacket with solder block over mastic strip (Figure 3). Secure ground braid to cable jacket 4-1/2" (114 mm) from cable semi-con edge using vinyl tape (see NOTE and Figure 3).

NOTE: Position vinyl tape with care, it also serves as a marker for positioning the termination.




Figure 3

3.3 Wrap ground braid around cable tape shield one complete wrap, trim excess at approximately a 45 degree angle, and line up with the pre-bent 45 degree angle already on the ground braid, to prevent overlap. Secure in place with constant force spring. Wrap spring in same direction as ground braid (Figure 4). Cinch (tighten) the spring after wrapping the final winding.

3.4 Select second Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Apply a second **SINGLE WRAP** of mastic over solder block on ground braid and previously applied mastic (Figure 4). Cut off excess.




Figure 4

3.5 Wrap two highly stretched half-lapped layers of electrical grade vinyl tape around Scotch<sup>®</sup> Mastic Strip 2230, constant force spring and exposed tape shield (Figure 5).

NOTE: Take care not to cover exposed semi-con insulation shield. A minimum of 1" (25 mm) must be exposed.

NOTE: DO NOT completely cover the ground braid with electrical grade vinyl tape when applying over the Scotch<sup>®</sup> Mastic Strip 2230 per Step 3.5. LEAVE A MINIMUM OF 1/4" (6 MM) OF EXPOSED GROUND BRAID between the Vinyl Tape Marker applied in step 3.2 and the start of the two half-lapped layers of electrical grade vinyl tape covering the Scotch<sup>®</sup> Mastic Strip 2230 applied in Step 3.5.

### SPECIAL NOTE FOR CLOTH OR PAPER SEMI-CON INSULATION SHIELD

In cables with cloth or paper semi-conductive shields, it is recommended the shield be over wrapped with one halflapped layer of highly stretched semi-conductive rubber tape, such as Scotch<sup>®</sup> Electrical Semi-Conducting Tape 13.





Figure 5

## 4.0 Install Lug or Connector

### **Important Packaging Notice**

In order to make sure that you receive an undamaged termination, this 3M Cold Shrink QT-III Silicone Rubber Termination is packed with a RED SHIPPING CORE inside of the white core. Please remove the red shipping core BEFORE you install the termination. This shipping core can be recycled with other polypropylene waste.

### 4.1 Check to insure 3M Cold Shrink QT-Ill Silicone Rubber Termination assembly fits over the selected lug or connector BEFORE installing the lug or connector. If lug or connector. (Figure 6) will not fit through the termination core, clean the insulation (per Step 5.0) and slide termination on cable before installing lug or connector. DO NOT REMOVE CORE AT THIS TIME.



4.2 For 3M Compression Lugs and 3M Stem Connectors:

a. Refer to the final pages of this Instruction document for 3M Connector and Lug crimping information. b. For Aluminum Conductors - Thoroughly wire brush conductor strands to remove aluminum oxide layer. Insert conductor into lug or connector and then remove conductor. This will transfer some of the antioxidant paste onto the conductor. Wire brush the antioxidant paste into the strands. Immediately insert conductor into lug or connector barrel as far as it will go.

### NOTE: Die/crimper head rotation between consecutive crimps is RECOMMENDED.

c. Position connector or lug and crimp according to manufacturer's directions. Remove excess oxide inhibitor and sharp crimp flashings following crimping.

4.3 For 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole or 3M Mechanical Shearbolt Connector QCI Series: a. Refer to the Instructions that are packed with the Shearbolt product for the installation procedures.

## 5.0 Clean Cable Insulation and Lug or Connector Barrel Using Standard Practice

5.1 If abrasive must be used:
a. Use on insulation only. *DO NOT USE ABRASIVE ON SEMI-CON INSULATION SHIELD!*b. Use only aluminum oxide abrasive; grit 120 or finer, included in 3M Cable Cleaning Preparation Kit CC-2.
c. Be careful not to reduce the cable insulation diameter below that allowed by the kit.

5.2 Wipe the cable insulation with one of the solvent saturated pads from the 3M Cable Cleaning Preparation Kit CC-2, or other approved cable cleaner/solvent, AND ALLOW IT TO DRY BEFORE INSTALLING TERMINATION. A clean lint-free cloth, or inexpensive paper towel, can be used to dry the insulation surface if air drying time is of concern. DO NOT ALLOW SOLVENT TO TOUCH SEMI-CON INSULATION SHIELD!

## 6.0 Install Termination

6.1 Slide the termination body onto the cable and remove core. Make sure the termination body (not the core) is butted up to the edge of the vinyl tape marker previously applied in Step 3.2 (Figure 7). Pull the core while unwinding, counterclockwise, starting with the loose end (Figure 7). Be sure to alternate the pulling and unwinding actions (pull-unwind-pull-unwind-etc.) to help prevent the core material from binding up as the core is being removed.

## NOTE: Once the termination body makes contact over the mastic seal area, there is no need to continue supporting the assembly. DO NOT PUSH OR PULL ON THE TERMINATION ASSEMBLY WHILE UNWINDING THE CORE.





Figure 7

6.2 Connect ground braid to system ground according to standard practice.



# **Instructions for Wire Shielded Cable**

## 7.0 Prepare Cable

- 7.1 Check to be sure cable size fits within kit range as shown in Table 1. (For Use With Compression Lugs or Connectors), or Table 2 (For Use With 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole).
- 7.2 Prepare cable using dimensions shown in Figure 8 and Figure 9. BE SURE TO ALLOW FOR DEPTH OF TERMINAL LUG OR CONNECTOR.
- 7.3 **If using a Crimp Type (Compression) lug,** measure the depth of the barrel, or if using a Crimp Type (Compression) connector, measure to the barrel center stop/midpoint, and see the NOTE below, and Table 4, concerning Aluminum Lug and Connector growth allowances, in order to calculate the Insulation Removal Length. Table 8 (located in the final pages of this Instruction document) can used to assist in calculating the total Jacket Removal Length when using a compression lug or connector.

If using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, proceed to Step 7.4.

*NOTE: Provide additional exposed conductor distance to account for growth during crimping of ALUMINUM lugs or connectors as follows:* 

Aluminum Lug and Connector Growth Allowance	2 - 350 1/4" (6 mm)	400 - 650 1/2" (13 mm)	750–1000 3/4" (19 mm)	1250 - 2000 Field determined					

Table 4

*NOTE:* It is imperative to remove all remnants of the semi-con layer, even if the semi-con layer comes off as one layer. There should not be any remaining black areas, or particles, on the cable insulation layer.





Figure 8


- 7.4 If using 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, refer to the Instructions that are packed with the Shearbolt product for the Insulation Cutback length for the specific Shearbolt Lug or Connector being used. Table 9 (located in the final pages of this Instruction document) can used to assist in calculating the total Jacket Removal Length when using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Shearbolt Connector QCI Series.
- 7.5 Bend leading 1-1/2" (38 mm) of exposed shield wires back upon themselves to jacket edge (Figure 9).





## 8.0 Install Ground Braid

8.1 Select a Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Using light tension apply a **SINGLE WRAP** of mastic around the cable jacket 1/4" (6 mm) from cut edge (Figure 10). Cut off excess.





- 8.2 Position pre-formed ground braid with short tail over wire shield directly adjacent to cable jacket cut edge. PLEASE NOTE: The ground braid needs to make full contact with the shield wires. Position long tail of ground braid, extending over cable jacket with solder block over mastic strip (Figure 11). Secure ground braid to cable jacket 4-1/2" (114 mm) from cable semi-con edge using vinyl tape (see NOTE and Figure 11).
- NOTE: Position vinyl tape with care, it also serves as a marker for positioning the termination.




Figure 11

- 8.3 Wrap ground braid around cable shield wires one complete wrap, trim excess at approximately a 45 degree angle, and line up with the pre-bent 45 degree angle already on the ground braid, to prevent overlap. Secure in place with constant force spring. Wrap spring in same direction as ground braid (Figure 12). Cinch (tighten) the spring after wrapping the final winding.
- 8.4 Select second Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Apply a second **SINGLE WRAP** of mastic over solder block on ground braid and previously applied mastic (Figure 12). Cut off excess.




Figure 12

8.5 Wrap two highly stretched half-lapped layers of electrical grade vinyl tape around mastic seal, constant force spring and exposed shield wires (Figure 13).

NOTE: Take care not to cover exposed semi-con insulation shield. A minimum of 1" (25 mm) must be exposed.

NOTE: DO NOT completely cover the ground braid with electrical grade vinyl tape when applying over the Scotch<sup>®</sup> Mastic Strip 2230 per Step 8.5. LEAVE A MINIMUM OF 1/4" (6 MM) OF EXPOSED GROUND BRAID between the Vinyl Tape Marker applied in step 8.2 and the start of the two half-lapped layers of electrical grade vinyl tape covering the Scotch<sup>®</sup> Mastic Strip 2230 applied in Step 8.5.

### SPECIAL NOTE FOR CLOTH OR PAPER SEMI-CON INSULATION SHIELD

In cables with cloth or paper semi-conductive shields, it is recommended the shield be over-wrapped with one half-lapped layer of highly stretched semi-conductive rubber tape, such as Scotch<sup>®</sup> Electrical Semi-Conducting Tape 13.




Figure 13

## 9.0 Install Lug or Connector

### **Important Packaging Notice**

In order to make sure that you receive an undamaged termination, this 3M Cold Shrink QT-III Silicone Rubber Termination is packed with a RED SHIPPING CORE inside of the white core. Please remove the red shipping core BEFORE you install the termination. This shipping core can be recycled with other polypropylene waste.

9.1 Check to insure 3M Cold Shrink QT-III Silicone Rubber Termination assembly fits over the selected lug or connector BEFORE installing the lug or connector. If lug or connector (Figure 14) will not fit through the termination core, clean the insulation (per Step 10.0) and slide termination on cable before installing lug. DO NOT REMOVE CORE AT THIS TIME.





9.2 For 3M Compression Lugs and 3M Stem Connectors:

a. Refer to the final pages of this instruction document for 3M Connector and Lug crimping information.b. For Aluminum Conductors - Thoroughly wire brush conductor strands to remove aluminum oxide layer. Insert conductor into lug or connector and then remove conductor. This will transfer some of the antioxidant paste onto the conductor. Wire brush the antioxidant paste into the strands. Immediately insert conductor into lug or connector barrel as far as it will go.

### NOTE: Die/crimper head rotation between consecutive crimps is RECOMMENDED.

c. Position connector or lug and crimp according to manufacturer's directions. Remove excess oxide inhibitor and sharp crimp flashings following crimping.

9.3 For 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole or 3M Mechanical Shearbolt Connector QCI Series: a. Refer to the Instructions that are packed with the Shearbolt product for the installation procedures.

## **10.0** Clean Cable Insulation and Lug or Connector Barrel Using Standard Practice

- 10.1 If abrasive must be used:
  - a. Use on insulation only. DO NOT USE ABRASIVE ON SEMI-CON INSULATION SHIELD!
  - b. Use only aluminum oxide abrasive; grit 120 or finer, included in the 3M Cable Cleaning Preparation Kit CC-2.
  - c. Be careful not to reduce the cable insulation diameter below that allowed by the kit.
- 10.2 Wipe the cable insulation with one of the solvent saturated pads from the 3M Cable Cleaning Preparation Kit CC-2, or other approved cable cleaner/solvent, **AND ALLOW IT TO DRY BEFORE INSTALLING TERMINATION.** A clean lint-free cloth, or inexpensive paper towel, can be used to dry the insulation surface if air drying time is of concern. **DO NOT ALLOW SOLVENT TO TOUCH SEMI-CON INSULATION SHIELD!**

### 11.0 Install Termination

11.1 Slide the termination body onto the cable and remove core. Make sure the termination body (not the core) is butted up to the edge of the vinyl tape marker previously applied in Step 8.2 (Figure 15). Pull the core while unwinding, counterclockwise, starting with the loose end (Figure 15). Be sure to alternate the pulling and unwinding actions (pull-unwind-pull-unwind-etc.) to help prevent the core material from binding up as the core is being removed.

## NOTE: Once the termination body makes contact over the mastic seal area, there is no need to continue supporting the assembly. DO NOT PUSH OR PULL ON THE TERMINATION ASSEMBLY WHILE UNWINDING THE CORE.





Figure 15

11.2 Connect ground braid to system ground according to standard practice.



# Instructions for UniShield® Cable

## 12.0 Prepare Cable

- 12.1 Check to be sure cable size fits within kit range as shown in Table 1 (For Use With Compression Lugs or Connectors), or Table 2 (For Use With 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole).
- 12.2 Prepare cable using dimensions shown in Figures 16, 17 and 18. BE SURE TO ALLOW FOR DEPTH OF TERMINAL LUG OR CONNECTOR.
- 12.3 **If using a Crimp Type (Compression) lug,** measure the depth of the barrel, or if using a Crimp Type (Compression) connector, measure to the barrel center stop/midpoint, and see the NOTE below, and Table 5, concerning Aluminum Lug and Connector growth allowances, in order to calculate the Insulation Removal Length. Table 10 (located in the final pages of this Instruction document) can used to assist in calculating the total Jacket Removal Length when using a compression lug or connector.

If using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, proceed to Step 12.5.

12.4 Install constant force spring as shown in Figure 16. Pull shield wires through semi-conductive jacket to leading edge of constant force spring (Figure 16).

*NOTE: Provide additional exposed conductor distance to account for growth during crimping of ALUMINUM lugs or connectors as follows:* 




Figure 16

- 12.5 If using 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole, or 3M Mechanical Shearbolt Connector QCI Series, refer to the Instructions that are packed with the Shearbolt product for the Insulation Cutback length for the specific Shearbolt Lug or Connector being used. Table 11 (located in the final pages of this Instruction document) can used to assist in calculating the total Semi-Conductive Jacket Removal Length when using 3M Shearbolt Lugs QL2 Series: Two Hole, or 3M Shearbolt Connector QCI Series.
- 12.6 Remove constant force spring. Bend shield wires back upon semi-conductive jacket 1-1/2" (38 mm). Cut excess shield wire and discard (Figure 17).




Figure 17

12.7 Remove semi-conductive jacket to dimension shown in Figure 18.

NOTE: To ease jacket removal, install constant force spring as shown in Figure 18 and ring-cut 80% through jacket. Remove jacket sections by pulling against constant force spring. DO NOT BELL SEMI-CON JACKET. Remove constant force spring.

NOTE: It is imperative to remove all remnants of the semi-conductive jacket, even if the semi-conductive jacket comes off as one layer. There should not be any remaining black areas, or particles, on the cable insulation layer.




Figure 18

## 13.0 Install Ground Braid

13.1 Select a Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Using light tension apply a SINGLE WRAP of mastic around the cable semi-conductive jacket 1/4" (6 mm) from shield wires (Figure 19). Cut off excess.





Figure 19

13.2 Position pre-formed ground braid with short tail directly over cut edge of folded back shield wires. PLEASE NOTE: The ground braid needs to make full contact with the shield wires. Position long tail of ground braid, extending over cable semi-conductive jacket with solder block over mastic strip (Figure 20). Secure ground braid to cable semi-conductive jacket 4-1/2" (114 mm) from cable Semi-Conductive Jacket edge using vinyl tape (See NOTE and Figure 20).

NOTE: Position vinyl tape with care, it also serves as a marker for positioning the termination.





- 13.3 Wrap ground braid around cable shield wires one complete wrap, trim excess at approximately a 45 degree angle, and line up with the pre-bent 45 degree angle already on the ground braid, to prevent overlap. Secure in place with constant force spring. Wrap spring in same direction as ground braid (Figure 21). Cinch (tighten) the spring after wrapping the final winding.
- 13.4 Select second Scotch<sup>®</sup> Mastic Strip 2230 from kit and remove white release liners. Apply a second **SINGLE WRAP** of mastic over solder block on ground braid and previously applied mastic (Figure 21). Cut off excess.




Figure 21

13.5 Wrap two highly stretched half-lapped layers of electrical grade vinyl tape around mastic seal, constant force spring and exposed shield wires (Figure 22).

NOTE: Take care not to cover exposed Semi-Conductive Jacket. A minimum of 1" (25 mm) must be exposed.

NOTE: DO NOT completely cover the ground braid with electrical grade vinyl tape when applying over the Scotch<sup>®</sup> Mastic Strip 2230 per Step 13.5. LEAVE A MINIMUM OF 1/4" (6 MM)OF EXPOSED GROUND BRAID between the Vinyl Tape Marker applied in step 13.2 and the start of the two half-lapped layers of electrical grade vinyl tape covering the Scotch<sup>®</sup> Mastic Strip 2230 applied in Step 13.5.





Figure 22

## 14.0 Install Lug or Connector

### **Important Packaging Notice**

In order to make sure that you receive an undamaged termination, this 3M Cold Shrink QT-III Silicone Rubber Termination is packed with a RED SHIPPING CORE inside of the white core. Please remove the red shipping core BEFORE you install the termination. This shipping core can be recycled with other polypropylene waste.

14.1 Check to insure 3M Cold Shrink QT -III Silicone Rubber Termination fits over the selected lug or connector BEFORE installing the lug or connector. If lug or connector (Figure 23) will not fit through the termination core, clean the insulation (per Step 15.0) and slide termination on cable before installing lug or connector. DO NOT REMOVE CORE AT THIS TIME.





14.2 For 3M Compression Lugs and 3M Stem Connectors:

a. Refer to the final pages of this Instruction document for 3M Connector and Lug crimping information.
b. For Aluminum Conductors - Thoroughly wire brush conductor strands to remove aluminum oxide layer. Insert conductor into lug or connector and then remove conductor. This will transfer some of the antioxidant paste onto the conductor. Wire brush the antioxidant paste into the strands. Immediately insert conductor into lug or connector barrel as far as it will go.

### NOTE: Die/crimper head rotation between consecutive crimps is Recommended.

c. Position connector or lug and crimp according to manufacturer's directions. Remove excess oxide inhibitor and sharp crimp flashings following crimping.

14.3 For 3M Mechanical Shearbolt Lugs QL2 Series: Two Hole or 3M Mechanical Shearbolt Connector QCI Series: a. Refer to the Instructions that are packed with the Shearbolt product for the installation procedures.

## 15.0 Clean Cable Insulation and Lug or Connector Barrel Using Standard Practice

- 15.1 If abrasive must be used:
  - a. Use on insulation only. DO NOT USE ABRASIVE ON SEMI-CON INSULATION SHIELD!
  - b. Use only aluminum oxide abrasive; grit 120 or finer, included in the 3M Cable Cleaning Preparation Kit CC-2.
    - c. Be careful not to reduce the cable insulation diameter below that allowed by the kit.
- 15.2 Wipe the cable insulation with one of the solvent saturated pads from the 3M Cable Cleaning Preparation Kit CC-2, or other approved cable cleaner/solvent, AND ALLOW IT TO DRY BEFORE INSTALLING TERMINATION. A clean lint-free cloth, or inexpensive paper towel, can be used to dry the insulation surface if air drying time is of concern. DO NOT ALLOW SOLVENT TO TOUCH SEMI-CON INSULATION SHIELD!

## 16.0 Install Termination

16.1 Slide the termination body onto the cable and remove core. Make sure the termination body (not the core) is butted up to the edge of the vinyl tape marker previously applied in Step 13.2 (Figure 24). Pull the core while unwinding, counterclockwise, starting with the loose end (Figure 24). Be sure to alternate the pulling and unwinding actions (pull-unwind-pull-unwind-etc.) to help prevent the core material from binding up as the core is being removed.

## *NOTE:* Once the termination body makes contact over the mastic seal area, there is no need to continue supporting the assembly. DO NOT PUSH OR PULL ON THE TERMINATION ASSEMBLY WHILE UNWINDING THE CORE.





Figure 24

16.2 Connect ground braid to system ground according to standard practice.



Jacket Removal Calculation Table - Tape Shield Cable - Crimp Type (Compression) Lugs / Connectors - 7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110										
CABLE PREPARATION ITEM	Inches -Add this column-	mm -Add this column-	NOTES							
Insulation Length	9.0"	229 mm	Value from Figure 1							
Insulation Removal Length = Depth of Crimp Type (Compression) Terminal Lug or Connector Barrel (See NOTES column.)	+	+	Measure full depth of bore for lugs and to the center stop for connectors.							
Growth Allowance (Aluminum Only) for Crimp Type (Compression) Lug / Connector (See NOTES column.)	+	+	See Table 3 for correct growth allowance. <b>This measurement applies only to</b> <b>Aluminum lugs / connectors.</b>							
TOTAL JACKET REMOVAL LENGTH	=	=								

Table 6

Jacket Removal Calculation Table - Tape Shield Cable - 3M <sup>™</sup> Mechanical Shearbolt QL2 Series Lugs / 3M <sup>™</sup> Mechanical Shearbolt Connectors QCI Series - 7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110										
CABLE PREPARATION ITEM	Inches -Add this column-	mm -Add this column-	NOTES							
Insulation Length	9.0"	229 mm	Value from Figure 1							
Insulation Removal Length = Depth of Mechanical Shearbolt QL2 Series Terminal Lug or QCI Series Connector Barrel (See NOTES column.)	+	+	<ul> <li>Obtain Insulation Removal Length:</li> <li>For Mechanical Shearbolt Lugs see</li> <li>3M<sup>™</sup> Mechanical Shearbolt Lugs QL2 Series: Two Hole Instructions.</li> <li>For Mechanical Shearbolt Connectors see 3M<sup>™</sup> Mechanical Shearbolt Connectors QCI Series Instructions.</li> </ul>							
TOTAL JACKET REMOVAL LENGTH	=	=								

#### Jacket Removal Calculation Table - Wire Shield Cable - Crimp Type (Compression) Lugs / Connectors -7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110

,		, , ,	
CABLE PREPARATION ITEM	Inches -Add this column-	mm -Add this column-	NOTES
Insulation Length	9.0"	229 mm	Value from Figure 8
Insulation Removal Length = Depth of Crimp Type (Compression) Terminal Lug or Connector Barrel (See NOTES column.)	+	+	Measure full depth of bore for lugs and to the center stop for connectors.
Growth Allowance (Aluminum Only) for Crimp Type (Compression) Lug / Connector (See NOTES column.)	+	+	See Table 4 for correct growth allowance. This measurement applies only to Aluminum lugs / connectors.
TOTAL JACKET REMOVAL LENGTH	=	=	

Table 8

### Jacket Removal Calculation Table - Wire Shield Cable - 3M™ Mechanical Shearbolt QL2 Series Lugs / 3M™ Mechanical Shearbolt Connector QCI Series -7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110

CABLE PREPARATION ITEM	Inches -Add this column-	mm -Add this column-	NOTES
Insulation Length	9.0"	229 mm	Value from Figure 8
Insulation Removal Length = Depth of Mechanical Shearbolt QL2 Series Terminal Lug or QCI Series Connector Barrel (See NOTES column.)	+	+	<ul> <li>Obtain Insulation Removal Length:</li> <li>For Mechanical Shearbolt Lugs see</li> <li>3M™ Mechanical Shearbolt Lugs QL2 Series: Two Hole Instructions.</li> <li>For Mechanical Shearbolt Connectors see 3M™ Mechanical Shearbolt Connectors QCI Series Instructions.</li> </ul>
TOTAL SEMI-CON JACKET REMOVAL LENGTH	=	=	

#### Semi- Conductive Jacket Preparation Calculation Table - UniShield® Cable - Crimp Type (Compression) Lugs / Connectors -7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110 Inches mm CABLE PREPARATION ITEM NOTES -Add this column--Add this column-Semi-Conductive Jacket Length 7.5" 191 mm Value from Figure 16 Insulation Removal Length = Depth of Crimp Type (Compression) Measure full depth of bore for lugs + +Terminal Lug or Connector Barrel and to the center stop for connectors. (See NOTES column.) See Table 5 for correct growth Growth Allowance allowance. (Aluminum Only) for Crimp Type + +(Compression) Lug / Connector This measurement applies only to (See NOTES column.) Aluminum lugs / connectors. TOTAL SEMI- CONDUCTIVE = = JACKET PREPARATION LENGTH

### Table 10

#### Semi- Conductive Jacket Preparation Calculation Table - UniShield® Cable - 3M<sup>™</sup> Mechanical Shearbolt QL2 Series Lugs / 3M<sup>™</sup> Mechanical Shearbolt Connector QCI Series -7622-T-110, 7622-T-110(L), 7623-T-110, 7624-T-110, 7625-T-110, 7625-T-110(L), 7626-T-110

CABLE PREPARATION ITEM	Inches -Add this column-	mm -Add this column-	NOTES		
Semi-Conductive Jacket Length	7.5"	191 mm	Value from Figure 16		
Insulation Removal Length = Depth of Mechanical Shearbolt QL2 Series Terminal Lug or QCI Series Connector Barrel (See NOTES column.)	+	+	Obtain Insulation Removal Length: For Mechanical Shearbolt Lugs see 3M <sup>™</sup> Mechanical Shearbolt Lugs QL2 Series: Two Hole Instructions. For Mechanical Shearbolt Connectors see 3M <sup>™</sup> Mechanical Shearbolt Connectors QCI Series Instructions.		
TOTAL SEMI- CONDUCTIVE JACKET PREPARATION LENGTH	=	=			

## **Tooling Index**

			Lug and Crir	nping Inform	nation for 3M	l <sup>™</sup> Scotchlok™	Copper Lugs	;			
30014 thru 30045 One hole			$\bigcirc$	31036 thru 31068 One hole-long barrel				31145 thru 31178 Two hole-long barrel			
		01174			Crimping To	ol-Die Sets (N	linimum Nun	ber Of Crimp	is)		
Cable Size AWG/	Stud Size	3M™ Scotchlok™ Copper Lug		Burndy Co	orporation		Thomas	& Betts Corp	oration	Square D Co. Anderson Div.	
kcmil	(in.)	Number	MD6	MY29	Y34A	Y35, Y39, Y45*, Y46*	TBM 5	TBM 8	TBM 15	VC6–3, VC6–FT**	
6	10 1/4 5/16	30014 30015 30016	_	6AWG(1)	_	U5CRT(1)	Blue(1)	Blue(1)	_	(1)	
4	10 1/4 3/8	30018 30019 30021	W161(1)	4AWG(1)	A4CR(1)	U4CRT(1)	Grey(1)	Grey(1)	-	(1)	
2	1/4 5/16 3/8	30022 30023 30024	W162(2)	2AWG(1)	A2CR(1)	U2CRT(2)	Brown(1)	Brown(1)	33(1)	(2)	
1	5/16 3/8	30027 30028	-	1AWG(1)	A1CR(1)	U1CRT(2)	Green(1)	Green(1)	37(1)	(2)	
1/0	5/16 3/8	30031 30032	W163(2)	1/0(1)	A25R(1)	U25RT(1)	Pink(2)	Pink(2)	42H(2)	(1)	
2/0	3/8 3/8	30036 31036	W241(2) W241(3)	2/0(1) 2/0(2)	A26R(1) A26R(2)	U26RT(2) U26RT(3)	Black(2) Black(3)	Black(2) Black(3)	45(1) 45(2)	(1) (2)	
3/0	1/2 1/2	30041 31041	W243(2) W243(3)	3/0(1) 3/0(2)	A27R(1) A27R(2)	U27RT(2) U27RT(3)	Orange(2) Orange(3)	Orange(2) Orange(3)	50(1) 50(2)	(2) (3)	
4/0	1/2 1/2 1/2	30045 31045 31145	BG(3) BG(4) BG(4)	4/0(1) 4/0(2) 4/0(2)	A28R(2)	U28RT(2) U28RT(3) U28RT(3)	Purple(2) Purple(3) Purple(3)	Purple(2) Purple(3) Purple(3)	54H(2) 54H(3) 54H(3)	(2) (3) (3)	
250	1/2 1/2	31049 31149	W166(4)	250(2)	A29R(2)	U29RT(3)	Yellow(2)	Yellow(2)	62(2)	(2)	
300	1/2 1/2	31053 31153	-	-	A30R(2)	U30RT(3)	-	White(3)	66(3)	(3)	
350	1/2 1/2	31056 31156	-	-	A31R(2)	U31RT(3)	-	Red(4)	71H(4)	-	
400	1/2 1/2	31060 31160	-	_	A32R(2)	U32RT(3)	-	Blue(4)	76H(4)	-	
500	1/2 5/8 1/2	31066 31067 31166	_	_	A34R(2)	U34RT(3)	_	Brown(4)	87H(4)	_	
600	1/2 1/2	31068 31168	-	_	_	U36RT(3)	-	Green(4)	94H(4)	-	
750	1/2	31172	_	_	_	Y39, Y45, Y46 U39RT(5)	_	_	106H(4)	-	
1000	1/2	31178	_	-	-	Y45: S44RT(6) Y46: P44RT(6)	-	-	125H(4)	-	

\* Y45 and Y46 accept all Y35 dies ("U" series). For Y45 use PT6515 adapter. For Y46 use PUADP adapter.

\*\* Anderson VC6–3 and VC6–FT require no die set.

## **Tooling Index**

				Lug an	d Crimping	Information	n for 3M	™ Scotch	llok™ Cop	oper/Alu	minum L	ugs			
	40016 thru 40079 One hole						40132 thru 40178 Two hole								
/G/	<b>•</b>	* *				Crimpin	ig Tool-I	Die Sets (	(Minimu	n Numbo	er Of Crir	nps)			
Cable Size AWG/ kcmil	Stud Size (in.)	3M <sup>**</sup> Scotchlok <sup>**</sup> Lug Number		Bur	ndy Corpora	ition		Thor	nas & Bet	ts Corpor	ation	Square Anderso		ITT Blackburn Co.	Kearny Nat'l Div.
Cable	Stu	3M <sup>™</sup> Lui	MD6	MY29	Y34A	Y35, Y39, Y45*, Y46*	Y1000**	TBM 5	TBM 8	TBM 12	TBM 15	VC6–3** VC6–FT**	VC8C**	0D58	TYPE 0
6	5/16	40016	W161(1)	6AWG(1)	A6CAB(1)	U6CABT(1)	(1)	Grey(1)	Grey(1)	-	29(1)	(1)	-	BY19(3)	J(3)
4	5/16	40020	W162(3)	4AWG(1)	A4CAB(1)	U4CABT(1)	(1)	Green(2)	Green(2)	-	37(1)	(1)	-	BY53(3)	P(3)
2	3/8 1/2	40024 40025	W163(3) W163(3)	2AWG(1) 2AWG(1)	A2CAB(1) A2CAB(1)	U2CABT(1) U2CABT(1)	(1) (1)	Pink(2) Pink(2)	Pink(2) Pink(2)	-	42H(2) 42H(2)	(1) (1)	-	BY23(3) BY23(3)	1/2(3) 1/2(3)
1	3/8 1/2	40028 40029	W163(3) W163(3)	1AWG(1) 1AWG(1)	A1CAR(1) A1CAR(1)	U1CART(1) U1CART(1)	(1) (1)	Gold(2) Gold(2)	Gold(2) Gold(2)	-	45(1) 45(1)	(1) (1)	-	BY23(3) BY23(3)	1/2(3) 1/2(3)
1/0	3/8 1/2 3/8	40032 40033 40132	W241(3) W241(3) W241(3)	1/0(1) 1/0(1) 1/0(1)	A25AR(1) A25AR(1) A25AR(1)	U25ART(1) U25ART(1) U25ART(1)	(1) (1) (1)	Tan(2) Tan(2) Tan(2)	Tan(2) Tan(2) Tan(2)	-	50(1) 50(1) 50(1)	(1) (1) (1)	-	BY25(3) BY25(3) BY25(3)	5/8–1(3) 5/8–1(3) 5/8–1(3)
2/0	1/2 1/2	40037 40137	BG(4) BG(4)	2/0(1) 2/0(1)	A26AR(2) A26AR(2)	U26ART(2) U26ART(2)	(1) (1)	Olive(2) Olive(2)	Olive(2) Olive(2)	-	54H(2) 54H(2)	(2) (2)	-	BY31C(3) BY31C(3)	5/8–1(3) 5/8–1(3)
3/0	1/2 1/2	40041 40141	W166(4) W166(4)	3/0(1) 3/0(1)	A27AR(2) A27AR(2)	U27ART(2) U27ART(2)	(1) (1)	Ruby(2) Ruby(2)	Ruby(2) Ruby(2)	_	60(2) 60(2)	(2) (2)	_	_	737(3) 737(3)
4/0	1/2 5/8 1/2	40045 40046 40145	W660(4) W660(4) W660(4)	4/0 (2) 4/0 (2) 4/0 (2)	A28AR(2) A28AR(2) A28AR(2)	U28ART(2) U28ART(2) U28ART(2)	(1) (1) (1)	_	White(4) White(4) White(4)	-	66(4) 66(4) 66(4)	(2) (2) (2)	_	BY35C(4) BY35C(4) BY35C(4)	840(4) 840(4) 840(4)
250	1/2 5/8 1/2	40049 40050 40149	W249(3) W249(3) W249(3)	-	A29AR(2) A29AR(2) A29AR(2)	U29ART(2) U29ART(2) U29ART(2)	(1) (1) (1)	_	_	71H(4) 71H(4) 71H(4)	71H(2) 71H(2) 71H(2)	(3) (3) (3)	_	_	-
300	1/2 1/2	40053 40153	-	-	A30AR(2) A30AR(2)	U30ART(2) U30ART(2)	(1) (1)	_	-	76H(4) 76H(4)	76H(2) 76H(2)	(3) (3)	_	_	-
350	1/2 5/8 1/2	40056 40057 40156	_	-	_	U31ART(2) U31ART(2) U31ART(2)	(1) (1) (1)	_	-	87H(4) 87H(4) 87H(4)	87H(3) 87H(3) 87H(3)	(3) (3) (3)	_	_	-
400	1/2	40160	-	-	-	U32ART(4)	(1)	-	-	94H(4)	94H(4)	-	(2)	-	-
500	5/8 1/2	40067 40166	-	_	_	U34ART(4) U34ART(4)	(1) (1)	_	_	106H(4) 106H(4)	106H(3) 106H(3)	_	(2) (2)	_	_
600	1/2	40170	-	-	-	U36ART(4)	(1)	-	-	-	115H(3)	-	(3)	-	-
750	5/8 1/2	40073 40172	-	-	_	U39ART(4) U39ART(4)	(1) (1)	_	-	_	125H(4) 125H(4)	_	(3) (3)	_	-
1000	5/8 1/2	40079 40178	-	-	-	S44ART(4) S44ART(4)	(1) (1)	-	-	-	140H(4) 140H(4)	-	(3) (3)	-	-

\* Y45 and Y46 accept all Y35 dies ("U" series). For Y45 use PT6515 adapter. For Y46 use PUADP adapter.

\*\* Anderson VC6–3, VC6–FT, VC8C and Burndy Y1000 require no die set.

## **Tooling Index**

Crimping Information for 3M™ Stem Connectors Copper/Aluminum					,		0
Conductor Size AWG & kcmil		3M <sup>™</sup> Connector	Crimping Table For 3M <sup>™</sup> Stem Type Connector				
			Recommended Crimping Tools				
Stranded	Solid	Number	Manufacturer	Mech. Tool	Die (Minimum No. Crimps)	Hydraulic	Die (Minimum No. Crimps)
2, 1 4 1/0	1, 1/0 2 2/0	SC0001 SC0002 SC0010	Burndy	MD6	BG(4), W241(3)	Y35, Y39, Y45*, Y46*	U25ART(2), U243(2)
			Kearny	0–51, 0–52	5/8-1 (4)	WH-1, WH-2	5/8-1(4)
			T & B	TBM 5	Tan(2)	-	-
			T & B	TBM 8	Olive(2), Tan(2)	TBM 15	50(2)
			Anderson	-	-	VC6**	(2)
2/0 3/0 4/0	3/0 4/0 -	SC0020 SC0030 SC0040	Burndy	MD6	W249(3)	Y35, Y39, Y45*, Y46*	U28ART(2)
			Kearny	0–51, 0–52	840(5)	WH-1, WH-2	840(2)
			T & B	TBM 8	Red(4)	TBM 15	71H(3)
			Anderson	-	-	VC6**	(2)

\* Y45 and Y46 accept all Y35 dies ("U" series). For Y45 use PT6515 adapter. For Y46 use PUADP adapter.

\*\* Anderson VC6 is dieless and does not require a die set.

3M, Scotch and Scotchlok are trademarks of 3M Company.

UniShield is a trademark of General Cable Technologies Corporation.

### **Important Notice**

All statements, technical information, and recommendations related to 3M's products are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use. Any statements related to the product which are not contained in 3M's current publications, or any contrary statements contained on your purchase order shall have no force or effect unless expressly agreed upon, in writing, by an authorized officer of 3M.

### Warranty; Limited Remedy; Limited Liability.

This product will be free from defects in material and manufacture at the time of purchase. **3M MAKES NO OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** If this product is defective within the warranty period stated above, your exclusive remedy shall be, at 3M's option, to replace or repair the 3M product or refund the purchase price of the 3M product. **Except where prohibited by law, 3M will not be liable for any direct, indirect, special, incidental or consequential loss or damage arising from this 3M product, regardless of the legal theory asserted.** 



#### **Electrical Markets Division**

6801 River Place Blvd. Austin, TX 78726-9000 800.245.3573 Fax 800.245.0329 www.3M.com/electrical

Please Recycle. Printed in USA. © 3M 2018. All Rights Reserved. 78-8113-5099-6 Rev G