

3M™ QS II Inline Cable Repair Splice Kit 5412R

Instruction Sheet


IEEE Std. No. 404

15 kV Class

150 kV BIL

Kit Contents:

- 1 Molded Rubber Splice Body
- 1 Connector
- 2 Packets of Silicone Grease
- 1 Template
- 1 Instruction Sheet



(CN) Cable




(JCN) Cable

Accessory Splice Jacket


Selection Chart

Note: Final Determining factor is cable insulation diameter.

Kit Number (With Connector)	Cable Insulation O.D. Range	Conductor Size	Cable Insulation Thickness
		AWG	mils
5412R-CIR-2/0	0.870" - 1.055" (22,1 - 26,8 mm)	2/0	220
5412R-CIR-3/0		3/0	175
5412R-CIR-4/0		4/0	220
			175
			220



Concentric Neutral Cable



Jacketed Concentric Neutral Cable

3M™ QS-II

Inline Cable Repair Splice Kit


for use on Concentric Neutral (CN) Cable
and Jacketed Concentric Neutral (JCN)
Cable (With Accessory Splice Jacket)

5412R


78-8124-5411-0-C

A. Prepare Cables Using Standard Procedures (Shown on CN Cable)

1. Cut out damaged section of cable, but do not exceed 6" (152 mm). Check to make certain that the cable insulation diameter is between 0.870" and 1.055" (22,1 to 26,8 mm).



2. Gently fold neutral wires back over cable,ⓐ avoiding sharp bends. If cable does not have a jacket, bind neutral wires as shown with wire or vinyl tapeⓑ and fold neutral wires back over binding.ⓒ
3. Continue cable preparation according to figure below.




4. Clean cable using standard practice:
 - a. Do not use solvent or abrasive on cable semi-conductive insulation shield.
 - b. If abrasive must be used, do not reduce cable insulation diameter below the 0.870" (22,1 mm) specified for splice.


B. Installation (Shown on CN Cable)

1. Install CIR Connector provided onto Cable X only and crimp per the **Crimping Tool Table**.
2. Remove excess contact aid from connector end and file off any sharp crimp flashing.
3. Lubricate the connector, Cable X insulation and both ends of splice bore with silicone grease provided.
4. Slide the splice body onto connector and Cable X until uncrimped connector end is exposed, ① as shown. For easier installation, the splice body may be rotated while being installed.


Note: *For Jacketed Concentric Neutral (JCN) Cables, accessory splice jacketing components should also be slid onto cable at this time.*



5. Connect exposed connector end to Cable Y② and crimp per **Crimping Tool Table**.
6. Remove excess contact aid from connector end and file off any sharp crimp flashing.
7. Place a tape marker on Cable Y semi-conductive insulation shield, 1/2" (13 mm) from end of cable semi-con.③




8. Lubricate exposed connector and Cable Y insulation with silicone grease.
9. Center splice body over connector, so leading edge aligns with tape marker. ④ Remove tape marker.




C. Grounding Splice (Shown on CN Cable)

1. Position concentric neutral wires back over cable and splice. Attach one strand from each cable to its respective grounding eye, ① returning it back to the neutral wire bundle.
2. Join neutral wires using an appropriate connector(s). A low profile inline compression connector is recommended. ②



D. Jacketed Concentric Neutral (JCN) Cable Only

1. Install Accessory Splice Jacket Kit over splice and exposed neutral wires.①
2. The 3M™ Cold Shrink Stacked Sleeve Repair Splice Jacket Kit SJ-2SSR may be used for re-jacketing. Refer to the instructions provided with the kit.
3. If using the 3M splice jacket kit SJ-2A series or 3M splice jacket HSJ-2 series, refer to instructions provided with kit. Note that an additional 3M Cold Shrink Tubing 8420 series or 3M Heat Shrink Tubing ITCSN is also required to cover the longer length of the repair splice.



CRIMPING TOOL TABLE					
Mechanical			Hydraulic		Technical Data
Mfg.	Tool	Die (Crimps per End)	Tool	Die (Crimps Per End)	
BURNDY	MD6	W-K840 (4) W-249 (3)	Y-35, Y-39, Y-45*	U28 ART (2)	
KEARNEY	0-52, 0-51	840 (4)** 845H (3)	WH-1, WH-2	840 (3)**	
T&B	TBM-8	Blue (4)	TBM-15	76 (2)	
ANDERSON	--	--	VC6	UNIVERSAL (2)	

* Usable with - Die Adapter PT651

** Excess flash must be filed off to round out connector

3M is a trademark of 3M Company. All other trademarks herein are the property of their respective owners.

Important Notice

All statements, technical information, and recommendations related to 3M's products are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use. Any statements related to the product, which are not contained in 3M's current publications, or any contrary statements contained on your purchase order, shall have no force or effect unless expressly agreed upon, in writing, by an authorized officer of 3M.

Warranty; Limited Remedy; Limited Liability

This product will be free from defects in material and manufacture at the time of purchase. **3M MAKES NO OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** If this product is defective within the warranty period stated above, your exclusive remedy shall be, at 3M's option, to replace or repair the 3M product or refund the purchase price of the 3M product. **Except where prohibited by law, 3M will not be liable for any direct, indirect, special, incidental or consequential loss or damage arising from this 3M product, regardless of the legal theory asserted.**



Electrical Markets Division

6801 River Place Blvd.
Austin, TX 78726-9000
800.245.3573
FAX: 800.245.0329
www.3M.com/electrical

Please recycle
© 3M 2017 All rights reserved
78-8124-5411-0 Rev C