




Quick Guide


Programming RfID Markers with the M-Series Receiver




Press Write Mode.




Select template.
Press View/Edit




Scroll down.
Highlight area to change
Press Modify.




Show All.
Press OK.



Select compressed term to add to template.




Scroll to next edit.
Press Modify.




Press Locate/OK.




Move cursor left and right.
Press Select to enter information.




Press Write Marker.




Select marker type.




Place receiver tip over Marker.
Press Start Write.




Choose to lock data, or not.




Receiver identifies iD Marker.




Receiver programming Marker.



Programming complete.



Press Locate for Marker locate mode.
Press Read to see Marker Data.



Marker Data displayed.