



# Tips and Techniques for Optimum Plate Mounting

## Clean cylinder/sleeve

1. Clean sleeve per manufacturer recommendations.
2. Clean cylinder with 50:50 isopropyl alcohol/water. Clean sleeve with 100% isopropyl alcohol.
3. Wipe dry with clean cloth.



## Clean plate

1. Clean back of new or used print plate with 50:50 isopropyl alcohol/water.
2. Wipe dry with clean cloth.



## Apply plate mounting tape

1. Press tape evenly with hand or roller to ensure uniform contact to cylinder/sleeve.



## Mount plate

1. Roll down entire print plate using additional pressure on lead and trail edges.



## 3M™ E-Series Plate Mounting Tapes

- Bubble-free mounting ease
- Wide choice of adhesives, foams and thickness for the results your customers demand