

Product Description

Scotchgard™ Spot Remover & Upholstery Cleaner is a ready-to-use aerosol product specially formulated for daily use on common spots and spills. This effective spot remover is an important part of the 3M carpet care system.

Special Features

- Aerosol delivers a thick white foam which minimizes the overuse of chemicals and moisture on the carpet
- Effectively removes most common spots and spills
- No rinsing required
- No sticky residue to cause resoiling

Applications

- Commercial and residential carpets
- Most carpet fibers (nylon, polyester, olefin, wool and blends)
- Most carpet styles (loop or cut piles)
- Safe for use on stain resistant nylon fibers
- Upholstery fabrics that can be safely cleaned with water

Packaging

- 17 ounce aerosol can
- 12 cans per case

General Use Directions

Note: Apply a small amount of product in an inconspicuous area to make sure the product is safe for use on your fabric. Allow the product to dry, and if the color or texture of the fabric is changed, do not use the product.

Dry Spots

1. Loosen any solid material using a dull spatula, spoon, or butter knife by scrapping toward the center of the spot.
2. Vacuum away the dried material before applying spot remover.
3. Shake can and apply a uniform layer of foam to the spotted area extending the application about 1" beyond the spot.
4. Allow 1-2 minutes for the chemical to penetrate the fibers.
5. Use a dull tool to work the spot remover deep into the pile.
6. Blot using white paper towels or absorbent rags – never scrub.
7. Blot from the outer edge toward the center of the spot.
8. Turn the blotting material often to expose a fresh side of the cloth.
9. Continue blotting until no color from the spot is being transferred to the cloth.

Quick Links

- [Resource Library](#)
- [Safety Data Sheets \(SDS\)](#)
- [Video Library](#)

Some of these links lead to web-based resources that are not product-specific.

Wet Spills

1. Absorb wet spills as soon as possible using white paper towels or absorbent rags.
2. After removing as much liquid as possible follow steps 3-9 above.

Upholstery Cleaning

1. Thoroughly vacuum the upholstery.
2. Shake can and apply a uniform layer of foam to the soiled area.
3. Allow 1-2 minutes for the chemical to penetrate the fabric.
4. Blot using white paper towels or absorbent rags – never scrub.
5. Turn the blotting material often to expose a fresh side of the cloth.
6. Allow fabric to dry completely and vacuum.

Note: Refer to product Safety Data Sheets for specific health hazard, first aid and precautionary information.

SDS#: 10-2821-6

Health and Safety

When handling any chemical products, read the manufacturers' container labels and the Safety Data Sheets (SDS) for important health, safety and environmental information. To obtain SDS sheets for 3M products go to 3M.com/SDS, or by mail or in case of an emergency, call 1-888-364-3577 or 1-651-737-6501. When using any equipment, always follow the manufacturers' instructions for safe operation.

Technical Information

Technical information and data, recommendations, and other statements provided by 3M are based on information, tests, or experience which 3M believes to be reliable, but the accuracy or completeness of such information is not guaranteed. Such technical information and data are intended for persons with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. The typical values shown should not be used for the purpose of specification limits. If you have questions about this Product, contact the **Customer Service Department at 1-800-852-9722**.

Scotchgard™ Spot Remover & Upholstery Cleaner (Aerosol)

Product Use

Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty

3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

Limited Remedy

If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

No Extension of Warranty

In the case of an approved warranty claim, the replacement Product will carry only the remaining term of the original warranty period.

Limitation of Liability

Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.

Commercial Solutions Division

3M Center, Building 220-12E-04
St. Paul, MN 55144

1-800-328-0033
3M.com/Facility

© 3M 2018. All rights reserved.
3M is a trademark of 3M. Used under license in Canada.
All other trademarks are property of their respective owners.
Revision B, March 2018. Please recycle.

