


. Slide the 3M™ Cold Shrink Quick Insulator QI assembly, loose core end first, onto cable or wire prior to connecting.




2. Make connection and file off any excess flash from the connector. Clean cable insulation to a minimum distance "X" as indicated in the application chart for the product being installed.




3. Place a tape marker distance "X" from the center of the crimped connector on the cable opposite the loose core end and parked insulator assembly.



Position the QI Insulator over connector area, aligning the leading tube end (not the spiral core) with the tape marker.



5. Install the QI Insulator by slowly pulling the loose core end and unwinding (counterclockwise) while maintaining alignment of the tube with the tape marker. Continue unwinding the core to complete installation.



Note: The ends of the QI Insulator may be squeezed to assist the tube in shrinking to its final diameter.

3M is a trademark of 3M Company.

Important Notice

All statements, technical information, and recommendations related to 3M's products are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use. Any statements related to the product which are not contained in 3M's current publications, or any contrary statements contained on your purchase order shall have no force or effect unless expressly agreed upon, in writing, by an authorized officer of 3M.

Warranty; Limited Remedy; Limited Liability.

This product will be free from defects in material and manufacture at the time of purchase. 3M MAKES NO OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If this product is defective within the warranty period stated above, your exclusive remedy shall be, at 3M's option, to replace or repair the 3M product or refund the purchase price of the 3M product. Except where prohibited by law, 3M will not be liable for any direct, indirect, special, incidental or consequential loss or damage arising from this 3M product, regardless of the legal theory asserted.



Electrical Markets Division

6801 River Place Blvd. Austin, TX 78726-9000 800-245-3573 Fax 800-245-0329 www.3M.com/electrical

Please Recycle. Printed in USA. © 3M 2015. All Rights Reserved. 78-8127-8641-2 Rev J

3M[™] Cold Shrink Quick Insulator QI Series Instructions

For 1000 volts or less

Product Name	Conductor Size Range	Diameter Range* Inches (mm)	Max Connector O.D. Inches (mm)	Max Connector Length Inches (mm)	Reference Distance "X" Inches (mm)
QI-5/16-220	8-1/0 AWG	0.2-0.65 (5-16)	0.65 (16)	2.75 (70)	4.25 (108)
QI-10/37-270	2 AWG-500 kcmil	0.4-1.45 (10-37)	1.45 (37)	4.5 (114)	5.5 (140)
QI-18/57-325	250-1250 kcmil	0.7-2.25 (18-57)	2 (51)	6 (152)	7 (178)
QI-14/70-235	4/0 AWG - 500 kcmil(Cu)**, 800 kcmil(Al)**	0.5-2.75 (13-70)	2.75 (70)	5 (127)	4.65 (118)
QI-14/70-430	4/0 AWG - 3000 kcmil	0.5-2.75 (13-70)	2.75 (70)	12 (305)	8.50 (216)

^{*}Range reflects minmum and maximum O.D. over which the insulator will seal.

QTY: 1 Each



Working around energized electrical systems may cause serious injury or death. Installation should be performed by personnel familiar with good safety practice in handling electrical equipment. De-energize and ground all electrical systems before installing product.



^{**}Restricted by connector length.