



# Scotchgard™ Vehicle Protection Package - Application Chart

## Professional Series



### Scotchgard™ Carpet Protector (PN 38602)

Helps to resist carpet stains

1. Apply to clean, colorfast fabrics.
2. Shake well before spraying.
3. Hold spray bottle 6 inches from fabric.
4. Overlap spray using a sweeping motion to evenly treat carpet.
5. Allow carpet to dry completely, typically 1-4 hours\*. If white residue remains on carpet after drying due to over application, simply remove with light brushing.

**Note:** Wipe any overspray off adjacent surfaces to avoid visible residual or staining. This can be removed with water and a clean cloth.

Do **not** use Scotchgard™ Carpet Protector on fabric and upholstery. Scotchgard™ Fabric and Upholstery Protector should be used on fabric and upholstery.

\*Dry times can vary significantly by climate type. Dry times will be shorter in dry climates and longer in humid environments.



### Scotchgard™ Fabric and Upholstery Protector (PN 38617)

Helps stop spills from staining your seats

1. Apply to clean, colorfast fabrics.
2. Shake well before spraying.
3. Hold can upright and 6" from fabric surface.
4. Overlap spray using a sweeping motion to evenly treat fabric. Two light coats are better than one heavy coat. **Note:** Allow fabric to dry between coats.
5. Allow fabric to dry completely, typically 1 to 4 hours\*.

**Application Tip:** On upholstery, avoid heavy application and saturation into foam cushioning. A light spray coating once in the horizontal direction and once in the vertical direction should be sufficient. If necessary, a second light spray may be applied after first one has dried.

**Note:** Wipe any overspray off adjacent surfaces to avoid visible residual or staining. This can be removed with water and a clean cloth.

\*Dry times can vary significantly by climate type. Dry times will be shorter in dry climates and longer in humid environments.



### Scotchgard™ Leather and Vinyl Protector (PN 38601)

Helps protect interior surfaces

1. Test in an inconspicuous area before use.
2. Put a small amount of creamy gel on a clean cloth.
3. Spread evenly, using a circular motion, working the gel into the surface.
4. Dirty or textured surfaces may require a second application.
5. Turn cloth frequently and buff to a gloss until surface is dry. Do not leave surface wet or covered with excessive product.

**Note:** Wipe off any excess material in seams, edges, or adjacent areas with a dry, clean cloth. If product gets on carpet, remove using a damp, clean cloth.



### Scotchgard™ Paint Protector (PN 38600)

Safeguards your car's exterior finish

Wash and dry vehicle. Do not apply in direct sunlight or onto a hot surface.

#### Hand application:

1. Apply a thin, uniform film to the paint surface using a terry cloth wax applicator or a clean, soft, cotton terry cloth towel. Do not allow to dry to a haze.
2. Apply and remove product one panel at a time.
3. Remove residue and buff to a high gloss using a 3M™ Perfect-It™ Detailing Cloth (PN 06016).
4. Remove any excess product from adjacent surfaces (glass, vinyl, rubber) using a 3M™ Perfect-It™ Detailing Cloth (PN 06016).

#### Tool Application (most time efficient application method):

Using a 6" D/A (Dual Action) sander equipped with a 3M™ Hookit™ Clean Sand Painter's Backup Pad (PN 05551) and a Foam Applicator Pad:

1. Apply a thin uniform film to the paint surface using a DA equipped with a Foam Applicator Pad. Do not allow to dry to a haze.
2. Apply and remove product one panel at a time.
3. Buff to a high gloss with a polisher equipped with a clean, dry, terry cloth bonnet or by hand using a 3M™ Perfect-It™ Detailing Cloth (PN 06016).
4. Remove any excess product from adjacent surfaces (glass, vinyl, rubber) using a 3M™ Perfect-It™ Detailing Cloth (PN 06016).

**Note:** Allowing this product to dry to a haze is not recommended and can make removal difficult. If the product becomes dry or difficult to remove, use a damp 3M™ Perfect-It™ Detailing Cloth (PN 06016). A second coat is not necessary but can be applied if desired.

**Important:** 3M™ Paint Protection Film, graphics, or striping tape should be applied before the Paint Protector is applied.



## Accessories



- 3M™ Perfect-It™ Detailing Cloth, PN 06016



- 3M™ Hookit™ Clean Sand Painter's Backup Pad, PN 05551