ANZ Aluminum Repair Procedures

Sealing and Coating

Product List ANZ Coating Anti 3M™ Car Wash Soap Concentrate, 3.78 litre, PN **Pre-Cleaning** 38377 Prewash/clean vehicle prior to disassembly 3M™ All Purpose Cleaner (power wash undercarriage area at repair). and Degreaser Concentrate, 3.78 litre, PN 38350 3M™ General Purpose Adhesive Cleaner, aerosol, PN 08987: Adhesive Remover, PN 38983 Removal of Heavy Surface Contaminates Clean to remove heavy contaminants from repair area. Scotch-Brite™ Clean N Strip Disc, PN 57016 or Scotch-Brite™ Roloc™+ Clean N Strip TR Disc, PN 07466 3M™ Cubitron™ II Clean Sanding Hookit™ **OEM Coating Removal** Abrasive Disc, 6 in., 80+ grade, PN 31371 Remove OEM coating as needed using Clean N Strip disc. 3M™ Platinum™ Plus Finishing Featheredge using grade 80 abrasive on DA sander. Blow Glaze, 30 oz., PN 31180; off surface with clean, dry air. Clean surface with all purpose Glaze for DMS, PN 05862 cleaner and degreaser. 3M™ Hookit™ Purple Clean Sanding Sheet Roll, 150 grade, 70mm x 12m, PN 30710; Disc 334U, 6 in., P320 grit, PN 01812 Filling/Leveling Surface Use polyester glaze to fill the repair area, bringing it the same 3M™ Hookit™ Sanding Block Dust Free level as the surrounding coating. 70mm x 127mm, PN 05207 3M™ Dry Guide Coat, 50 gram applicator kit. PN 05861 Sanding and Primer Sand glaze using P150 on a hand block. Final featheredge area 3M™ Hookit™ Soft Interface Pad. using P320 abrasive on a DA sander. Blow off with clean, dry air. 6 in. x 1/2 in. x 3/4 in., PN 05777 Final clean with VOC compliant wax and grease remover. 3M™ Soft Edge Foam Masking Tape Apply primer following paint company recommendations. PLUS, 21mm (.8 in.), PN 06293 3M™ Smooth Transition Tape. Sanding Primer 1/4 in. (6.4mm), PN 06800 Apply 3M guide coat to primed surface. Sand primer using P320 on a DA sander with an interface pad. Blow off with clean, dry 3M™ Scotchblok™ Masking Paper, 18 in. x 180 ft., PN 06738 air. Final clean with VOC compliant wax and grease remover. Scotch® Performance Green Masking Tape 233+, Masking 12mm width (.47 in.), PN 26332 Apply soft edge foam masking tape following existing coating 3M™ Rocker Protector Pouch, edge. Final mask the area using tape and paper to protect from 3 fl. oz. (US), PN 08733; 5.5 fl. oz. (ÚS), PN 08734 3M™ Paintable Undercoating. Coating Test Panel Waterbased — Pouch. 5.5 fl. oz. (US), PN 08744 Apply the coating to a test panel. Always apply a light coat first, allow it to flash, and adjust the spray equipment to deliver the 3M™ Trizact™ Hookit™ Blending texture required to match the OEM appearance. Disc, 6 in., P1000 grit, PN 02090 Apply Coating Think About Your Health Apply anti chip coating to the repair area using settings from test panel, blending the material into surrounding area as needed. 3M[™] E-A-R[™] Skull Screws[™] Ear Plug, PN P1300

Blend Sanding

Use P1000 $3M^{m}$ Trizact m Disc on a DA sander to smooth the blend edges. This operation produces a smooth transition without removing chip coating profile.

Visit www.3m.com.au/aad or www.3m.co.nz/aad for more SOPs and videos



3M™ Half Facepiece

appropriate cartridge

Respirator, PN 07502 with

15200 or 3M Secure Fit AF401SF-AF

ly or designated for use on

