

Post-it® Flex Write Surface & Post-it® Dry Erase Surface

Surface Preparation Guide

Preparation Steps	Primed & Painted Drywall	Painted Steel	Glass	Finished Wood	Whiteboard	Chalkboard	Existing Dry Erase Painted Drywall	Existing Chalkboard Painted Surface	Heavily Textured or Delicate Surface
Debris Removal	Remove debris (ex: Tape, Nails, tacks, etc)								
Optional: Filler Application	Fill holes with 3M™ Patch Plus Primer			If needed, fill holes with Bondo®					
Optional: Surface Sanding	Recommend: 3M #180/220 Grit Sandpapers				If surface requires sanding: 3M #180/220 Grit Sandpapers Recommended				
Surface Cleaning	Clean with water, let dry	Clean with water, let dry	Clean with water or glass cleaner, let dry	Clean with water, let dry	Clean with Rubbing Alcohol	Clean with Rubbing Alcohol	Clean with Rubbing Alcohol	Clean with Rubbing Alcohol	
Adhesion Test	Recommended			Recommended		Recommended	Recommended	Recommended	
For Poor Adhesion: Use Primer*	Use a surface primer, let dry per instructions			Use a surface primer, let dry per instructions		Use a surface primer, let dry per instructions			
Post-Primer: Surface Cleaning	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	Clean with water, let dry	

Do not recommend applying product to the following surfaces:

- Brick
- Cinder Block
- Wallpaper
- Stainless Steel
- Textured
- Delicate
- Raw Wood

*Example Primer: KILZ2 Multi-Surface Interior/Exterior Primer & Sealer (Water-Based)

