




Personal Safety

- Respiratory Protection 
- Hearing Protection 
- Face Protection 
- Reusable Workwear 
- Safety Gloves 

Safety First! Always select appropriate personal protective equipment - eyewear, gloves, hearing and respiratory protection for your job and workplace.

Pre-Cleaning		<ul style="list-style-type: none"> • Degrease the surface using paint company or other recommended VOC-compliant water-based and solvent-based products. Always follow the manufacturer's instructions for surface cleaning instructions. 	
Shake Aerosol		<ul style="list-style-type: none"> • Agitate the aerosol can thoroughly — one minute of shaking is required to mix the components prior to use. Attach the desired accessory extension and actuator if needed to access the areas inside the panel enclosure. 	
Application with Standard Actuator		<ul style="list-style-type: none"> • If applying to new panels prior to installation, use the standard actuator. Spray up to three (3) coats to ensure full coverage and maximize protection 	
Mark Extension Wand		<ul style="list-style-type: none"> • If using the 360° accessory wand, mark the extension about 2 cm (1") from the end as a reference. This will help reduce overspray as you remove the wand from the cavity during application 	
Insert Wand into Panel opening		<ul style="list-style-type: none"> • Insert the wand to the farthest point. Begin spraying as you remove the wand until the reference mark comes into view. Repeat up to three (3) times to ensure complete coverage and maximize corrosion protection. 	 <p>3M™ Cavity Wax Plus</p>  <p>3M™ Cavity Wax Plus Applicator Wand Kit</p>
Clean Accessory Nozzle		<ul style="list-style-type: none"> • After application, invert the can and clear the material from the accessory wand and nozzle by depressing the actuator. To help prevent a buildup of cavity wax inside the wand or actuator, attach the actuator to a can of high power spray gun cleaner and rinse clean. 	
Remove Excess Cavity Wax		<ul style="list-style-type: none"> • Re-assemble the associated parts and wipe off any excess cavity wax using a VOC compliant surface cleaner. 	